



### **EYM-4950 96 x 48 1/8 DIN Universal Input Programmable Timer & Counter with Output Module System**

- 6 digits Process (PV) and 6 digits Set (SV) Value Display
- Operation with 2 Set Value
- Reset , Pause and ChA-ChB Counting Inputs
- Configurable Counter / "Totalizer Counter", Batch Counter ,  
Timer, Chronometer , Frequencycounter and Tachometer Functions
- Programmable Time Bases for Timer and Chronometer (Second ,  
Minute , Hour )
- Operation with Automatic and Manual Reset
- Output Module System
- NPN/PNP Type Operation
- INC , DEC , INC / INC , INC / DEC , UP / DOWN , x1 / x2 / x4  
Counting with Phase Shifting Property in Counter Function
- Multiplication Coefficient and Decimal Point Position
- Different Alarm Alternatives in Frequencycounter and Cycle  
Measuring Functions
- Absolute or Offset Operation in Counter Function
- RS-232 (standard) or RS-485 (optional) Serial Communication  
with Modbus ASCII or RTU Protocol

Instruction manual of EZM-4950 Programmable Timer&Counter consists of two main sections. Explanation of these sections are below. Also, there are other sections which include order information and technical specifications of the device. All titles and page numbers in instruction manual are in "CONTENTS" section. User can reach to any title with section number.

### Installation:

In this section, physical dimensions of the device, panel mounting, electrical wiring, module mounting in the device, physical and electrical installation of the device to the system are explained.

### Operation and Parameters:

In this section, user interface of the device, how to access to the parameters, description of parameters are explained.

Also in these sections, there are warnings to prevent serious injury while doing the physical and electrical mounting or using the device.

Explanation of the symbols which are used in these sections are given below.



This symbol is used for safety warnings. User must pay attention to these warnings.



This symbol is used to determine the dangerous situations as a result of an electric shock. User must pay attention to these warnings definitely.



This symbol is used to determine the important notes about functions and usage of the device.

## CONTENTS

<b>1.PREFACE</b> .....	Page 6
1.1 GENERAL SPECIFICATIONS	
1.2 ORDERING INFORMATION	
1.3 WARRANTY	
1.4 MAINTENANCE	
<b>2.INSTALLATION</b> .....	Page 9
2.1 GENERAL DESCRIPTION	
2.2 DIMENSIONS	
2.3 PANEL CUT-OUT	
2.4 ENVIRONMENTAL RATINGS	
2.5 PANEL MOUNTING	
2.6 INSTALLATION FIXING CLAMP	
2.7 REMOVING FROM THE PANEL	
2.8 SELECTION OF OPERATION FUNCTION AND INPUT TYPE WITH DIP SWITCH	
<b>3.ELECTRICAL WIRINGS</b> .....	Page 15
3.1 TERMINAL LAYOUT AND CONNECTION INSTRUCTION	
3.2 ELECTRICAL WIRING DIAGRAM	
3.3 CONNECTION OF DEVICE SUPPLY VOLTAGE INPUT	
3.4 COUNTING INPUT CONNECTION	
3.4.1 PROXIMITY & SWITCH CONNECTION	
3.4.2 INCREMENTAL ENCODER & SWITCH CONNECTION	
3.4.3 SWITCH CONNECTION	
3.5 GALVANIC ISOLATION TEST VALUES OF EZM-4950 PROGRAMMABLE TIMER&COUNTER AND OUTPUT MODULES	
<b>4.DEFINITIONS AND SPECIFICATIONS OF OUTPUT MODULES</b> .....	Page 22
4.1 EMO-400 RELAY OUTPUT MODULE	
4.2 EMO-410 SSR DRIVER MODULE	
4.3 EMO-420 DIGITAL (TRANSISTOR) OUTPUT MODULE	
4.4 INSTALLING AND PULLING OUT OUTPUT MODULES	
4.5 TO STICK OUTPUT MODULES' LABELS TO THE DEVICE	
<b>5.CONNECTION TERMINALS OF OUTPUT MODULES AND CONNECTION WIRING</b> .....	Page 27
5.1 EMO-400 RELAY OUTPUT MODULE CONNECTION	
5.2 EMO-410 SSR DRIVER MODULE CONNECTION	
5.3 EMO-420 DIGITAL (TRANSISTOR) OUTPUT MODULE CONNECTION	
<b>6.CONNECTIONS FOR RS-232 / RS-485 SERIAL COMMUNICATION</b> .....	Page 29
6.1 CABLE CONNECTION BETWEEN RS-232 TERMINAL OF THE DEVICE AND PC	
6.2 CONNECTION FOR RS-485 SERIAL COMMUNICATION	
6.3 INSTALLING RS-232 / RS-485 SERIAL COMMUNICATION MODULES TO THE DEVICE	
<b>7.DEFINITION OF FRONT PANEL AND ACCESSING TO THE PARAMETERS</b> .....	Page 32
7.1 DEFINITION OF FRONT PANEL	
7.2 POWER ON OBSERVATION OF EZM - 4950 PROGRAMMABLE TIMER & COUNTER AND SOFTWARE REVISION ON THE DISPLAY	

- 7.3 ADJUSTMENT OF SET1 AND SET2 VALUES
- 7.4 RESETTING COUNT VALUE AND OBSERVING TOTAL COUNT VALUE IN COUNTER / "TOTALIZER COUNTER" FUNCTION
- 7.5 COUNTER / "TOTALIZER COUNTER" PARAMETERS
  - 7.5.1 COUNTER / "TOTALIZER COUNTER" APPLICATIONS EXAMPLES
- 7.6 BATCH COUNTER PARAMETERS
  - 7.6.1 BATCH COUNTER APPLICATIONS EXAMPLES
- 7.7 TIMER PARAMETERS
  - 7.7.1 TIMER APPLICATIONS EXAMPLES
- 7.8 FREQUENCYMETER / TACHOMETER PARAMETERS
  - 7.8.1 FREQUENCYMETER / TACHOMETER APPLICATIONS EXAMPLES
- 7.9 CHRONOMETER PARAMETERS
  - 7.9.1 CHRONOMETER APPLICATIONS EXAMPLES
- 7.10 ACCESSING TO THE PROGRAM PARAMETERS

<b>8.PROGRAM PARAMETERS.....</b>	<b>Page 67</b>
<b>9.FAILURE MESSAGES IN EZM-4950 PROGRAMMABLE TIMER &amp; COUNTER ..</b>	<b>Page 100</b>
<b>10.SPECIFICATIONS.....</b>	<b>Page 102</b>

## **EU DECLARATION OF CONFORMITY**

**Manufacturer Company Name** : Emko Elektronik A.S.

**Manufacturer Company Address:** DOSAB, Karanfil Sokak, No:6, 16369 Bursa, Turkiye

**The manufacturer hereby declares that the product conforms to the following standards and conditions.**

**Product Name** : Programmable Timer & Counter

**Model Number** : EZM-4950

**Type Number** : EZM-4950

**Product Category** : Electrical equipment for measurement, control and laboratory use

**Conforms to the following directives :**

**73 / 23 / EEC The Low Voltage Directive as amended by 93 / 68 / EEC**

**89 / 336 / EEC The Electromagnetic Compatibility Directive**

**Has been designed and manufactured according to the following specifications**

**EN 61000-6-4:2001 EMC Generic Emission Standard for the Industrial Environment**

**EN 61000-6-2:2001 EMC Generic Immunity Standard for the Industrial Environment**

**EN 61010-1:2001 Safety Requirements for electrical equipment for measurement, control and laboratory use**

## 1.Preface


EZM Series Programmable Timer & Counter can be used in package machines, production and quality control rollers, in cutting and processing machine of glass, plastic, marble, sheet, iron, fabric all measuring and controlling of dimension, count, total count, speed, cycle, productivity, time and can be adapted easily to all mechanical construction and automation system. They can be used in many application with their control outputs, serial communication unit and output modules.

Some application fields which they are used are below:

### Application Fields

Glass  
Plastic  
Marble  
Sheet iron  
Automotive  
Machine production industries

## 1.1 General Specifications



## 1.2 Ordering Information

EZM-4950 (96x48 1/8 DIN)	A	B	C	D	E	/	F	G	H	I	/	U	V	W	Z
		00		0		/					/			0	0

A	Supply Voltage
1	100-240V $\sim$ (-15%;+10%) 50/60Hz
2	24 V $\sim$ (-15%;+10%) 50/60Hz 24V $\text{---}$ (-15%;+10%)
9	Customer (Maximum 240V $\sim$ (-15%;+10%))50/60Hz

D	Serial Communication	Product Code
0	None	-
1	RS-232	EMC-400
2	RS-485	EMC-410

FG	Module-1	Product Code
00	None	-
01	Relay Output Module(3A@250V $\sim$ Resistive Load)	EMO-400
02	SSR Driver Output Module	EMO-410
03	Digital(Transistor) Output Module	EMO-420

HI	Module-2	Product Code
00	None	-
01	Relay Output Module(3A@250V $\sim$ Resistive Load)	EMO-400
02	SSR Driver Output Module	EMO-410
03	Digital(Transistor) Output Module	EMO-420

U	Function of Device
0	Counter / "Totalizer Counter"
1	Batch Counter
2	Timer
3	Frequencymeter and Tachometer
4	Chronometer

V	Input Type
0	NPN
1	PNP

All order information of EZM-4950 Programmable Timer&Counter are given on the table at left. User may form appropriate device configuration from information and codes that at the table and convert it to the ordering codes.

Firstly, supply voltage then output modules and other specifications must be determined. Please fill the order code blanks according to your needs.

Please contact us, if your needs are out of the standards.



$\sim$  Symbol means Vac,

$\text{---}$  Symbol means Vdc

$\sim\text{---}$  Symbol means Vac and Vdc

### **1.3 Warranty**

EMKO Elektronik warrants that the equipment delivered is free from defects in material and workmanship. This warranty is provided for a period of two years. The warranty period starts from the delivery date. This warranty is in force if duty and responsibilities which are determined in warranty document and instruction manual performs by the customer completely.

### **1.4 Maintenance**

Repairs should only be performed by trained and specialized personnel. Cut power to the device before accessing internal parts.

Do not clean the case with hydrocarbon-based solvents (Petrol, Trichlorethylene etc.). Use of these solvents can reduce the mechanical reliability of the device. Use a cloth dampened in ethyl alcohol or water to clean the external plastic case.



## 2. Installation



Before beginning installation of this product, please read the instruction manual and warnings below carefully.

In package ,

- One piece unit
- Two pieces mounting clamps
- One piece instruction manual

A visual inspection of this product for possible damage occurred during shipment is recommended before installation. It is your responsibility to ensure that qualified mechanical and electrical technicians install this product.

If there is danger of serious accident resulting from a failure or defect in this unit, power off the system and separate the electrical connection of the device from the system.

The unit is normally supplied without a power switch or a fuse. Use power switch and fuse as required.

Be sure to use the rated power supply voltage to protect the unit against damage and to prevent failure.

Keep the power off until all of the wiring is completed so that electric shock and trouble with the unit can be prevented.

Never attempt to disassemble, modify or repair this unit. Tampering with the unit may result in malfunction, electric shock or fire.


Do not use the unit in combustible or explosive gaseous atmospheres.

During the equipment is putted in hole on the metal panel while mechanical installation some metal burrs can cause injury on hands, you must be careful.


Montage of the product on a system must be done with it's fixing clamps. Do not do the montage of the device with inappropriate fixing clamp. Be sure that device will not fall while doing the montage.

It is your responsibility if this equipment is used in a manner not specified in this instruction manual.


## 2.1 General Description



## 2.2 Dimensions



## 2.3 Panel Cut-Out



## 2.4 Environmental Ratings

### Operating Conditions



**Operating Temperature** : 0 to 50 °C



**Max. Operating Humidity** : 90% Rh (non-condensing)



**Altitude** : Up to 2000m.




#### Forbidden Conditions:

**Corrosive atmosphere**

**Explosive atmosphere**

**Home applications (The unit is only for industrial applications)**

## 2.5 Panel Mounting



1-Before mounting the device in your panel, make sure that the cut-out is the right size.


2-Check front panel gasket position

3-Insert the device through the cut-out. If the mounting clamps are on the unit, put out them before inserting the unit to the panel.



During installation into a metal panel, care should be taken to avoid injury from metal burrs which might be present. The equipment can loosen from vibration and become dislodged if installation parts are not properly tightened. These precautions for the safety of the person who does the panel mounting.

## 2.6 Installation Fixing Clamp



The unit is designed for panel mounting.

1-Insert the unit in the panel cut-out from the front side.

2- Insert the mounting clamps to the holes that located top and bottom sides of device and screw up the fixing screws until the unit completely immobile within the panel




Montage of the unit to a system must be done with it's own fixing clamps. Do not do the montage of the device with inappropriate fixing clamps. Be sure that device will not fall while doing the montage.

## 2.7 Removing from the Panel



Before starting to remove the unit from panel, power off the unit and the related system.



1-Loosen the screws.

2-Pull mounting clamps from top and bottom fixing sockets.

3-Pull the unit through the front side of the panel



### 3. Electrical Wirings



You must ensure that the device is correctly configured for your application. Incorrect configuration could result in damage to the process being controlled, and/or personal injury. It is your responsibility, as the installer, to ensure that the configuration is correct.

Parameters of the device has factory default values. These parameters must be set according to the system's needs.



Only qualified personnel and technicians should work on this equipment. This equipment contains internal circuits with voltage dangerous to human life. There is severe danger for human life in the case of unauthorized intervention.




Be sure to use the rated power supply voltage to protect the unit against damage and to prevent failure.



Keep the power off until all of the wiring is completed so that electric shock and trouble with the unit can be prevented.


#### 3.1 Terminal Layout and Connection Instructions



### 3.2 Electrical Wiring Diagram




Electrical wiring of the device must be the same as 'Electrical Wiring Diagram' below to prevent damage to the process being controlled and personnel injury.






### 3.3 Connection of Device Supply Voltage Input

Connection of Universal Supply Voltage Input



Connection of Low Voltage 24 V $\sim$  Supply Voltage Input



**Note-1 :**

There is internal 33R  $\Omega$  fusible flameproof resistor in 100-240 V $\sim$  50/60Hz

There is internal 4R7  $\Omega$  fusible flameproof resistor in 24V $\sim$  50/60Hz and 24V $\text{---}$

**Note-2 :** "L" is "+", "N" is "-" for 24V $\text{---}$  supply voltage

**Note-3 :** External fuse is recommended.



Make sure that the power supply voltage is the same indicated on the instrument.

Switch on the power supply only after that all the electrical connections have been completed.

Supply voltage range must be determined in order. While installing the unit, supply voltage range must be controlled and appropriate supply voltage must be applied to the unit. Controlling prevents damages in unit and system and possible accidents as a result of incorrect supply voltage.



There is no power supply switch on the device. So a power supply switch must be added to the supply voltage input. In accordance with the safety regulations, the power supply switch shall bring the identification of the relevant instrument. Power supply switch shall be easily accessible by the user.

Power switch must be two poled for separating phase and neutral. On/Off condition of power switch is very important in electrical connection. On/Off condition of power switch must be signed for preventing the wrong connection.

If an external fuse is used, it must be on phase connection in  $\sim$  supply input.



If an external fuse is used, it must be on (+) line connection in  $\text{---}$  supply input.



The instrument is protected with an internal fuse (Please refer to Note1 for information). In case of failure it is suggested to return the instrument to the manufacturer for repair.

### 3.4 Counting Input Connection

#### 3.4.1 Proximity & Switch Connection




**NOTE-1 :** Auxiliary power supply for external transmitter  
12V<sub>DC</sub> ± 10%, 50 mA maximum with short circuit protection

**NOTE-2 :** Reset and Pause inputs have protection time against electrical contact debounce. Protection time can be set with `PRO-D4` parameter. (2-250 msec.)


### 3.4.2 Incremental Encoder & Switch Connection

#### DIP SWITCH ADJUSTMENT : PNP



NOTE-1

#### DIP SWITCH ADJUSTMENT : NPN




NOTE-1

NOTE-1 : Auxiliary power supply for external transmitter  
12V<sub>DC</sub> ± 10%, 50 mA maximum short circuit protection


NOTE-2 : Reset and Pause inputs have protection time against electrical contact debounce. Protection time can be set with P\_r\_o\_t parameter. (2-250 msec.)

### 3.4.3 Switch Connection

#### DIP SWITCH ADJUSTMENT : PNP




#### DIP SWITCH ADJUSTMENT : NPN



NOTE-1 : Auxiliary power supply for external transmitter  
12V $\pm$  10%, 50 mA maximum short circuit protection

NOTE-2 : Reset and Pause inputs have protection time against electrical contact debounce. Protection time can be set with `P_r_o_u` parameter. (2-250 msec.)

### 3.5 Galvanic Isolation Test Values of EZM-4950 Programmable Timer & Counter and Output Modules




## 4. Definitions and Specifications of Output Modules

EZM-4950 programmable Timer & Counter is a modular product which is designed to operate with additional output units which user may need.

Two output modules can be plugged in the equipment by the user. User may configure the product for different applications according to the system requirements with the output modules which are described in this section.

### Dimensions of Output Modules



### 4.1 EMO-400 Relay Output Module

EMO-400 Relay output module can be plugged in Module-1 or Module-2 socket to be used in applications that relay output is necessary

#### Specifications of EMO-400 Relay Output Module

**Output** : 3A @ 250V ~ , Single Open Contact

**Dimensions** : 14x30.7x41.4mm

**Electrical Life** : 100,000 operation (Full Load)

#### Applications of EMO-400 Relay Output Module

It can be used for programmable different alarm functions as control or alarm output.

## 4.2 EMO-410 SSR Driver Module

EMO-410 SSR Driver Module can be plugged in Module-1 or Module-2 socket to be used in applications that SSR driver output is necessary

### Specification of EMO-410 SSR Driver Module

**Output** : Maximum 20 mA, 15-18V $\pm$ 10%, isolated

**Dimensions** : 14x30.7x41.4mm

### Applications of EMO-410 SSR Driver Module

It can be used for programmable different alarm functions as control or alarm output.

Note 1: SSR Driver Module must be preferred instead of relay output module in applications with short output period because of limited life of their relay contact (number of open/close events).

## 4.3 EMO-420 Digital (Transistor) Output Module

EMO-420 Digital (Transistor) Output Module can be plugged in Module-1 or Module-2 socket to be used in applications that digital output is necessary

### Specifications of EMO-420 Digital (Transistor) Output Module

**Output** : Maximum 40 mA, 15-18V $\pm$ 10%, isolated

**Dimensions** : 14x30.7x41.4mm

### Applications of EMO-420 Digital (Transistor) Output Module

It can be used for programmable different alarm functions as control or alarm output.


#### 4.4 Installing and Pulling Out Output Modules




First, detach all cable connections from the device and uninstall it from the panel.



Suppress to the lock pins where top and bottom of the device



Pull the cover case with your other hand from front panel to rear side.



Pull out the cover case from the device



Slide output modules into socket.

Pull out the module from it's socket, instead of this module install the new one or other module user wants to use.



Replace the cover case by taking care of the terminal numbers should be at right position.




After adding or changing modules to the unit, these changes must be taken into consideration while mounting of the unit to the system. If mounting is incorrect, it can cause accidents to harm system, operator or person who does the mounting. Responsibility of these kind of harmful events belongs to the user.



## 4.5 To Stick Output Modules' Labels to the Equipment

Every module which is plugged in Module-1 or Module-2 socket has labels' for showing the relation between connection terminal and the device. These labels are attached to empty attachment places which are separated for Module-1 and Module-2 on the device. Labels for all modules and attachment places are shown below.

Label which is plugged in Module-2 socket, describes module termination connection is attached to this area.



Label which is plugged in Module-1 socket, describes module termination connection is attached to this area.

### LABELS FOR OUTPUT MODULES



Label for EMO-400 Relay Output Module




Label for EMO-410 SSR Driver Module




Label for EMO-420 Digital (Transistor) Output Module

**Example :** If user installs EMO-400 Relay Output Module to Module-1 socket, EMO-410 SSR Output Module to Module-2 socket and attach the appropriate labels on the device view will be like below :




## 5.Connection Terminals of Output Modules and Connection Wirings


### Module-1 / Module-2 Optional Output Modules





### 5.1 EMO-400 Relay Output Module Connection



### 5.2 EMO-410 SSR Driver Module Connection




### 5.3 EMO-420 Digital (Transistor) Output Module Connection




## 6.Connection for RS-232 / RS-485 Serial Communication


### RS-232 Terminal Definitions



### RS-485 Terminal Definitions





## 6.1 Cable Connection Between RS-232 Terminal of the Device and the PC




Cable Length must be max. 12 meters for 9600 baud rate

PC (Personal Computer)  
9 Pin DCON connection




Cable Length must be max. 12 meters for 9600 baud rate

PC (Personal Computer)  
25 Pin DCON connection




## 6.2 Connection for RS-485 Serial Communication



### 6.3 Installing RS-232 / RS-485 Serial Communication Modules to the Device


Pull the cover case with your hand through rear side as explained in "Installing and Pulling Out Output Modules" section. Pull the modules in Module-1 and Module-2 socket through rear side. Separate supply card which is at the bottom of the equipment by lifting the locking tabs located on front panel. Pay attention to cable connection between top and bottom cards. Damages in this cable makes the equipment not to work.

RS-232 or RS-485 module is plugged into socket signed as A and B. Hold the equipment to be it's front panel is on your right, communication socket is on your left and module connection socket with 5 terminals on above. Plug in module connection socket with 5 terminals to the socket on Top Card. Do the same things for terminal socket in bottom card and connection socket with 3 terminals to the socket on Bottom Card. Replace the cover case by taking care of the terminal numbers should be at right position.



## 7. Definition of Front Panel and Accessing to the Set Parameters

### 7.1 Definition of Front Panel



**NOTE-1 :** Total count value is 12 digits in Counter / "Totalizer Counter" function


**NOTE-2 :** In Counter / "Totalizer Counter" function if SET1 operation form selection parameter [Pr0-22] is 000000, then SET1 can be negative. While most significant digit ( 6th digit ) of SET1 value is changed from 0 to 9 with increment button, after 9, "-" character is shown. If when "-" character is on the most significant digit ( 6th digit ) of SET1 value and Enter button is pressed, SET1 value becomes negative.



## 7.2 Power On Observation of EZM - 4950 Programmable Timer & Counter and Software Revision on the Display

When power is applied to the device, software revision number of the controller is momentarily illuminated on actual value display. Then operation screen is observed.

When power on, view of the screen is shown below:



Software Revision




Operation Screen is shown



If there is an unexpected situation while opening the device, power off the device and inform a qualified personnel.


### 7.3 Adjustment of SET1 and SET2 Values

#### Changing SET2 value in Counter / "Totalizer Counter" functions



If **Prp-28** Reset and Set Protection parameter is **000002**, **000003** or **000005** then SET2 value can not be changed. For details, refer to parameters section.


## Changing SET1 value in Counter / "Totalizer Counter" function



SET1 value is shown by pressing SET1 button.


Press Shift Button

Press SET1 or SET2 button to exit without saving Set value.



6th digit of SET1 value starts to flash. Press Shift button again.

Increase the flashing value with increment button.




Save the value as SET1 value by pressing Enter button.



If **Prp-28** Reset and Set Protection parameter is **000002** , **000003** or **000004** , then SET1 value can not be changed. For details, refer to parameters section.

## 7.4 Resetting Count Value and Observing Total Count Value in COUNTER / "TOTALIZER COUNTER" Function



When user stops pressing the buttons, operation screen is shown.


**Note-1:** If manual reset is applied when counting direction parameter  $Pr_{o-19}$  is 000001 difference between SET2 value and value on the screen is added to the total count value



**Note-2:** Becoming zero of count value is for if counting direction parameter  $Pr_{o-19}$  is 000000, if counting direction parameter  $Pr_{o-19}$  is 000001 count value becomes equal to SET2 value

**i** If  $Pr_{o-20}$  Reset and Set Protection parameter is 000001 or 000003 then total count value can not be reset. For details, refer to parameters section.

**i** RESET operation can be realized by Reset button or applying signal to the RESET input. These two operations are named MANUAL RESET in parameters section. At the end of the MANUAL RESET operation, if counting direction parameter  $Pr_{o-19}$  is 000000 then count value becomes 000000. If counting direction parameter  $Pr_{o-19}$  is 000001 then count value becomes equal to SET2 value.



## 7.5 COUNTER / "TOTALIZER COUNTER" Parameters

**SET1** SET value for Output-1. Control of the Output-1 is done according to this value. It can be adjusted from `000000` to `999999`

If SET1 operation form selection parameter `Pro-22` is selected operation with offset `000001`, it can be adjusted from `-999999` to `999999`

**SET2** SET value for Output-2. Control of the Output-2 is done according to this value. It can be adjusted from `000000` to `999999`

`Pro-01`

### Input Types and Functions

- `000000` Upcount on rising edge of Ch-A input(INC)
- `000001` Downcount on rising edge of Ch-A input(DEC)
- `000002` Upcount on rising edge of Ch-A input and downcount on rising edge of Ch-B input (INC / DEC)
- `000003` Upcount on rising edge of Ch-A and Ch-B inputs (INC / INC)
- `000004` Upcount on rising edge of Ch-A input when Ch-B is at 0, downcount on rising edge of Ch-A input when Ch-B is at 1.(UP / DOWN)
- `000005` x1 phase shifting (for incremental encoders)
- `000006` x2 phase shifting (for incremental encoders)
- `000007` x4 phase shifting (for incremental encoders)

`Pro-04`

### Pulse Time of Ch-A, Ch-B, Reset and Pause Inputs

It is used to protect against the electrical contact debounce or the signal that is less than the determined pulse time.

It can be adjusted from `000000` to `000250` msec . If it's adjusted to `000000` then there is no time protection for Ch-A and Ch-B. If the parameter value is adjusted `000000` or `000001` then Reset and Pause protection times are accepted as 2 msec.

`Pro-06`

### Output Functions

- `000000` **Manual Reset-1.** Device continues to count till manual reset is applied. Output-2 pulse time `Pro-11` is not considered.
- `000001` **Manual Reset-2.** Device continues to count till count value reaches to SET2 value. For starting to count again, manual reset input must be active. Output-2 pulse time `Pro-11` is not considered.
- `000002` **Manual Reset-3.** It operates like Manual Reset-1. Only difference, output-2 pulse time `Pro-11` is considered.



In operation with Manual or Automatic Reset, at the end of the reset operation, if counting direction parameter `Pro-19` `000000` count value becomes . If `000000` `Pro-19` ou `000001` becomes SET2.



For details on parameters, refer to Section 8 (Program Parameters).

**000003** **Automatic Reset-1.** Count value is reset when it reaches to SET2 value (For  $0 \Rightarrow P$ ). Count value is added to total count value and device starts to count from **000000**

**000004** **Automatic Reset-2.** Counting is stopped when count value reaches to SET2 value. Count value becomes zero (for  $0 \Rightarrow P$ ) at the end of output-2 pulse time **PrO-17**. And count value is added to total count value. Device starts to count from **000000**

**000005** **Automatic Reset-3.** Count value becomes zero (for  $0 \Rightarrow P$ ) when it reaches to SET2 value and count value is added to total count value. Device starts to count from **000000**. Meanwhile, SET2 value is shown in actual value display, count value is shown at the end of output-2 pulse time **PrO-17**

**000006** **Automatic Reset-4.** Counting is continued when count value reaches to SET2 value. Count value becomes zero (for  $0 \Rightarrow P$ ) at the end of Output-2 pulse **PrO-17** time and it is added to total count value. Device starts to count from **000000**

**000007** **Automatic Reset-5.** Counting is continued till manual reset is active. Output-1 and Output-2 pulse times (**PrO-16** and **PrO-17**) are not considered. It is preferred if upcount and downcount are done at the same time.



In operation with Manual or Automatic Reset, at the end of the reset operation, if counting direction parameter **PrO-19** **000000**, count value becomes .if **000000** **PrO-19** **000000** becomes SET2.

#### **PrO-14** Operation form for Output-1

**000000** Output - 1 Normally non-energised

**000001** Output - 1 Normally energised

#### **PrO-15** Operation form for Output-2

**000000** Output - 2 Normally non-energised

**000001** Output - 2 Normally energised

#### **PrO-16** Output-1 Pulse Time

Energising time for Output-1. It can be adjusted from **000000** to **009999**. If it is **000000**, then it operates indefinitely.

#### **PrO-17** Output-2 Pulse Time

Energising time for Output-2. It can be adjusted from **000000** to **009999**. If it is **000000**, then it operates indefinitely.

#### **PrO-19** Selection of counting direction

**000000** Upcount ( $0 \Rightarrow$  Preset)

**000001** Downcount (Preset  $\Rightarrow 0$ )



For details on parameters, refer to Section 8 (Program Parameters).

**Pro-20 Point Position for display**

- 000000 No point
- 000001 Between first and second digits
- 000002 Between second and third digits
- 000003 Between third and fourth digits
- 000004 Between fourth and fifth digits

**Pro-21 Saving Count Value (Power down back-up)**

- 000000 Count value is saved to memory when power is off and restored on power up.
- 000001 Count value is not saved to memory when power is off

**Pro-22 Selection of SET1 Operation Form**

- 000000 Operating without offset. It can be adjusted from  000000 to  999999
- 000001 Operating with offset. SET1 can be adjusted SET1 = SET2+SET1

**Pro-23 Slave Address**

Device address for serial communication bus.  
It can be adjusted from  000001 to  000247

**Pro-24 Selection of Modbus Protocol Type**

- 000000 MODBUS ASCII communication protocol is selected.
- 000001 MODBUS RTU communication protocol is selected

**Pro-25 Parity**

- 000000 No parity
- 000001 Odd parity
- 000002 Even parity

**Pro-26 Baud Rate**

- 000000 1200 Baud Rate
- 000001 2400 Baud Rate
- 000002 4800 Baud Rate
- 000003 9600 Baud Rate
- 000004 19200 Baud Rate



For details on parameters, refer to Section 8 (Program Parameters).

Pro-27

#### Stop Bit

000000

1 Stop Bit

000001

2 Stop Bits

Pro-28

#### Reset and Set protection (Accessing from front panel)

000000

There is no Reset and Set protection

000001

Reset Button protection is active

000002

SET1 and SET2 protection is active

000003

Reset Button, SET1 and SET2 protection is active (Full protection)

000004

SET1 protection is active

000005

SET2 protection is active

Pro-30

#### Multiplication Coefficient

Count value is multiplied with this value. It can be adjusted from 000001 to 999999. If it is 010000, it has no effect.

Pro-PS

#### Program Password

It is used for accessing to the program parameters.

It can be adjusted from 000000 to 099999. If it is 000000, there is no password protection.



For details on parameters, refer to Section 8 (Program Parameters).




## 7.5.1 COUNTER / "TOTALIZER COUNTER" Applications Examples

### EXAMPLE-1 :

There is a production band like in diagram below. Bottles are perceived by a proximity sensor in Ch-A. If


$Pr_0-01 = 000000$  ;  $Pr_0-30 = 010000$  ;



Counting the bottles is done with upcount by using only Ch-A input. When user reset count value with manual reset, count value is added to total count value.

### EXAMPLE-2 :

There is a cloth workbench. An encoder with 100 pulse is connected to this system. The encoder is connected to Ch-A and Ch-B inputs.



Encoder with 100 pulse

$Pr_0-01 = 000005$  ;  $Pr_0-04 = 000000$  ;  
 $Pr_0-19 = 000000$  ;  $Pr_0-30 = 010000$  ;

You wish to display 200 in actual value display for a drive pulley going forward of 100 cm. If you want to display cloth length in actual value display, you must adjust coefficient parameter  $Pr_0-30$  like in below:

$Pr_0-30$  = Measured cloth length  
 Value on the screen

$Pr_0-30$  Coefficient must be =  $100/200 = "00.5000"$


After adjustment of coefficient, calculated value is cloth length and you can see this value in actual value display.

If you want to display the speed of the drive pulley as dm instead of cm  $Pr_0-20$  point position for display parameter must be  $000001$ , if m instead of cm, this parameter must be  $000002$

### EXAMPLE-3 :

There is a system like in the diagram below. Ch-A is used for measuring the flow.

If  $Pr_0-01 = 000000$  ;  $Pr_0-30 = 010000$




In this application, total amount of flow is measured. If it is known how many pulses are being sent for each liter from the sensor in Ch-A we can measure the desired value by changing the  $Pr_0-30$  parameter.

For example if sensor gives 10 pulses for 1 liter fluid flow and we want to observe the liquid quantity as liter, coefficient parameter  $Pr_0-30$  parameter value must be  $Pr_0-30 = 1Lt/10 pulse = "00.1000"$

#### EXAMPLE - 4 :

There is a cutting unit below. 100- pulse encoder is connected to Ch-A and Ch-B inputs.



If  $Pr0-01 = 000005$  ;  $Pr0-04 = 000000$  ;  $Pr0-19 = 000000$  ;  
 $Pr0-22 = 000001$  And  $Pr0-30 = 010000$  ;

If  $Pr0-22$  parameter is  $000001$  , then device operates with offset. If SET1 is negative value, then Output-1 will be active in SET2-SET1. This option offers us to solve wrong cutting problem on the speedy mechanic, by reaching slowly to the target.

**(SET1=SET1+SET2)**

For example ;if SET1 = -000100 ; SET2 = 000500 ; then SET1 = -100+500 = 400

If more sensitivity is needed,  $Pr0-01$  parameter can be selected  $000006$  or  $000001$

For example, while x1 phase shifting counting is performed in a system with a cutting unit as shown above, a 100-pulse encoder is connected to Ch-A and Ch-B inputs. If the system is advanced 100 cm for 50 encoder pulses, so it is advanced 2 cm with 1 encoder pulse.

When x2 phase shifting counting is performed, for the system is being advanced 100 cm, 100 encoder pulses are needed. In this case, the system is advanced 1 cm with 1 encoder pulse.


When x4 phase shifting counting is performed, for the system is being advanced 100 cm, 200 encoder pulses are needed. In this case, the system is advanced 0.5 cm with 1 encoder pulse.

Sensitivity of the system is changed from 2 cm to 0.5 cm.

#### EXAMPLE-5 :


There are two sensors in Ch-A and Ch-B inputs for determining the amount of the liquid in Channel-A and Channel-B. Multiplication coefficient parameter  $Pr0-30$  is adjusted to converts the pulses to observe the amount of the liquid exactly in the actual value screen. (For example liter)

For observing total amount of liquid  $Pr0-01$  must be  $000003$



If the tank is filled with liquid 20 liters from Channel-1 and 40 liters from Channel-2, 60 liters is observed in actual value screen.

If Output-1 controls the Channel-1, Output-2 controls the Channel-2, SET1 is 20 and SET2 is 40, then it is possible to close the system after filling the tank with 20 liters from Channel-1 and 40 liters from Channel-2



## 7.6 BATCH COUNTER Parameters

**SET1** SET value for Output-1. Control of the Output-1 is done according to this value. It can be adjusted from `000000` to `999999`

**SET2** SET value for Output-2. Control of the Output-2 is done according to this value. It can be adjusted from `000000` to `999999`

`Pr0-01`

### Input Types and Functions

- `000000` Upcount on rising edge of input Ch-A (INC)
- `000001` Downcount on rising edge of input Ch-A (DEC)
- `000002` Upcount on rising edge of input Ch-A and downcount on rising edge of input Ch-B (INC / DEC)
- `000003` Upcount on rising edge of input Ch-A and Ch-B (INC / INC)
- `000004` Upcount on rising edge of Ch-A input when Ch-B is at 0, downcount on rising edge of Ch-A input when Ch-B is at 1. (UP / DOWN)
- `000005` x1 phase shifting (for incremental encoders)
- `000006` x2 phase shifting (for incremental encoders)
- `000007` x4 phase shifting (for incremental encoders)

`Pr0-04`

### Pulse Time of Ch-A, Ch-B, Reset and Pause Inputs

It is used to protect against the electrical contact debounce or the signal that is less than the determined pulse time.

It can be adjusted from `000000` to `000250` msec. If it's adjusted to `000000` then there is no time protection for Ch-A and Ch-B. If the parameter value is adjusted `000000` or `000001` then Reset and Pause protection times are accepted as 2 msec.

- i** When **SET1** value is shown on the screen if **MANUAL RESET** is applied, batch count value, when **SET2** value is shown on the screen if **MANUAL RESET** is applied, normal count value becomes zero.
- i** In operation with Manual or Automatic Reset, at the end of the reset operation, if counting direction parameter `Pr0-19` `000000` count value becomes . If `000000` `Pr0-19` or `000001` becomes SET2. For both conditions (`0P` or `P0`), batch count value becomes `000000`
- i** For details on parameters, refer to Section 8 (Program Parameters).

**Pro-06****Output Functions**

000000

Manual Reset. BATCH counting operation continues until manual reset input is active.

000001

Automatic Reset. BATCH counting operation continues until Batch count value reaches to SET1 value. When Batch count value is equal to SET1 value, Batch count value becomes zero (for 0→P) and device starts to count again.

**Pro-14****Operation Form of Output-1**

000000

Output - 1 Normally non-energised

000001

Output - 1 Normally energised

**Pro-15****Operation Form of Output-2**

000000

Output - 2 Normally non-energised

000001

Output - 2 Normally energised

**Pro-16****Output-1 Pulse Time**

Energising time for Output-1. It can be adjusted from 000000 to 009999. If it is 000000, then it operates indefinitely.

**Pro-17****Output-2 Pulse Time**

Energising time for Output-2. It can be adjusted from 000000 to 009999. If it is 000000, then it operates indefinitely.

**Pro-19****Selection of counting direction**

000000

Upcount (0 → Preset )

000001

Downcount (Preset → 0)

**Pro-20****Point Position for display**

000000

No point

000001

Between first and second digits

000002

Between second and third digits

000003

Between third and fourth digits

000004

Between fourth and fifth digits

**Pro-21****Saving Count Value (Power down back-up)**

000000

Count value is saved power is off and restored on power up.

000001

Count value is not saved to memory when power is off

**Pro-23****Slave Address**

Device address for serial communication bus. It can be adjusted from 000001 to 000247



For details on parameters, refer to Section 8 (Program Parameters).

Pro-24

#### Selection of Modbus Protocol Type

000000

MODBUS ASCII communication protocol is selected.

000001

MODBUS RTU communication protocol is selected

Pro-25

#### Parity

000000

No parity

000001

Odd parity

000002

Even parity

Pro-26

#### Baud Rate

000000

1200 Baud Rate

000001

2400 Baud Rate

000002

4800 Baud Rate

000003

9600 Baud Rate

000004

19200 Baud Rate

Pro-27

#### Stop Bit

000000

1 Stop Bit

000001

2 Stop Bits

Pro-28

#### Reset and Set protection (Accessing from front panel)

000000

There is no Reset and Set protection

000001

Reset Button protection is active

000002

SET1 and SET2 protection is active

000003

Reset Button , SET1 and SET2 protection is active (Full protection)

000004

SET1 protection is active

000005

SET2 protection is active

Pro-30

#### Multiplication Coefficient

Count value is multiplied with this value. It can be adjusted from 000001 to 999999. If it is 000000, it has no effect.

Pro-PS

#### Program Password

It is used for accessing to the program parameters.

It can be adjusted from 000000 to 009999. If it is 000000, there is no password protection.




For details on parameters, refer to Section 8 (Program Parameters).

## 7.6.1 BATCH COUNTER Applications Examples

### EXAMPLE-1 :

There is a production band like in diagram below. Bottles are perceived by a proximity sensor in Ch-A. If

$Pr_{0-01} = 000000$  ;  $Pr_{0-30} = 010000$  ;




Device is used in a packing line as shown on the left. Bottles must be counted into packs of 4 bottles and dispatched in a box containing a batch of 4 packs. According to this, SET1 and SET2 are defined 4. 4 pieces of packet which contain a batch of 4 series are allowed to be formed.

If  $Pr_{0-06} = 000001$  (Automatic Reset-1); after arranging the bottles in a box as shown on the left, output-1 will be active and it stops the system. Batch count value is reset and it will be ready to count the new series.


### EXAMPLE-2 :

There is a cloth workbench. An encoder with 100 pulse is connected to this system. The encoder is connected to Ch-A and Ch-B inputs.

If  $Pr_{0-01} = 000005$  ;  $Pr_{0-04} = 000000$  ;  
 $Pr_{0-19} = 000000$  And  $Pr_{0-30} = 010000$  ;



Coefficient parameter is adjusted to be able to observe the cloth length in actual value screen. If we want to be cut the cloth in same length at 5m and stopped the system when 40 pieces of 5m cloths are formed, SET1 must be 40 and SET must be 5.



## 7.7 TIMER Parameters

### SET1

SET value for Output-1. Control of the Output-1 is done according to this value. It can be changed by time unit and scale selection parameter  $PrO-05$

### SET2

SET value for Output-2. Control of the Output-2 is done according to this value. It can be changed by time unit and scale selection parameter  $PrO-05$

$PrO-05$

#### Time Unit and Scale Selection

000000

Hour / Minute

It can be adjusted from 000000 to 009959

000001

Minute / Second

It can be adjusted from 000000 to 009959

000002

Second / Millisecond

It can be adjusted from 000000 to 009999

000003

Hour / Minute

It can be adjusted from 000000 to 002359

000004

Hour

It can be adjusted from 000000 to 099999

000005

Minute

It can be adjusted from 000000 to 099999

000006

Second

It can be adjusted from 000000 to 099999

$PrO-06$

#### Output Functions

000000

**Manual Reset-1.** Device continues to count till manual reset is applied. Output-2 pulse time  $PrO-17$  is not considered.

000001

**Manual Reset-2.** Device continues to count till count value reaches to SET2 value. For starting to count again, manual reset input must be active. Output-2 pulse time  $PrO-17$  is not considered.

000002

**Manual Reset-3.** It operates like Manual Reset-1. Only difference, output-2 pulse time  $PrO-17$  is considered.

000003

**Automatic Reset-1.** Count value becomes zero (0→P) when it reaches to SET2 value. Count value is added to total count value and device starts to count from 000000

000004

**Automatic Reset-2.** Counting is stopped when count value reaches to SET2 value. Count value is becomes zero (0→P) at the end of output-2 pulse time  $PrO-17$  And device starts to count again.



In operation with Manual or Automatic Reset, at the end of the reset operation, if counting direction parameter  $PrO-19$  000000 count value becomes



.If 000000  $PrO-19$  or 000000 becomes SET2.

For details on parameters, refer to Section 8 (Program Parameters).

**000005** **Automatic Reset-3.** Count value becomes zero (0→P) when it reaches to SET2 value. Device starts to count again. Meanwhile, SET2 value is shown in actual value display, count value is shown at the end of output-2 pulse time **Pro-17**

**000006** **Automatic Reset-4.** Counting is continued when count value reaches to SET2 value. Count value becomes zero (0→P) at the end of Output-2 pulse time **Pro-17**. Device starts to count again.

**000007** **Automatic Reset-5.** When count value reaches to SET2 value, SET1 changes position, count value becomes zero (for 0→P) Output-1 and Output-2 does not change position until count value reaches to SET2 value.



**In operation with Manual or Automatic Reset, at the end of the reset operation, if counting direction parameter **Pro-19** **000000** count value becomes .if **000000** **Pro-19** or **000001** becomes SET2.**

#### **Pro-14** Operation form for Output-1

**000000** Output - 1 Normally non-energised

**000001** Output - 1 Normally energised

#### **Pro-15** Operation form for Output-2

**000000** Output - 2 Normally non-energised

**000001** Output - 2 Normally energised

#### **Pro-16** Output-1 Pulse Time

Energising time for Output-1. It can be adjusted from **000000** to **009999**. If it is **000000**, it operates indefinitely.

#### **Pro-17** Output-2 Pulse Time

Energising time for Output-2. It can be adjusted from **000000** to **009999**. If it is **000000**, it operates indefinitely.

#### **Pro-19** Selection of counting direction

**000000** Upcount (0 → Preset)

**000001** Downcount (Preset → 0)

#### **Pro-21** Saving Count Value (Power down back-up)

**000000** Count value is saved when power is off and restored on power up.

**000001** Count value is not saved to memory when power is off

#### **Pro-23** Slave Address

Device address for serial communication bus.

It can be adjusted from **000001** to **000247**



**For details on parameters, refer to Section 8 (Program Parameters).**



Pro-24

#### Selection of Modbus Protocol Type

000000

MODBUS ASCII communication protocol is selected.

000001

MODBUS RTU communication protocol is selected

Pro-25

#### Parity

000000

No parity

000001

Odd parity

000002

Even parity

Pro-26

#### Baud Rate

000000

1200 Baud Rate

000001

2400 Baud Rate

000002

4800 Baud Rate

000003

9600 Baud Rate

000004

19200 Baud Rate

Pro-27

#### Stop Bit

000000

1 Stop Bit

000001

2 Stop Bits

Pro-28

#### Reset and Set protection (Accessing from front panel)

000000

There is no Reset and Set protection

000001

Reset Button protection is active

000002

SET1 and SET2 protection is active

000003

Reset Button , SET1 and SET2 protection is active (Full protection)

000004

SET1 protection is active

000005

SET2 protection is active

Pro-PS

#### Program Password

It is used for accessing to the program parameters.

It can be adjusted from 000000 to 999999 . If it is 000000 , there is no password protection.




For details on parameters, refer to Section 8 (Program Parameters).

## 7.7.1 Timer Applications Examples

### EXAMPLE-1 :

There is a switch for giving start and stop signal on PAUSE input.

If  $Pr0-05 = 000001$  ;



When switch is "On", counting is started (Minute / second).  
When switch is "Off", counting is stopped. Time between opening and closing of the switch is observed on actual value screen.


Expired time can be reset with manual reset. If total operation time is wanted to be observed on the screen, manual reset is not applied and after Start/Stop operation counting is started from the last count value.

NOTE: If output-1 and output-2 is wanted to be used as an alarm output;

For example SET1 = 10.00 ; SET2 = 30.00 and  $Pr0-06 = 000002$

Device starts to count (Minute / second) when switch is "On". It is possible to have a warning when SET1 and SET2 times are expired and stopping the alarm at the end of the Output-1 and Output-2 pulse times. (  $Pr0-16$  And  $Pr0-17$  )

## 7.8 FREQUENCYMETER / TACHOMETER Parameters



### SET1

SET value for Output-1. Control of the Output-1 is done according to this value. It can be adjusted from 000000 to 999999

### SET2

SET value for Output-2. Control of the Output-2 is done according to this value. It can be adjusted from 000000 to 999999

Pro-03

#### Selection of Measurement Method

000000

Frequency or cycle is calculated by measuring cycle time of the signals in Ch-A input

000001

Frequency or cycle is calculated by counting the pulses in Ch-A input during the time is set in measurement period parameter Pro-08

Pro-04

#### Pulse Time of Ch-A, Ch-B, Reset and Pause Inputs

It is used to protect against the electrical contact debounce or the signal that is less than the determined pulse time.

It can be adjusted from 000000 to 000250 msec. If it's adjusted to 000000 then there is no time protection for Ch-A and Ch-B. If the parameter value is adjusted 000000 or 000001 then Reset and Pause protection times are accepted as 2 msec.

Pro-07

#### Time Out (Input Signal Reset Time)

The actual value is reset, if there is no signal in Ch-A input during this time  
It can be adjusted from 000001 to 000099

Pro-08

#### Measurement Period

Number of pulses is counted during this time  
It can be adjusted from 000001 to 000999

Pro-09

#### Output-1 Function

000000

Output-1 is latched. It does not change position until manual reset is applied.

000001

Non-latched with hysteresis output is selected.

000002

Output-1 is an alarm output. For details, refer to Output-1 Alarm functions parameter Pro-11.



For details on parameters, refer to Section 8 (Program Parameters).

### Pro-10 Output-2 Function

000000 Output-2 is latched. It does not change position until manual reset is applied.

000001 Non-latched with hysteresis output is selected.

### Pro-11 Alarm Functions for Output-1

If Output-1 function parameter Pro-09 is 000002, Output-1 becomes active according to this parameter

000000 High Alarm.

000001 Low Alarm.

000002 Deviation High Alarm.

000003 Deviation Low Alarm.

000004 Deviation Band Alarm.

### Pro-12 Hysteresis for Output-1

Hysteresis for Output-1. It is used if Output-1 is non-latched. It can be adjusted from 000000 to 050000

### Pro-13 Hysteresis for Output-2

Hysteresis for Output-2. It is used if Output-2 is non-latched. It can be adjusted from 000000 to 050000

### Pro-14 Operation form for Output-1

000000 Output - 1 Normally non-energised

000001 Output - 1 Normally energised

### Pro-15 Operation form for Output-2

000000 Output - 2 Normally non-energised

000001 Output - 2 Normally energised

### Pro-16 Output-1 Pulse Time

Energising time for Output-1. It can be adjusted from 000000 to 009999. If it is 000000, then it operates indefinitely.

### Pro-17 Output-2 Pulse Time

Energising time for Output-2. It can be adjusted from 000000 to 009999. If it is 000000, then it operates indefinitely.



For details on parameters, refer to Section 8 (Program Parameters).

Pro-18

### Start of Controlling

000000

Controlling is started when the device is energised

000001

Controlling is started when count value reaches to SET1 value.

000002

Controlling is started when count value reaches to SET2 value.

Pro-20

### Point Position for display

000000

No point

000001

Between first and second digits

000002

Between second and third digits

000003

Between third and fourth digits

000004

Between fourth and fifth digits

Pro-23

### Slave Address

Device address for serial communication bus.

It can be adjusted from 000001 to 000247

Pro-24

### Selection of Modbus Protocol Type

000000

MODBUS ASCII communication protocol is selected.

000001

MODBUS RTU communication protocol is selected

Pro-25

### Parity

000000

No parity

000001

Odd parity

000002

Even parity

Pro-26

### Baud Rate

000000

1200 Baud Rate

000001

2400 Baud Rate

000002

4800 Baud Rate

000003

9600 Baud Rate

000004

19200 Baud Rate

Pro-27

### Stop Bit

000000

1 Stop Bit

000001

2 Stop Bits



For details on parameters, refer to Section 8 (Program Parameters).

Pro-28

### Reset and Set protection (Accessing from front panel)

000000

There is no Reset and Set protection

000001

Reset Button protection is active

000002

SET1 and SET2 protection is active

000003

Reset Button , SET1 and SET2 protection is active (Full protection)

000004

SET1 protection is active

000005

SET2 protection is active

Pro-29

### Frequency / Cycle Multiplication Coefficient

Count value is multiplied with this value. It can be adjusted from 000001 to 999999

Pro-30

### Multiplication Coefficient

Count value is multiplied with this value. It can be adjusted from 000001 to 999999 . If it is 010000 , it has no effect.

Pro-PS

### Program Password

It is used for accessing to the program parameters.

It can be adjusted from 000000 to 999999 . If it is 000000 , there is no password protection.



For details on parameters, refer to Section 8 (Program Parameters).

## 7.8.1 FREQUENCYMETER / TACHOMETER Applications Examples

Two different method are used in Frequencymeter / Tachometer function;


**Method -1 :** To get frequency or cycle value by measuring the revolution time  
(This method is used if the sensor sends one pulse per revolution)

**Method -2 :** To get frequency or cycle value by counting the pulses during the time is set in  
Pr0-08 parameter

**Method -1 :**

If Pr0-03 is 000000 ;

Measuring starts on rising edge of Ch-A input. Time (T) is between two rising edge.



If Pr0-29 parameter is 000001 , Pr0-30 parameter is 010000 , then speed is measured cycle per second.

For measuring the speed cycle per minute, Pr0-29 parameter must be 000060


For measuring the speed cycle per hour, Pr0-29 parameter must be 003600

### EXAMPLE-1 :

There is a cloth workbench as shown below:

When Pr0-29 parameter is 000001 , Pr0-30 parameter is 010000 , cloth is advanced 80 cm per revolution and 20 cycle / sec is observed on the display.

User can observe cloth length , 80 cm, on the display by changing the Pr0-29 and Pr0-30 Parameter



$$\text{Pr0-30} = \frac{\text{Cloth Length in one revolution}}{\text{Pr0-29} * \text{Value on the display (f)}}$$

If Pr0-29 = 1

Pr0-30 Multiplication coefficient = 80/20 = 4

After adjustment of the parameter, 80 cm / sec is observed on the display.

For dm/sec, point position for display parameter Pr0-20 must be 000001

For m/sec, point position for display parameter Pr0-20 must be 000002

For cm / minute, Pr0-29 parameter must be 000060

For cm / hour, Pr0-29 parameter must be 003600




This method must be used if speed is over 100 cycle / second

## Method -2:


If  $Pr_0-03$  parameter is  $000001$  ;

Pulses in Ch-A input is counted during time is set in  $Pr_0-08$  parameter. Average time for one pulse is calculated.



### EXAMPLE-2:

For one revolution of cylinder 10 pulse is applied in Ch-A input during  $Pr_0-08 = 000020$




If 10 pulse is applied during 2 secs;

$T = 2/10 = 0.2\text{sec}$   $f = 1/T$   $f = 5$  cycle / sec is shown on the display

If  $Pr_0-29$  parameter is  $000001$  and  $Pr_0-30$  parameter is  $010000$  , speed is measured as cycle per second.

For cycle / minute,  $Pr_0-29$  parameter must be  $000060$

For cycle / hour,  $Pr_0-29$  parameter must be  $003600$



### EXAMPLE-3:

8 pulse is applied per revolution during  $Pr_0-08 = 000005$

If  $Pr_0-29$  parameter is  $000001$  and

$Pr_0-30$  Parameter is  $010000$ , speed of the system (cycle per second) is calculated as shown below:


If 8 pulse is applied during 0.5 sec;

$T = 0.5/8 = 0.0625\text{sec}$   $f = 1/T$   $f = 16$  cycle / sec is shown on the display

For cycle / minute,  $Pr_0-29$  parameter must be  $000060$

For cycle / hour,  $Pr_0-29$  parameter must be  $003600$





## 7.9 CHRONOMETER Parameters

### SET1

SET value for Output-1. Control of the Output-1 is done according to this value. It can be changed by time unit and scale selection parameter **Pro-05**

### SET2

SET value for Output-2. Control of the Output-2 is done according to this value. It can be changed by time unit and scale selection parameter **Pro-05**

**Pro-02**

#### Input Type and Function Selection for Chronometer

000000

Period measurement of signals in Ch-A input

000001

Pulse time measurement of signals in Ch-A input

000002

Sum of the time difference between Ch-A and Ch-B inputs rising edges

**Pro-04**

#### Pulse Time of Ch-A, Ch-B, Reset and Pause Inputs

It is used to protect against the electrical contact debounce or the signal that is less than the determined pulse time.

It can be adjusted from 000000 to 000250 msec. If it's adjusted to 000000 then there is no time protection for Ch-A and Ch-B. If the parameter value is adjusted 000000 or 000001 then Reset and Pause protection times are accepted as 2 msec.

**Pro-05**

#### Time Unit and Scale Selection

000000

Hour / Minute

It can be adjusted from 000000 to 009959

000001

Minute / Second

It can be adjusted from 000000 to 009959

000002

Second / Millisecond

It can be adjusted from 000000 to 009959

000003

Hour / Minute

It can be adjusted from 000000 to 002359

000004

Hour

It can be adjusted from 000000 to 099999

000005

Minute

It can be adjusted from 000000 to 099999

000006

Second

It can be adjusted from 000000 to 099999



In operation with Manual or Automatic Reset, at the end of the reset operation, if counting direction parameter **Pro-19** 000000 count value becomes .If 000000 **Pro-19** or 000001 becomes SET2.



For details on parameters, refer to Section 8 (Program Parameters).

PrO-06

### Output Functions

000000

**Manual Reset-1.** Device continues to count till manual reset is applied. Output-2 pulse time [PrO-17] is not considered.

000001

**Manual Reset-2.** Device continues to count till count value reaches to SET2 value. For starting to count again, manual reset input must be active. Output-2 pulse time [PrO-17] is not considered.

000002

**Manual Reset-3.** It operates like Manual Reset-1. Only difference, output-2 pulse time [PrO-17] is considered.

000003

**Automatic Reset-1.** Count value becomes zero (for 0⇒P) when it reaches to SET2 value and device starts to count again.

000004

**Automatic Reset-2.** Counting is stopped when count value reaches to SET2 value. Count value becomes zero (for 0⇒P) at the end of output-2 pulse time [PrO-17]. And device starts to count again.

000005

**Automatic Reset-3.** Count value becomes zero (for 0⇒P) when it reaches to SET2 value. Device starts to count again. Meanwhile, SET2 value is shown in actual value display, count value is shown at the end of output-2 pulse time.

000006

**Automatic Reset-4.** Counting is continued when count value reaches to SET2 value. Count value becomes zero (0⇒P) at the end of Output-2 pulse time [PrO-17] device starts to count again.

000007

**Automatic Reset-5.** When count value reaches to SET2 value, SET1 changes position, count value becomes zero (0⇒P). Output-1 and Output-2 do not change position, until count value reaches to SET2 value.



In operation with Manual or Automatic Reset, at the end of the reset operation, if counting direction parameter [PrO-19] is 000000 count value becomes . If [PrO-19] is 000001, count value becomes SET2.

PrO-14

### Operation form for Output-1

000000

Output - 1 Normally non-energised

000001

Output - 1 Normally energised

PrO-15

### Operation form for Output-2

000000

Output - 2 Normally non-energised

000001

Output - 2 Normally energised

PrO-16

### Output-1 Pulse Time

Energising time for Output-1. It can be adjusted from 000000 to 009999. If it is 000000, then it operates indefinitely.

PrO-17

### Output-2 Pulse Time

Energising time for Output-2. It can be adjusted from 000000 to 009999. If it is 000000, then it operates indefinitely.

PrO-19

### Selection of counting direction

000000

Upcount (0⇒Preset)

000001

Downcount (Preset⇒0)



For details on parameters, refer to Section 8 (Program Parameters).

**Pro-21****Saving Count Value (Power down back-up)**

000000

Count value is saved to memory when power is disconnected and restored on power up.

000001

Count value is not saved to memory when power is disconnected

**Pro-23****Slave Address**

Device address for serial communication bus.

It can be adjusted from 000001 to 000247

**Pro-24****Selection of Modbus Protocol Type**

000000

MODBUS ASCII communication protocol is selected.

000001

MODBUS RTU communication protocol is selected

**Pro-25****Parity**

000000

No parity

000001

Odd parity

000002

Even parity

**Pro-26****Baud Rate**

000000

1200 Baud Rate

000001

2400 Baud Rate

000002

4800 Baud Rate

000003

9600 Baud Rate

000004

19200 Baud Rate

**Pro-27****Stop Bit**

000000

1 Stop Bit

000001

2 Stop Bits

**Pro-28****Reset and Set protection (Accessing from front panel)**

000000

There is no Reset and Set protection

000001

Reset Button protection is active

000002

SET1 and SET2 protection is active

000003

Reset Button , SET1 and SET2 protection is active (Full protection)

000004

SET1 protection is active

000005

SET2 protection is active

**Pro-PS****Program Password**

It is used for accessing to the program parameters.

It can be adjusted from 000000 to 009999 . If it is 000000 , there is no password protection.




For details on parameters, refer to Section 8 (Program Parameters).

## 7.9.1 Examples About CHRONOMETER Applications

### EXAMPLE-1 :

There is a switch for giving start and stop signal on Ch-A input.

$Pr_0-02 = 000001$  ;  $Pr_0-04 = 000050$  ;  $Pr_0-05 = 000001$  iken ;




When switch is "On", counting is started (Minute / second). When switch is "Off", counting is stopped. Time between opening and closing of the switch is observed on actual value screen.

Expired time can be reset with manual reset. If total operation time is wanted to be observed on the screen, manual reset is not applied and after Start/Stop operation counting is started from the last count value.

### EXAMPLE-2 :

There is a production band as shown below. There are two sensors, first is on Ch-A input used for starting the system, second is on Ch-B input used for stopping the system. If

$Pr_0-02 = 000002$  ;  $Pr_0-04 = 000050$  ;  $Pr_0-05 = 000001$  ;




When the object passes in front of the first sensor on Ch-A input, counting is started (Minute / second).

When the object passes in front of the second sensor on Ch-B input, counting is stopped.


Time between two objects can be determined.

## 7.10 Accessing to the Program Parameters

Parameters are grouped as program parameters. Accessing to the program parameters is same for all functions. So, only accessing to the program parameters for COUNTER / "TOTALIZER COUNTER" is explained in this section. For details on parameters refer to PROGRAM PARAMETERS section.



The most significant digit of the parameter (1st digit for this parameter) flashes.



### Output Functions

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.

Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### Output-1 Operation Form

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.

Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### Output-2 Operation Form

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.

Press ENTER button

The most significant digit of the parameter (4th digit for this parameter) flashes.




### Output-1 Pulse Time

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.

Press ENTER button

The most significant digit of the parameter (4th digit for this parameter) flashes.



### Output-2 Pulse Time

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.



Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### Direction of the Counting

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.



Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### Point position for the display

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.



Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### Saving Count Value (Power down back-up)


You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any



Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### SET1 Operation Form Selection

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.

Press ENTER button

The most significant digit of the parameter (3rd digit for this parameter) flashes.



### Communication Accessing Address

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.

Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### Modbus Protocol Type Selection

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.

Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### Parity Selection

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.

Press ENTER button



The most significant digit of the parameter (1st digit for this parameter) flashes.



### Baud Rate

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.



Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### Stop Bit Selection

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.



Press ENTER button

The most significant digit of the parameter (1st digit for this parameter) flashes.



### Reset and Set Protection

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.



Press ENTER button

The most significant digit of the parameter (6th digit for this parameter) flashes.



### Multiplication Coefficient

You can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Press PROG button to exit from programming section without doing any changes.




Press ENTER button

When **Psuurd** password screen is shown if ENTER button is pressed without entering the password, this Parameter can not be observed.

The most significant digit of the parameter (4th digit for this parameter) flashes.

Press PROG button to exit from programming section without doing any changes.



Pro-PS  
000000



### Program Password

User can change the parameter with INCREMENT button, save it to the memory and pass to the next parameter with ENTER button.

Continue to press ENTER button for scanning all parameters.



000000  
003000



### Operation Screen



Pro-01  
000000



### Input Types and Functions


## 8. Program Parameters

Pro-01

Input Types and Functions  
(It is accessible in COUNTER / "TOTALIZER COUNTER" and BATCH COUNTER functions)


000000

Upcount on rising edge of Ch-A input




000001

Downcount on rising edge of Ch-A input.




000002

Upcount on rising edge of Ch-A input.  
Downcount on rising edge of Ch-B input.




**000003**


Upcount on rising edge of Ch-A input  
 Upcount on rising edge of Ch-B input

**000004**

Upcount on rising edge of Ch-A input when Ch-B is at 0  
 Downcount on rising edge of Ch-A when Ch-B is at 1

**000005**


**x1 Phase Shifting** (for incremental encoders)  
 Upcount on rising edge of Ch-A input when Ch-B is at 0  
 Downcount on rising edge of Ch-A input when Ch-B is at 1



If **Pr0-01** is **000005**, **Pr0-04** must be **000000**. If not counting is not performed.

**000006****x2 Phase Shifting** (for incremental encoders)


Upcount on rising edge of Ch-A when Ch-B is at 0  
 Downcount on rising edge of Ch-A when Ch-B is at 1  
 Upcount on falling edge of Ch-A when Ch-B is at 1  
 Downcount on falling edge of Ch-A when Ch-B is at 0



If **Pr0-01** is **000006**, **Pr0-04** must be **000000**. If not counting is not performed.

**000007****x4 Phase Shifting** (for incremental encoders)


Upcount on rising edge of Ch-A when Ch-B is at 0  
 Downcount on falling edge of Ch-A when Ch-B is at 0  
 Downcount on rising edge of Ch-A when Ch-B is at 1  
 Upcount on falling edge of Ch-A when Ch-B is at 1  
 Downcount on rising edge of Ch-B when Ch-A is at 0  
 Upcount on falling edge of Ch-B when Ch-A is at 0  
 Upcount on rising edge of Ch-B when Ch-A is at 1  
 Downcount on falling edge of Ch-B when Ch-A is at 1





If **Pr0-01** is **000007**, **Pr0-04** must be **000000**. If not counting is not performed.

**Pro-02****Selection of Input Type Function for Chronometer  
(It is accessible only in CHRONOMETER function)****000000**

Period measurement in Ch-A input.

**000001**

Pulse time measurement in Ch-A input.

**000002**Sum of the time difference between Ch-A and Ch-B inputs  
rising edges

Input type function selection parameter **Pro-02** for chronometer is performed according to the time range is set in Time Unit and Scale selection parameter **Pro-05**

Pro-03

### Selection of Measuring Method

(It is accessible only in FREQUENCYMETER / TACHOMETER Function)

000000

Frequency or cycle is calculated by measuring cycle time of the signals in Ch-A input

000001

Frequency or cycle is calculated by counting the pulses in Ch-A input during the time is set in measurement period parameter Pro-08



For details on these methods, refer to Section 7.8.1“Examples About Frequency/Tachometer Function Applications”  
Only Ch-A input performs in Frequency/Tachometer function.

Pro-04

### Pulse Time of Ch-A, Ch-B, Reset and Pause Input

(It is accessible in functions except for TIMER function)

It is used to protect against the electrical contact debounce or the signal that is less than the determined pulse time.

It can be adjusted from 000000 to 000250 msec. If it's adjusted to 000000 then there is no time protection for Ch-A and Ch-B. If the parameter value is adjusted 000000 or 000001 then Reset and Pause protection times are accepted as 2 msec.



If Input Types and Functions parameter Pro-01 is 000005, 000006 or 000007 then pulse time of Ch-A and Ch-B parameter Pro-04 must be 000000. If not counting is not performed.

Pro-05

### Selection of Time Unit and Scale

(It is accessible in TIMER and CHRONOMETER functions)

000000

Hour / Minute

It can be adjusted from 000000 to 009959

000001

Minute / Second

It can be adjusted from 000000 to 009959

000002

Second / Millisecond

It can be adjusted from 000000 to 009999

000003

Hour / Minute

It can be adjusted from 000000 to 002359

**000004** Hour  
It can be adjusted from **000000** to **099999**

**000005** Minute  
It can be adjusted from **000000** to **099999**

**000006** Second  
It can be adjusted from **000000** to **099999**




After adjustment of Time Range parameter **Pr0-05**, if SET1 and SET2 values are not appropriate for this selection, SET1 and SET2 are changed according to this selection. (E.g. If time range is 99.99 and SET1 is 45.94, there is no problem. If time range is 99.59 and SET1 is 45.94, then SET1 is changed as 45.59)

**Pr0-06** Output Functions  
(It is accessible in functions except for FREQUENCYMETER / TACHOMETER function)  
This parameter can be adjusted from **000000** to **000007** in Batch Counter function and operates different from the other functions.

**Pr0-06** → **000000** Manual Reset-1.  
Device continues to count till manual reset is applied.  
Output-2 pulse time **Pr0-17** is not considered.

How it operates in COUNTER / "TOTALIZER COUNTER", TIMER and CHRONOMETER function is explained below:

Counting direction : 0 ⇒ P (Upcount)      **Pr0-19** = **000000**




When count value reaches to SET1 value, Output-1 becomes active. If Output-1 pulse time **Pr0-16** is **000000**, Output-1 does not change condition until manual reset input is active. If Output-1 pulse time **Pr0-16** is not 0, at the end of the pulse time Output-1 becomes inactive. When count value reaches to SET2 value, Output-2 becomes active. Counting continues over SET2 value. Output-2 pulse time **Pr0-17** is not considered.

Count value is added to total count value when manual reset is active in COUNTER / "TOTALIZER COUNTER" functions.



How it operates in COUNTER / “TOTALIZER COUNTER”, TIMER and CHRONOMETER functions is explained below:

Counting direction :  $P \Rightarrow 0$  (Downcount)  $Pr0-19 = 000001$




When the count value reaches to SET1 value, Output-1 becomes active. If Output-1 Pulse Time  $Pr0-16$  is  $000000$ , Output-1 does not change condition until manual reset input is active. If Output-1 pulse time  $Pr0-16$  is not 0, Output-1 becomes inactive at the end of the pulse time. When actual value reaches to  $000000$ , Output-2 becomes active. Counting continues under  $000000$  Output-2 pulse time  $Pr0-17$  is not considered.

Count value is added to total count value when manual reset is active in COUNTER / “TOTALIZER COUNTER” functions.

$Pr0-06 \rightarrow 000001$  Manual Reset-2.  
(Output-2 Pulse Time  $Pr0-17$  is not considered)

How it operates in COUNTER / “TOTALIZER COUNTER”, TIMER and CHRONOMETER functions is explained below:

Counting direction :  $0 \Rightarrow P$  (Upcount)  $Pr0-19 = 000000$




When the count value reaches to SET1 value, Output-1 becomes active. If Output-1 pulse time  $PrO-16$  is  $000000$ , Output-1 does not change position until manual reset input is active. If Output-1 pulse time  $PrO-16$  is not 0, Output-1 becomes inactive at the end of the pulse time.

When the count value reaches to SET2 value, Output-2 becomes active. Counting does not continue over SET2 value. For starting to count manual reset input must be active. Output-2 Pulse Time  $PrO-17$  Is not considered.

Count value is added to total count value when manual reset is active in COUNTER / "TOTALIZER COUNTER" functions.

**How it operates in COUNTER / "TOTALIZER COUNTER", TIMER and CHRONOMETER functions is explained below:**

Counting direction :  $P \Rightarrow 0$  (Downcount)  $PrO-19 = 000001$



When the count value reaches to SET1 value, Output-1 becomes active. If Output-1 pulse time  $PrO-16$  is  $000000$ , Output-1 does not change condition until manual reset input is active. If Output-1 pulse time  $PrO-16$  is not 0, Output-1 becomes inactive at the end of the pulse time.

When the count value reaches to  $000000$  value, Output-2 becomes active. Counting does not continue under  $000000$ . For starting to count manual reset input must be active. Output-2 pulse time  $PrO-17$  Is not considered.

Count value is added to total count value when manual reset is active in COUNTER / "TOTALIZER COUNTER" functions.

Pr0-06 → 000002


### Manual Reset-3.

Counting continues until Manual Reset input is active.  
(Output-2 Pulse Time [Pr0-17] is considered)

How it operates in COUNTER / "TOTALIZER COUNTER", TIMER and CHRONOMETER functions is explained below:

Counting direction : 0 ⇒ P (Upcount)

Pr0-19 = 000000




When the count value reaches to SET1 value, Output-1 becomes active. If Output-1 Pulse Time [Pr0-16] is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time [Pr0-16] is 000000, changes position until Manual Reset input is active or according to Output-2.

When the count value reaches to SET2 value, Output-2 becomes active. Counting continues until manual reset input is active. If Output-2 Pulse Time [Pr0-17] is not 0, Output-2 changes position at the end of the pulse time. In this case, if Output-1 is active, it becomes inactive with Output-2.

Count value is added to total count value when manual reset is active in COUNTER / "TOTALIZER COUNTER" functions.

How it operates in COUNTER / “TOTALIZER COUNTER”, TIMER and CHRONOMETER function is explained below:

Counting direction :  $P \Rightarrow 0$  (Downcount)  $\overline{Pr0-19} = \overline{0000001}$



When the count value reaches to SET1 value, Output-1 becomes active. If Output-1 pulse time  $\overline{Pr0-16}$  is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time  $\overline{Pr0-16}$  is 000000 it changes position until Manual Reset input is active or according to Output-2.

When count value reaches to 000000 value, Output-2 becomes active. Counting continues until manual reset input is active. If Output-2 Pulse time  $\overline{Pr0-17}$  is not 0, Output-2 changes position at the end of the pulse time. In this case, if Output-1 is active, it becomes inactive with Output-2.


Count value is added to total count value when manual reset is active in COUNTER / “TOTALIZER COUNTER” functions.

Pr0-06 → 000003

### Automatic Reset-1

How it operates in COUNTER / "TOTALIZER COUNTER", TIMER and CHRONOMETER functions is explained below:

Counting direction : 0 ⇒ P (Upcount)      Pr0-19 = 000000



When the count value reaches to SET1 value, Output-1 becomes active. If Output-1 pulse time  $Pr0-16$  is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time  $Pr0-16$  is 000000, it changes position until Manual Reset input is active or according to Output-2 position.

When the count value reaches to SET2 value, Output-2 becomes active. Count value is reset. If Output-2 pulse time  $Pr0-17$  is not 0, Output-2 changes position at the end of the pulse time. In this case, if Output-1 is active, it becomes inactive with Output-2.


Count value is added to total count value when automatic reset is active in COUNTER / "TOTALIZER COUNTER" functions.



If output functions parameter  $Pr0-06$  is selected Automatic Reset (000003, 000004, 000005 or 000006), then  $Pr0-17$  must be different from zero. If not Automatic Reset is not realised.

How it operates in COUNTER / “TOTALIZER COUNTER”, TIMER and CHRONOMETER function is explained below:

Counting Direction : P  $\Rightarrow$  0 (Downcount) PrO-19 = 000001



When the count value reaches to SET1 value, Output-1 becomes active. If Output-1 pulse time  $PrO-16$  is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time  $PrO-16$  is 000000 it changes position until Manual Reset input is active or according to Output-2 position.

When the count value reaches to 000000 value, Output-2 becomes active. Count value becomes equal to Set-2 value and counting is started again. If Output-2 pulse time  $PrO-17$  is not 0, Output-2 changes position at the end of the pulse time. In this case, if Output-1 is active, it becomes inactive with Output-2.

Count value is added to total count value when automatic reset is active in COUNTER / “TOTALIZER COUNTER” functions.



If output functions parameter  $PrO-06$  is selected Automatic Reset (000001, 000004, 000005 or 000006), then  $PrO-17$  must be different from zero. If not Automatic Reset is not realized.


PrO-06 → 000004

## Automatic Reset-2

How it operates in COUNTER / "TOTALIZER COUNTER", TIMER and CHRONOMETER function is explained below:

Counting direction : 0 ⇒ P (Upcount)

PrO-19 = 000000



When the count value reaches to SET1, Output-1 becomes active. If Output-1 pulse time  $PrO-16$  is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time  $PrO-16$  is 000000, it changes position until Manual Reset input is active or according to Output-2 position.

When the count value reaches to SET2, Output-2 becomes active. Counting is stopped. If Output-2 pulse time  $PrO-17$  is not 0, count value is reset and Output-2 becomes inactive at the end of the pulse time. In this case, if Output-1 is active, it becomes inactive with Output-2.


Count value is added to total count value when automatic reset is active in COUNTER / "TOTALIZER COUNTER" functions.



If output functions parameter  $PrO-06$  is selected Automatic Reset (000003, 000004, 000005 or 000006), then  $PrO-17$  must be different from zero. If not, Automatic Reset is not realised.

How it operates in COUNTER / “TOTALIZER COUNTER”, TIMER and CHRONOMETER functions are explained below:

Counting direction : P ⇒ 0 (Downcount)  $PrO-19 = 000001$



When the count value reaches to SET1, Output-1 becomes active. If Output-1 pulse time  $PrO-16$  is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time  $PrO-16$  is 000000, it changes position until Manual Reset input is active or according to Output-2 position.

When the count value reaches to 000000 value, Output-2 becomes active. Counting is stopped. If Output-2 pulse time  $PrO-17$  is not 0, count value becomes equal to SET2 value, counting is started again and Output-2 becomes inactive. In this case, if Output-1 is active, it becomes inactive with Output-2.

Count value is added to total count value when automatic reset is active in COUNTER / “TOTALIZER COUNTER” functions.




If output functions parameter  $PrO-06$  is selected Automatic Reset (000003, 000004, 000005 or 000006), then  $PrO-17$  must be different from zero. If not, Automatic Reset is not realised.



How it operates in COUNTER / “TOTALIZER COUNTER”, TIMER and CHRONOMETER functions are explained below:

Counting direction : 0 ⇒ P (Upcount)

PrO-19 = 000000



When the count value reaches to SET1, Output-1 becomes active. If Output-1 pulse time  $PrO-16$  is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time  $PrO-16$  is 000000, it changes position until Manual Reset input is active or according to Output-2 position.

When the count value reaches to SET2, Output-2 becomes active and count value is reset.

When the count value reaches to SET2, Output-2 becomes active and count value is reset. But SET2 value is observed in actual value display. If Output-2 pulse time  $PrO-17$  is not 0, count value is observed in actual value display and Output-2 becomes inactive. In this case, if Output-1 is active, it becomes inactive with Output-2.


Count value is added to total count value when automatic reset is active in COUNTER / “TOTALIZER COUNTER” functions.



If output functions parameter  $PrO-06$  is Automatic Reset (000003, 000004, 000005 or 000006), then  $PrO-17$  must be different from zero. If not, Automatic Reset is not realised.

How it operates in COUNTER / “TOTALIZER COUNTER”, TIMER and CHRONOMETER functions are explained below:

Counting Direction : P  $\Rightarrow$  0 (Downcount)  $P_{r0-19} = 000001$



When the count value reaches to SET1, Output-1 becomes active. If Output-1 pulse time  $P_{r0-16}$  is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time  $P_{r0-16}$  is 000000, it changes position until Manual Reset input is active or according to Output-2 position.

When the count value reaches to 000000 value, Output-2 becomes active, count value becomes equal to SET2 and counting continues. But 000000 observed in actual value display. If Output-2 pulse time  $P_{r0-17}$  is not 0, count value is observed in actual value screen and Output-2 becomes inactive at the end of the pulse time. In this case, if Output-1 is active, it becomes inactive with Output-2.


Count value is added to total count value when automatic reset is active in COUNTER / “TOTALIZER COUNTER” functions.



If output functions parameter  $P_{r0-06}$  is selected Automatic Reset (000003, 000004, 000005 or 000006), then  $P_{r0-17}$  must be different from zero. If not, Automatic Reset is not realised.

How it operates in COUNTER / "TOTALIZER COUNTER", TIMER and CHRONOMETER functions are explained below:

Counting direction : 0 ⇒ P (Upcount)      PrO-19 = 000000



When the count value reaches to SET1, Output-1 becomes active. If Output-1 pulse time  $PrO-16$  is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time  $PrO-16$  is 000000, it changes position until Manual Reset input is active or according to Output-2 position.

When the count value reaches to SET2, Output-2 becomes active and counting continues over 0. If Output-2 pulse time  $PrO-17$  is not 0, count value is reset and Output-2 becomes inactive at the end of the pulse time. In this case, if Output-1 is active, it becomes inactive with Output-2.


Count value is added to total count value when automatic reset is active in COUNTER / "TOTALIZER COUNTER" functions.



If output functions parameter  $PrO-06$  is selected Automatic Reset (000003, 000004, 000005 or 000006), then  $PrO-17$  must be different from zero. If not, Automatic Reset is not realised.

How it operates in COUNTER / “TOTALIZER COUNTER”, TIMER and CHRONOMETER functions are explained below:

Counting Direction : P  $\Rightarrow$  0 (Downcount)  $P_{r0-19} = 000001$



When the count value reaches to SET1, Output-1 becomes active. If Output-1 pulse time  $P_{r0-16}$  is not 0, Output-1 changes position at the end of the pulse time. If Output-1 Pulse Time  $P_{r0-16}$  is 000000, it changes position until Manual Reset input is active or according to Output-2 position.

When count value reaches to 000000 value, Output-2 becomes active and counting continues under 0. If Output-2 pulse  $P_{r0-17}$  time is not 0, count value becomes equal to SET2 and Output-2 becomes inactive. In this case, if Output-1 is active, it becomes inactive with Output-2.

Count value is added to total count value when automatic reset is active in COUNTER / “TOTALIZER COUNTER” functions.



If output functions parameter  $P_{r0-06}$  is selected Automatic Reset (000003, 000004, 000005 or 000006), then  $P_{r0-17}$  must be different from zero. If not, Automatic Reset is not realised.

Pr0-06 → 000001


### Automatic Reset-5

Pulse times  $Pr0-16$  and  $Pr0-17$  is not considered.

How it operates in COUNTER / "TOTALIZER COUNTER" functions are explained below:

Counting direction : 0 ⇒ P (Upcount)

$Pr0-19 = 000000$




If count value is equal or greater than SET1 value, then Output-1 becomes active. Output-1 pulse time  $Pr0-16$  is not considered.

If count value is equal or greater than SET2 value, then Output-2 becomes active. If count value is less than SET2 value, Output-2 becomes inactive. Output-2 pulse time  $Pr0-17$  is not considered.

Count value is added to total count value when Manual Reset is performed.

Counting direction : P ⇒ 0 (Downcount)

$Pr0-19 = 000001$



If count value is equal or less than SET1 value, then Output-1 becomes active. If it is greater than SET1 value, Output-1 becomes inactive. Output-1 pulse time  $Pr0-16$  is not considered.

If count value is equal or less than  $000000$  value, then Output-2 becomes active. If count value is greater than  $000000$  value, then Output-2 becomes inactive. Output-2 pulse time  $Pr0-17$  is not considered.

Count value is added to total count value when Manual Reset is performed.



It is preferred if upcount and downcount is performed at the same time.

PrQ-06 → 000001


### Automatic Reset-5

Output-2 Pulse Time PrQ-17 is not considered

How it operates in TIMER and CHRONOMETER functions are explained below:

Counting direction : 0 ⇒ P (Upcount)

PrQ-19 = 000000




If count value is equal to or greater than SET1 value, then Output-1 becomes active. If Output-1 pulse time PrQ-16 is not 0, Output-1 changes position at the end of the pulse time. If Output-1 pulse time PrQ-16 is 000000, then Output-1 becomes inactive when count value reaches to SET2 value.

When count value reaches to SET2 value, count value is reset and Output-2 becomes active. Output-2 does not change position until count value reaches to SET2 value again.

Output-2 pulse time PrQ-17 is not considered.

Counting direction : P ⇒ 0 (Downcount)

PrQ-19 = 000001




If count value is equal to or less than SET1 value, then Output-1 becomes active. If Output-1 pulse time PrQ-16 is not 0, Output-1 changes position at the end of the pulse time. If Output-1 pulse time PrQ-16 is 000000, when count value reaches to 000000, Output-1 becomes inactive.

When count value reaches to 000000, count value becomes equal to SET2 value and Output-2 becomes active. Output-2 does not change position until count value reaches to 000000 again. Output-2 pulse time PrQ-17 is not considered.

**Pr0-06****Output Functions for BATCH COUNTER****Pr0-06** → **000000****Manual Reset**

How it operates in BATCH COUNTER function is explained below:


**Counting direction : 0 ⇒ P (Counting upwards)****Pr0-19 = 000000**

When count value reaches to SET2 value, count value is reset and Output-2 becomes active. If Output-2 pulse time  $Pr0-17$  is  $000000$  Then Output-2 does not change position until manual reset input is active. If Output-2 pulse time  $Pr0-17$  is not 0, Output-2 becomes inactive at the end of the pulse time.

When Output-2 becomes active, batch count value is added 1 (Batch count value can be observed by pressing SET1 button). When number of how many times Output-2 is active becomes equal to SET-1 value, then Output-1 becomes active. If Output-1 pulse time  $Pr0-18$  is  $000000$ , then Output-1 does not change position until manual reset input is active. If Output-1 pulse time  $Pr0-18$  is not, then Output-1 becomes inactive at the end of the pulse time.

How it operates in BATCH COUNTER function is explained below:

Counting Direction :  $P \Rightarrow 0$  (Downcount)  $Prd-19 = 000001$



When count value reaches to  $000001$ , count value becomes equal to SET2 and Output-2 becomes active. If Output-2 Pulse Time  $Prd-17$  is  $000000$ , then Output-2 does not change position until manual reset input is active. If Output-2 pulse time  $Prd-17$  is not 0, then Output-2 becomes inactive at the end of the pulse time.


When Output-2 becomes active, batch count value is added 1 (Batch count value can be observed by pressing SET1 button). When number of how many times Output-2 is active becomes equal to SET-1 value, then Output-1 becomes active. If Output-1 pulse time  $Prd-16$  is  $000000$ , then Output-1 does not change position until manual reset input is active. If Output-1 pulse time  $Prd-16$  is not, then Output-1 becomes inactive at the end of the pulse time.



PrO-06 → 000001 Automatic Reset

How it operates in BATCH COUNTER function is explained below:

Counting direction : 0 ⇒ P (Upcount) PrO-19 = 000000




When count value reaches to SET2 value, count value is reset and Output-2 becomes active. If Output-2 pulse time PrO-17 is 000000, then Output-2 does not change position until manual reset input is active. If Output-2 pulse time PrO-17 is not 0, Output-2 becomes inactive at the end of the pulse time.

When Output-2 becomes active, 1 is added to batch count value is (Batch count value can be observed by pressing SET1 button). When number of how many times Output-2 is active becomes equal to SET1 value, then Output-1 becomes active and Batch count value is reset automatically. If Output-1 pulse time PrO-16 is 000000, then Output-1 does not change position until manual reset input is active. If Output-1 pulse time PrO-16 is not 0, then Output-1 becomes inactive at the end of the pulse time.

Count direction : P ⇒ 0 (Downcount)

$P_{r0-19} = 000001$



When count value reaches to  $000000$  value, count value becomes equal to SET2 value and Output-2 becomes active. If Output-2 pulse time  $P_{r0-17}$  is  $000000$ , then Output-2 does not change position until manual reset input is active. If Output-2 pulse time  $P_{r0-17}$  is not 0, Output-2 becomes inactive at the end of the pulse time.

When Output-2 becomes active, 1 is added to batch count value is (Batch count value can be observed by pressing SET1 button). When number of how many times Output-2 is active becomes equal to SET1 value, then Output-1 becomes active and Batch count value is reset automatically. If Output-1 pulse time  $P_{r0-16}$  is  $000000$ , then Output-1 does not change position until manual reset input is active. If Output-1 pulse time  $P_{r0-16}$  is not 0, then Output-1 becomes inactive at the end of the pulse time.

**Pro-07**

**Time Out (Input Signal Reset Time)**  
 (It is accessible only in FREQUENCYMETER / TACHOMETER function)

Actual count value is reset if no signal is applied to Ch-A input for a time which is greater than the value is set in this parameter.  
 It can be adjusted from **000001** to **000099**



This parameter is visible if **Pro-03** measurement method selection parameter is **000000**. Only Ch-A input is performed in Frequency/Tachometer functions

**Pro-08**

**Measurement Period**  
 (It is accessible only in FREQUENCYMETER / TACHOMETER Function)

Number of pulses in Ch-A input is counted during this time  
 It can be adjusted from **000001** to **000999**



This parameter is visible if **Pro-03** measurement method selection parameter is **000000**. Only Ch-A input is performed in Frequency/Tachometer functions


**Pro-09**

**Output-1 Function**  
 (It is accessible only in FREQUENCYMETER / TACHOMETER Function)

**000000**

Output is latched. Output-1 does not change position until Manual reset is applied.


**Output-1 is latched**



000000 1

Non-latched with hysteresis output is selected.

#### Output-1 is non-latched



000000 2

Output-1 is an alarm output. For details, refer to Alarm Functions for Output-1 parameter **Pro-11**



Only Ch-A input is performed in Frequency/Tachometer functions

Pro-10


#### Output-2 Function

(It is accessible only in FREQUENCYMETER / TACHOMETER Function)

000000 0

Output is latched. Output-2 does not change position until Manual reset is applied.

#### Output-2 is latched




Only Ch-A input performs in Frequency/Tachometer function.

000000 1

Non-latched with hysteresis output is selected.

**Output-2 is non-latched**



Only Ch-A input is performed in Frequency/Tachometer functions

Pro-11


**Alarm Functions for Output-1**

(It is accessible only in FREQUENCYMETER / TACHOMETER Function)

If Output-1 function parameter **Pro-09** is selected **000002** Alarm output, then Output-1 becomes active according to this parameter.


000000

**High Alarm.**



000000 1


**Low Alarm.**



Only Ch-A input performs in Frequency / Tachometer function.


000002

### Deviation High Alarm.




000003

### Deviation Low Alarm.



000004

### Deviation Band Alarm.



Only Ch-A input performs in Frequencymer / Tachometer function.

Pro-12

### Hysteresis for Output-1 (It is accessible in FREQUENCYMETER / TACHOMETER functions)

It defines hysteresis for Output-1. It is used if Output-1 is non-latched.  
It can be adjusted from 000000 to 050000



Only Ch-A input performs in Frequencymer / Tachometer function.

Pro-13

### Hysteresis for Output-2 (It is visible only in FREQUENCYMETER / TACHOMETER Function)

It defines hysteresis for Output-2. It is used if Output-2 is non-latched.  
It can be adjusted from 000000 to 050000



Only Ch-A input performs in Frequency Meter / Tachometer function.

Pro-14

### Output-1 Operation Form

000000

Output-1 Normally non-energised

000001

Output-1 Normally energised

Pro-15

### Output-2 Operation Form

000000

Output-2 Normally non-energised

000001

Output-2 Normally energised

Pro-16

### Output-1 Pulse Time

It determines how long Output-1 will be active.  
It can be adjusted from 0000.00 to 0099.99 seconds.  
If it is 0000.00 second, then it operates indefinitely.  
For details, refer to the section where output functions Pro-06 are defined

Pro-17

### Output-2 Pulse Time

It determines how long Output-2 will be active.  
It can be adjusted from 0000.00 to 0099.99 seconds.  
If it is 0000.00 second, then it operates indefinitely.  
For details, refer to the section where output functions Pro-06 are defined

Pro-18

### Start of the Controlling (It is accessible only in FREQUENCYMETER/TACHOMETER functions)

Outputs are controlled according to this parameter

000000

Control is started when the unit is energised.

000001

Control is started when count value reaches to SET1 value

000002

Control is started when count value reaches to SET2 value.

Pro-19

#### Direction of Counting

(It is accessible in functions except for FREQUENCYMETER/  
TACHOMETER functions)

000000

Upcount. (0 ⇒ Preset)

000001

Downcount. (Preset ⇒ 0)



If Input Types and Functions parameter **Pro-01** is **000000** or **000001** in COUNTER / "TOTALIZER COUNTER" functions, then direction of counting parameter **Pro-19** can not be accessed.

Pro-20

#### Point Position for Display

(It is accessible in functions except for TIMER and  
CHRONOMETER functions)

000000

No point

000000

000001

Between first and second digits

000000

000002

Between second and third digits

000000

000003

Between third and fourth digits

000000

000004

Between fourth and fifth digits

000000

Pro-21

#### Saving Count Value (Power down back-up)

(It is accessible in functions except for FREQUENCYMETER/  
TACHOMETER functions)

000000

Count value is saved to memory when power is disconnected and restored on power up.

000001

Count value is not saved to memory when power is disconnected. When power up **000000** is shown on the screen.



Pro-22

### SET1 Operation Form Selection (It is accessible only in COUNTER / "TOTALIZER COUNTER" Function)

000000

Absolute operation. SET1 can be adjusted from 000000 to 999999

000001

Operation with offset. SET1 can be defined ± Offset according to SET2 value. (SET1 = SET1 + SET2)

For example ;if operation with offset is selected, SET1 = 5000, SET2 = 10000.

Output-1 becomes active or inactive according to SET1 = 5000 + 10000 = 15000 value

For example; If operation with offset is selected ;  
If 6th digit of the SET1 is adjusted to "-", SET1 becomes negative (For details, refer to Section 7.3)

SET1 = -05000 ; SET2 = 10000

Output-1 becomes active or inactive according to SET1 = -5000 + 10000 = 5000 value

Pro-23

### Slave Address

Device address for serial communication bus.

It can be adjusted from 000001 to 000247

Pro-24

### Modbus Protocol Type Selection

000000

Modbus **ASCII** protocol is selected

000001

Modbus **RTU** protocol is selected

Pro-25

### Communication Parity Selection

000000

No parity

000001

Odd Parity

000002

Even Parity

### Pro-26 Baud Rate

000000	1200 Baud Rate
000001	2400 Baud Rate
000002	4800 Baud Rate
000003	9600 Baud Rate
000004	19200 Baud Rate

### Pro-27 Communication Stop Bit selection

000000	1 Stop Bit
000001	2 Stop Bits

### Pro-28 Reset and Set protection (For accessing from front panel)

000000	There is no Reset and Set protection
000001	Only RESET button protection is active. Actual value can not be reset by Reset button. Actual value can be reset only reset input is active
000002	SET1 and SET2 can not be changed.
000003	Full protection ; Reset protection is active, also SET1 and SET2 can not be changed.
000004	SET1 can not be changed.
000005	SET2 can not be changed.

### Pro-29 Frequency / Cycle Coefficient (It is accessible only in FREQUENCYMETER / TACHOMETER functions)

It can be adjusted from 000001 to 099999. Count value is multiplied with this parameter.

If it is 000000 multiplication is not performed. So number of pulses are displayed without having any changes.

Pro-30

### Multiplication Coefficient (It is accessible except for TIMER and CHRONOMETER functions)

It can be adjusted from  to  . Changes in this parameter is evaluated when counting starts.

If it is  multiplication is not performed. So number of pulses are displayed without having any changes.

Pro-PS

### Program Password

It is used for accessing to the program parameters. It can be adjusted from  to .

If it is  , there is no password protection while accessing to the parameters.

When programming button is pressed,  will appear on the display.

If program password is not "0" while accessing to the program parameters ;

1- If user does not enter the  value correctly ; operation screen will appear without entering to operator parameters.

2- When  in top display and  in bottom display, if user presses ENTER button without entering password (for observing the parameters):

User can see all parameters except Program Password but device does not allow to do any changes with parameters.

( Please refer to Section 9. Failure Messages in EZM-4950 Programmable Timer & Counter (2) )

## 9. Failure Messages in EZM-4950 Programmable Timer & Counter



1 - Position of the DIP Switch is wrong. (DIP Switch determines the operation function of the device and it is under the top cover)  
For details, refer to Section 2.8 "Selection of Operation Function and Input Type with DIP Switch".

2 - If the password is not 0, user can access to the parameters without entering the password and by pressing ENTER button.

User can see all parameters except for programming password parameter **Pr-o-Ps** but user can not do any changes in parameters. If password is entered for accessing to the parameters correctly, most significant digit of the parameter flashes. But if the password is not entered, flashing of the most significant digit is not realised.

Operation Screen



When PROG button is pressed for 3 seconds, password entering screen will appear.

Password Screen



The most significant digit of the parameter (4th digit for this parameter) flashes.

Press ENTER button without entering the password.

For COUNTER /  
"TOTALIZER COUNTER"  
Function



Input Types  
and Functions

No digit flashes.

By pressing ENTER button, user can see all parameters except for program password

For COUNTER /  
"TOTALIZER COUNTER"  
function

Pro-30  
0.10000

Multiplication Coefficient

Press PROG button to exit  
from programming mode.



Continue to press ENTER  
button for scanning the  
parameters.

000000  
02 003000



Operation Screen

Pro-01  
000007



Input Types and  
Functions

999999  
01 02 003000



3 - If Actual Value is flashing and counting is stopped ;  
It appears if any of the count value is greater than the  
maximum count value.

(Total count value for Counter/"Totalizer Counter"  
Function - Batch count value for Batch Counter  
FUNCTION)

To remove this warning and reset the count value press  
RESET button.

-999999  
01 02 003000



4 - If actual value is flashing and counting is not  
performed;

It appears if any of the count value is less than the  
minimum count value.

(Total count value for Counter/"Totalizer Counter"  
Function - Batch count value for Batch Counter  
FUNCTION)

To remove this warning and reset the count value press  
RESET button.

## 10. Specifications

<b>Device Type</b>	: Programmable Timer & Counter
<b>Housing &amp; Mounting</b>	: 96mm x 48mm x 86.5mm 1/8 DIN 43700 plastic housing for panel mounting. Panel cut-out is 92x46mm
<b>Protection Class</b>	: NEMA 4X (IP65 at front, IP20 at rear).
<b>Weight</b>	: Approximately 0.21 Kg.
<b>Environmental Ratings</b>	: Standard, indoor at an altitude of less than 2000 meters with none condensing humidity
<b>Storage / Operating Temperature:</b>	-40 °C to +85 °C / 0 °C to +50 °C
<b>Storage / Operating Humidity</b>	: 90 % max. (None condensing)
<b>Installation</b>	: Fixed installation
<b>Over Voltage Category</b>	: II
<b>Pollution Degree</b>	: II, office or workplace, none conductive pollution
<b>Operating Conditions</b>	: Continuous
<b>Supply Voltage and Power</b>	: 100 - 240 V $\sim$ 50/60 Hz. (-15% / +10%) 6VA 24 V $\sim$ 50/60 Hz. (-15% / +10%) 6VA 24 V $\text{---}$ (-15% / +10%) 6W
<b>Electrical Characteristics Of Digital Inputs</b>	: Rated voltage : 16 VDC @ 5mA Maximum continuous permissible voltage : 30 VDC Logic 1 minimum level : 3 VDC Logic 0 maximum level : 2 VDC
<b>Maximum Input Frequency</b>	: For Counter / "Totalizer Counter" and Batch Counter ; If $\overline{P_{r0-0}} = 0, 1, 2$ ; 6000Hz If $\overline{P_{r0-0}} = 3, 4$ ; 4000Hz If $\overline{P_{r0-0}} = 5, 6$ ; 3500Hz If $\overline{P_{r0-0}} = 7$ ; 2000Hz For Frequencycounter / Tachometer ; 10kHz Max 30 Hz ( $\overline{P_{r0-0}} \neq \overline{000000}$ , debounce)
<b>Optional Output Modules</b>	:-EMO-400 Relay Output Module (3A@250V $\sim$ ) 100.000 operation (Full Load) -EMO-410 SSR Driver Output Module (Max20mA@18V $\text{---}$ ) -EMO-420 Digital (Transistor) Output Module (Max 40mA@18V $\text{---}$ )
<b>Standard Communication Module</b>	: EMC-400 RS-232 Communication Module
<b>Optional Communication Module</b>	: EMC-410 RS-485 Communication Module
<b>Communication Protocol</b>	: MODBUS-RTU, MODBUS-ASCII
<b>Process Display</b>	: 13 mm Red 6 digit LED display
<b>Set Display</b>	: 8 mm Green 6 digit LED display
<b>Led Indicators</b>	: SV1 (Set1 value), SV2 (Set2 value) , O1 / 2 (Control or Alarm Output ) LEDs
<b>Approvals</b>	: UL Recognized Component(File Number: E 254103), GOST-R, C $\text{\textcircled{C}}$