



Help Guide: Digital 4K Video Camera Recorder/Digital HD Video Camera Recorder
FDR-AX100/FDR-AX100E/HDR-CX900/HDR-CX900E

How to Use

Before use

Model Information

- [Model Information \[1\]](#)

Parts and controls

- [Parts and controls \(front/top\) \[2\]](#)
- [Parts and controls \(side\) \[3\]](#)
- [Parts and controls \(back/bottom\) \[4\]](#)
- [Parts and controls \(Wireless Remote Commander\) \[5\]](#)

Screen indicators

- [Screen indicators \[6\]](#)

Movie recording format

- [Recording formats available with this product and their features \[7\]](#)

Getting started

Checking the supplied items

- [Supplied items \[8\]](#)

- [Attaching the lens hood \[9\]](#)

Power source preparations

- [Attaching the battery pack \[10\]](#)
- [Charging the battery pack using the AC Adaptor \[11\]](#)
- [Charging the battery pack using your computer \[12\]](#)
- [Turning the power on \[13\]](#)
- [Using this product supplying power from a wall outlet \(wall socket\) \[14\]](#)

Initial setup

- [Setting the language, date and time \[15\]](#)
- [Adjusting the angle of the LCD monitor for easier viewing \[16\]](#)
- [Adjusting the angle of the viewfinder for easier viewing \[17\]](#)
- [Displaying items on the LCD monitor \[18\]](#)

Preparing a memory card

- [Inserting a memory card \[19\]](#)
- [Types of memory card you can use with this product \[20\]](#)

Recording

Recording movies/photos

- [Recording movies \[21\]](#)
- [Shooting photos \[22\]](#)

Changing the brightness manually for recording

- [Controlling the image settings manually with the MANUAL dial \[23\]](#)
- [Assigning frequently-used menu items to the MANUAL button \[24\]](#)
- [Adjusting the IRIS \(aperture\) \[25\]](#)
- [Adjusting the shutter speed \[26\]](#)
- [Adjusting the gain \(ISO\) \[27\]](#)

[Adjusting the exposure \[28\]](#)

- [Adjusting the light intensity \(ND filter\) \[29\]](#)

Useful functions for recording

- [Zooming \[30\]](#)
- [Adjusting the focus manually \[31\]](#)
- [Magnifying the image to obtain better manual focus \(Focus Magnifier\) \[32\]](#)
- [Capturing photos during movie recording \(Dual Capture\) \[33\]](#)
- [Recording in mirror mode \[34\]](#)
- [Intelligent Auto \[35\]](#)
- [Decreasing the voice volume of the person recording the movie \(My Voice Canceling\) \[36\]](#)
- [Recording the selected subject clearly \(Face Priority\) \[37\]](#)
- [Recording subjects other than people \(Tracking focus\) \[38\]](#)

Playback

Playing images using Event View

- [Playing movies and photos from the Event View screen \[39\]](#)
- [Screen display on the Event View screen \[40\]](#)

Playing images using Highlight Playback

- [Playing back a short movie \(Highlight Playback\) \[41\]](#)
- [Changing the settings for Highlight Playback \[42\]](#)
- [Saving Highlight Playback \(Scenario Save\) \[43\]](#)
- [Playing back a saved scenario \[44\]](#)

Playing MP4 movies (HD movie) (switching the movie format)

- [Playing MP4 movies \(HD movie\) \(switching the movie format\) \[45\]](#)

Editing images from the playback screen

- [Notes on editing \[46\]](#)

[Deleting the selected images \[47\]](#)

- [Deleting by date \[48\]](#)
- [Dividing a movie \[49\]](#)
- [Capturing a photo from a movie \(models with the USB IN/OUT jacks\) \[50\]](#)

Playing images on a 4K TV

- [Viewing images on a 4K TV \(models with the 4K functionality\) \[51\]](#)
- [Using the Trimming Playback function with an XAVC S 4K movie \(models with the 4K functionality\) \[52\]](#)

Playing images on a high definition TV

- [Connecting this product to a high definition TV \[53\]](#)
- [Enjoying 5.1ch surround sound \[54\]](#)
- [Using BRAVIA Sync \[55\]](#)
- [On Photo TV HD \[56\]](#)
- [On the HDMI cable \[57\]](#)

Playing images on a non-high-definition TV

- [Connecting this product to a non-high-definition TV \[58\]](#)

Saving images with an external device

How to save movies

- [Saving movies \[59\]](#)

Using the PlayMemories Home software

- [Using the PlayMemories Home software \[60\]](#)
- [Checking the computer system \[61\]](#)
- [Installing the PlayMemories Home software in your computer \[62\]](#)
- [Disconnecting this product from the computer \[63\]](#)
- [About the dedicated software for this product \[64\]](#)
- [Creating a Blu-ray disc \[65\]](#)

Saving images on an external media device

- [Notes on use of the external media \[66\]](#)
- [Saving images on an external media device \[67\]](#)
- [Saving the desired images in this product to the external media device \[68\]](#)
- [Playing back images in the external media device on this product \[69\]](#)
- [Deleting images in the external media device \[70\]](#)

Creating a disc with a recorder

- [Creating a disc with a recorder \[71\]](#)

Using the Wi-Fi function

What you can do with the Wi-Fi function

- [What you can do with the Wi-Fi function \[72\]](#)

Controlling via a smartphone

- [Using your smartphone or tablet as a wireless remote commander \[73\]](#)
- [Using your smartphone or tablet as a wireless remote commander using the NFC function \(NFC one-touch remote\) \[74\]](#)

Transferring images to a smartphone

- [Transferring movies \(MP4\) and photos to your smartphone or tablet \[75\]](#)
- [Transferring movies \(MP4\) and photos to your smartphone or tablet using the NFC function \(NFC one-touch sharing\) \[76\]](#)

Transferring images to a computer

- [Send to Computer \[77\]](#)

Transferring images to a TV

- [Playing images on a TV \(View on TV\) \[78\]](#)

Connecting a smartphone

- [Connecting to an Android smartphone or tablet \[79\]](#)
- [Connecting to an iPhone or iPad \[80\]](#)
- [Connecting to an NFC-enabled smartphone or tablet \[81\]](#)

Installing PlayMemories Mobile

- [About the PlayMemories Mobile software \[82\]](#)

Menu operations

Using menu items

- [Setting up menu items \[83\]](#)
- [How to use the keyboard \[84\]](#)

Shooting Mode

- [Movie \[85\]](#)
- [Photo \[86\]](#)
- [Smth Slw REC \[87\]](#)
- [Golf Shot \[88\]](#)
- [High SpeedREC \[89\]](#)

Camera/Mic

- [White Balance \[90\]](#)
- [Spot Meter/Fcs \[91\]](#)
- [Spot Meter \[92\]](#)
- [Spot Focus \[93\]](#)
- [Exposure \[94\]](#)
- [Focus \[95\]](#)
- [AGC Limit \[96\]](#)
- [AE Shift \[97\]](#)
- [Low Lux \[98\]](#)

- [Scene Selection \[99\]](#)
- [Picture Effect \[100\]](#)
- [Cinematone \[101\]](#)
- [Fader \[102\]](#)
- [Self-Timer \[103\]](#)
- [SteadyShot \(Movie\) \[104\]](#)
- [SteadyShot \(Photo\) \[105\]](#)
- [Digital Zoom \[106\]](#)
- [Auto Back Light \[107\]](#)
- [Dial Setting \[108\]](#)
- [NIGHTSHOT Light \[109\]](#)
- [Face Detection \[110\]](#)
- [Smile Shutter \[111\]](#)
- [Smile Sensitivity \[112\]](#)
- [Flash \(Only when connecting an external flash\) \[113\]](#)
- [Flash Level \(Only when connecting an external flash\) \[114\]](#)
- [Red Eye Reduction \(Only when connecting an external flash\) \[115\]](#)
- [My Voice Canceling \[116\]](#)
- [Blt-in Zoom Mic \[117\]](#)
- [Auto Wind NR \[118\]](#)
- [Audio Mode \[119\]](#)
- [Audio Rec Level \[120\]](#)
- [Ctrl with Smartphone \[121\]](#)
- [My Button \[122\]](#)
- [Grid Line \[123\]](#)
- [Zebra \[124\]](#)
- [Peaking \[125\]](#)
- [Camera Data Disp. \[126\]](#)
- [Audio Level Display \[127\]](#)

Image Quality/Size

- [REC Mode \[128\]](#)

- [Frame Rate \[129\]](#)
- [Dual Video REC \[130\]](#)
- [File Format \[131\]](#)
- [Image Size \[132\]](#)

Playback Function

- [Event View \[133\]](#)
- [Scenario \[134\]](#)

Edit/Copy

- [Send to Smartphone \[135\]](#)
- [View on TV \[136\]](#)
- [Send to Computer \[137\]](#)
- [Delete \[138\]](#)
- [Protect \[139\]](#)
- [Direct Copy \[140\]](#)

Setup

- [Media Info \[141\]](#)
- [Format \[142\]](#)
- [Repair Img. DB F. \[143\]](#)
- [File Number \[144\]](#)
- [Data Code \[145\]](#)
- [Volume \[146\]](#)
- [Download Music \(HDR-CX900/FDR-AX100\) \[147\]](#)
- [Empty Music \(HDR-CX900/FDR-AX100\) \[148\]](#)
- [WPS Push \[149\]](#)
- [Access point settings \[150\]](#)
- [Edit Device Name \[151\]](#)
- [Disp MAC Address \[152\]](#)
- [SSID/PW Reset \[153\]](#)
- [Network Info Reset \[154\]](#)

- [TV Type \[155\]](#)
- [HDMI Resolution \[156\]](#)
- [CTRL FOR HDMI \[157\]](#)
- [USB Connect \[158\]](#)
- [USB Connect Setting \[159\]](#)
- [USB Power Supply \[160\]](#)
- [USB LUN Setting \[161\]](#)
- [Beep \[162\]](#)
- [Monitor Brightness \[163\]](#)
- [Display Setting \[164\]](#)
- [Airplane Mode \[165\]](#)
- [REC Lamp \[166\]](#)
- [Remote Ctrl \[167\]](#)
- [Language Setting \[168\]](#)
- [24p Mode \(HDR-CX900E/FDR-AX100E\) \[169\]](#)
- [Cancel 24p Mode \(HDR-CX900E/FDR-AX100E\) \[170\]](#)
- [Calibration \[171\]](#)
- [Battery Info \[172\]](#)
- [Power Save \[173\]](#)
- [Initialize \[174\]](#)
- [Date & Time Setting \[175\]](#)
- [Area Setting \[176\]](#)

Charging time/recording time of movies/number of recordable photos

Check the charging time

- [Charging time \[177\]](#)

Expected recording and playback times for individual batteries

- [Expected recording time with each battery pack \[178\]](#)
- [Expected playback time with each battery pack \[179\]](#)

Expected movie recording time and number of recordable photos for memory cards

- [Notes on recording \[180\]](#)
- [Expected recording time of movies \[181\]](#)
- [Expected number of recordable photos \[182\]](#)

Bit-rate for each recording mode

- [Bit-rate and recording pixels \[183\]](#)

Pixels recorded at each image size of photos

- [Recording pixels and aspect ratio \[184\]](#)

Additional information

Precautions

- [About the AVCHD format \[185\]](#)
- [About the memory card \[186\]](#)
- [About the InfoLITHIUM battery pack \[187\]](#)

Handling of this product

- [On use and care \[188\]](#)
- [On connecting to a computer or accessory etc. \[189\]](#)
- [Notes on optional accessories \[190\]](#)
- [On moisture condensation \[191\]](#)
- [Note on disposal/transfer of the memory card \[192\]](#)
- [Notes on the Wireless Remote Commander \[193\]](#)

Maintenance

- [On handling the LCD monitor \[194\]](#)
- [To clean the casing surface \[195\]](#)

- [About care and storage of the lens \[196\]](#)

Using this product abroad

- [Using this product abroad \[197\]](#)
- [World time difference \[198\]](#)

Trademarks

- [On trademarks \[199\]](#)

License

- [Notes on the License \[200\]](#)

Zoom magnifications

- [Zoom magnifications \[201\]](#)

Troubleshooting

Troubleshooting

If you have problems

- [If you have problems \[202\]](#)

Overall operations

- [The power does not turn on. \[203\]](#)
- [This product does not operate even when the power is set to on. \[204\]](#)
- [The menu settings have been changed automatically. \[205\]](#)
- [This product gets warm. \[206\]](#)
- [Intelligent Auto is canceled. \[207\]](#)

Batteries/power sources

- The power abruptly turns off. [208]
- The POWER/CHG (charge) lamp does not light while the battery pack is being charged. [209]
- The POWER/CHG (charge) lamp flashes while the battery pack is being charged. [210]
- The remaining battery power is not displayed correctly. [211]
- The battery pack is quickly discharged. [212]

Monitor

- Menu items are grayed out. [213]
- The buttons do not appear on the LCD monitor. [214]
- The buttons on the touch panel do not work correctly or do not work at all. [215]
- The buttons on the LCD monitor quickly disappear. [216]
- There are dots in the shape of a grid on the monitor. [217]
- The backlight of the LCD monitor turns off if you do not attempt to operate this product for a while. [218]

Viewfinder

- The image in the viewfinder is not clear. [219]
- The image in the viewfinder is no-longer displayed. [220]

Memory card

- Operations using the memory card cannot be performed. [221]
- Images stored on the memory card cannot be deleted. [222]
- The data file name is not indicated correctly or flashes. [223]
- Images cannot be played back or the memory card is not recognized. [224]

Wireless Remote Commander

- The supplied Wireless Remote Commander does not function. [225]
- Another DVD device operates when you use the supplied Wireless Remote Commander. [226]

Recording

- [Pressing START/STOP or PHOTO does not record images. \[227\]](#)
- [Photos cannot be recorded. \[228\]](#)
- [The access lamp remains lit or flashing even if recording has stopped. \[229\]](#)
- [The imaging field looks different. \[230\]](#)
- [The actual recording time for movies is less than the expected recording time of the recording media. \[231\]](#)
- [This product stops recording. \[232\]](#)
- [There is a slight time lag between the moment when START/STOP is pressed and the actual movie recording starts or stops. \[233\]](#)
- [The auto focus does not function. \[234\]](#)
- [SteadyShot does not function. \[235\]](#)
- [Images cannot be recorded or played back correctly. \[236\]](#)
- [The subjects passing across this product very fast appear crooked. \[237\]](#)
- [Horizontal stripes appear on the images. \[238\]](#)
- [\[Monitor Brightness\] cannot be set. \[239\]](#)
- [Sound is not recorded correctly. \[240\]](#)
- [Photos are recorded automatically. \[241\]](#)

Playback

- [Images cannot be played back. \[242\]](#)
- [Photos cannot be played back. \[243\]](#)
- [The movie freezes. \[244\]](#)
- [An icon appears on a thumbnail. \[245\]](#)
- [No sound or only a quiet sound is heard during playback. \[246\]](#)
- [Left and right sound is heard unbalanced when playing back movies on computers or other devices. \[247\]](#)

Wi-Fi

- [The wireless access point you want to connect to does not appear. \[248\]](#)
- [\[WPS Push\] does not work. \[249\]](#)
- [\[Ctrl with Smartphone\], \[Send to Smartphone\], \[Send to Computer\] or \[View on TV\] terminates prematurely. \[250\]](#)

- [Cannot transfer movies to your smartphone. \[251\]](#)
- [The shooting screen does not display smoothly. The connection is cut off. \[252\]](#)
- [The NFC connection does not work. \[253\]](#)

Editing movies/photos on this product

- [Unable to edit. \[254\]](#)
- [A movie cannot be divided. \[255\]](#)

Playback on a TV

- [Neither image nor sound is played on the connected TV. \[256\]](#)
- [The top, bottom, right, and left edges of images are trimmed slightly on a connected TV. \[257\]](#)
- [The image appears distorted on the 4:3 TV. \[258\]](#)
- [Black bands appear at the top and bottom of the LCD monitor of the 4:3 TV. \[259\]](#)

Copying/Connecting to other devices

- [Images are not copied correctly. \[260\]](#)

Connecting to a computer

- [PlayMemories Home cannot be installed. \[261\]](#)
- [PlayMemories Home does not work correctly. \[262\]](#)
- [This product is not recognized by the computer. \[263\]](#)

Self-diagnosis display/Warning indicators

Self-diagnosis display/Warning indicators

- [Self-diagnosis display \[264\]](#)

Warning messages

Warning messages

- [Warning Indicators \[265\]](#)

[1] How to Use | Before use | Model Information


Model Information

In this Help Guide, the differences in the specifications for each model are described together. If you find the description “Models with ...” like below, confirm in this chapter whether the description applies to this product.

- (models with the 4K functionality)
- (models with the NTSC color system)

To confirm the model name of this product

See the bottom of this product.



A: Model name (FDR-xxxx/HDR-xxxx)

Differences in functions

Models with the NTSC color system: FDR-AX100/HDR-CX900

Models with the PAL color system: FDR-AX100E/HDR-CX900E

Models with the 4K functionality: FDR-AX100/FDR-AX100E



Models with the USB IN/OUT jacks: FDR-AX100/HDR-CX900

Models with the USB Output only jack: FDR-AX100E/HDR-CX900E

Note

- For the following items, the descriptions are explained with the model name.
 - Parts and controls
 - Menu items
 - Expected recording time of movies
 - Expected number of recordable photos
-

Parts and controls (front/top)



1. Multi interface shoe



For details on compatible accessories of the Multi interface shoe, visit the Sony website in your area, or consult your Sony dealer or local authorized Sony service facility.

Operations with other manufacture's accessories are not guaranteed. If you use a shoe adaptor (sold separately), you can also use accessories compatible with an Active Interface Shoe.

2. PHOTO button

3. Power zoom lever

4. N mark

NFC: Near Field Communication

5. Loop for a shoulder belt

6. Grip belt

7. FOCUS MAGNIFIER button

8. (microphone) jack (PLUG IN POWER)



9. Remote sensor

10. Camera recording lamp

11. NIGHT SHOT light
12. Multi/Micro USB Terminal
Supports Micro USB compatible devices.
If you use an adaptor cable (sold separately), you can also use accessories via an A/V Remote Connector.
13. Built-in microphone
14. Lens ring
15. Lens (ZEISS lens)
16. ZOOM/FOCUS switch
17. AF/MF button
18. MANUAL button
19. MANUAL dial

[3] How to Use | Before use | Parts and controls

Parts and controls (side)




1. Speaker
2. Memory card access lamp
While the lamp is lit or flashing, this product is reading or writing data.
3. Memory card slot
4. HDMI OUT jack

5. 🎧 (headphones) jack
6. ND FILTER (AUTO/MANUAL) switch
7. ND FILTER switch
8. POWER button
9. WHITE BALANCE button
10. PROGRAM AE button
11. IRIS button
12. GAIN/ISO button
13. SHUTTER SPEED button
14. ▶️ (View Images) button
15. 🗣️ (My Voice Canceling) button
Suppresses the voice of the person recording the movie.
16. DISPLAY button
17. NIGHT SHOT button

[4] How to Use | Before use | Parts and controls

Parts and controls (back/bottom)



1. LCD monitor/Touch panel

If you rotate the LCD panel 180 degrees, you can close the LCD monitor with the screen facing out. This is convenient during playback operations.

2. Viewfinder

This product is turned on when the viewfinder is pulled out.

3. Eye sensor

When the LCD monitor is closed, pull out the viewfinder and move your eye closer to the viewfinder. You can view the subject through the viewfinder.

4. Viewfinder lens adjustment dial

If the indications in the viewfinder appear blurred, adjust the viewfinder lens adjustment dial.

5. Battery pack

6. POWER/CHG (charge) lamp

7.  /  (Shooting Mode) button

8. START/STOP button

9. Built-in USB Cable


10. DC IN jack

11. Tripod receptacle

Attach a tripod (sold separately: the length of the screw must be less than 5.5 mm (7/32 in.)). Depending on the specifications of the tripod, this product may not attach in the proper direction.


12. BATT (battery) release lever

To fasten the grip belt



[5] How to Use | Before use | Parts and controls

Parts and controls (Wireless Remote Commander)




1. DATA CODE button
Displays the date and time and the camera settings data when you press this button during playback.
2. PHOTO button
The on-screen image when you press this button will be recorded as a still image.
3. SCAN/SLOW buttons
4. ◀◀/▶▶ (Previous/Next) buttons
5. PLAY button
6. STOP button
7. DISPLAY button
8. Transmitter
9. START/STOP button
10. Power zoom buttons
11. PAUSE button
12. VISUAL INDEX button
Displays a VISUAL INDEX screen during playback.
13. ◀/▶/▲/▼/ENTER buttons
When you press any of these buttons, the light blue frame appears on the LCD monitor.
Select a desired button or an item with ◀/▶/▲/▼, then press ENTER to enter.

[6] How to Use | Before use | Screen indicators

Screen indicators

The following indicators appear when you change the settings.



On the left side of the screen ([1])

 MENU button

 Self-timer recording

 [Airplane Mode] set to [On]

  Fader

[Face Detection] set to [Off]
 ON [Smile Shutter]
 Manual focus
 Scene Selection
 SteadyShot off
 70 Zebra
PEAK W **PEAK Y** **PEAK R** Peaking
 Intelligent Auto

At the center of the screen (2)

Slideshow Set
 Warning
 Playback mode
 REC/STBY Recording mode
 AE/AF lock
 Nightshot
 NFC
Wi-Fi Wi-Fi
 Picture Effect

On the right side of the screen (3)

HD 60i **HQ** **4K** **HD** Frame rate (30p/60p/50p/60i/50i/24p/25p), recording mode (PS/FX/FH/HQ/LP) and movie size
 Dual Video REC
 60 min Remaining battery
 Recording/playback/editing media
 0:00:00 Counter (hour:minute:second)
 00min Estimated recording time
 9999 **16:9** 20.0M/14.2M Approximate number of recordable photos and photo size
101 ▶ Playback folder of the memory card
 100/112 Current playing movie or photo/Number of total recorded movies or photos
 Connection to the external media device

At the bottom of the screen (4)

Audio Rec Level
 [Auto Wind NR] set to [Off]
 [My Voice Canceling] set to [On]
 Blt-in Zoom Mic
5.1ch **2ch** Audio Mode
CINEMA Cinematone
 Low Lux

AGC AGC Limit

 Audio Level Display

EV AE Shift

  Exposure Auto/Manual

F2.8 IRIS

30dB Gain

60 Shutter Speed

  Intelligent Auto

 Data file name

 Protect

   5500K White Balance

ND1 ND2 ND3 NDOff ND filter

Note

- Indicators and their positions are approximate and may differ from what you actually see.
- Some indicators may not appear, depending on the model.

[7] How to Use | Before use | Movie recording format

Recording formats available with this product and their features

This product supports XAVC S 4K (models with the 4K functionality), XAVC S HD and AVCHD. The image quality of XAVC S 4K is 4-times greater than the conventional high definition image quality.

XAVC S 4K

Recording pixels:

3,840 × 2,160 dots

Bit-rate:

60 Mbps

Feature:

Records in 4K. Even if you do not have a 4K TV, recording in 4K format is recommended for future purpose.

XAVC S HD

Recording pixels:

1,920 × 1,080 dots

Bit-rate:

50 Mbps

Feature:

Allows you to record clearer images since XAVC S HD has more information compared with AVCHD.

AVCHD

Recording pixels:

1,920 × 1,080 dots

Bit-rate:

Max. 28 Mbps

Feature:

Allows you to save images on devices other than computers.

Hint

- Bit-rate refers to the data amount recordable over a certain period of time.

[8] How to Use | Getting started | Checking the supplied items

Supplied items

The numbers in () indicate the supplied quantity.


For all models

Camcorder (1)

AC Adaptor (1)



HDMI cable (1)



USB connection support cable (1)




Power cord (mains lead) (1)



Lens hood (1)



Lens cap (attached to this product) (1)



Wireless Remote Commander (1)



Operating Guide (1)


Only for FDR-AX100/FDR-AX100E

Rechargeable battery pack NP-FV70 (1)




Only for HDR-CX900/HDR-CX900E

Rechargeable battery pack NP-FV50 (1)



Hint

- The USB connection support cable is designed for use with this product only. Use this cable when the Built-in USB Cable of this product is too short for connection.




[9] How to Use | Getting started | Checking the supplied items

Attaching the lens hood

Attach the lens hood to prevent stray light from affecting your images.

1. Align the red line on the lens hood with the red point on the lens (Lens hood index), then insert the lens hood into the lens mount and rotate it clockwise until the lens hood clicks into place.




[10] How to Use | Getting started | Power source preparations

Attaching the battery pack


Attach the battery pack to this product.

1. Close the LCD monitor and retract the viewfinder, and then attach the battery pack (①).
 - Align the indentation on this product and projection on the battery pack, then slide the battery pack upwards.



To remove the battery pack

Turn off this product. Slide the battery release lever (①) and remove the battery pack (②).



Note


- You cannot use any InfoLITHIUM battery pack other than the V series to this product.
- You cannot use the NP-FV30 InfoLITHIUM battery pack with this product.
- In the default setting, the power turns off automatically if you leave this product without any operation for about 2 minutes, to save battery power (Power Save).

[11] How to Use | Getting started | Power source preparations


Charging the battery pack using the AC Adaptor

Charge the battery pack using the supplied AC Adaptor. Attach the battery pack in advance.

1. Close the LCD monitor.
 - When the viewfinder is pulled out, retract it.



2. Connect the AC Adaptor and the power cord (mains lead) to this product and a wall outlet (wall socket).
 - The POWER/CHG (charge) lamp lights orange.
 - The POWER/CHG (charge) lamp turns off when the battery pack is fully charged.
Disconnect the AC Adaptor from the DC IN jack of this product.



- A: AC Adaptor
- B: Power cord (mains lead)
- C: DC IN jack
- D: Align the ▲ mark on the DC plug

Note

- Be aware of the following notes on using the AC Adaptor.
 - Use a nearby wall outlet (wall socket) when using the AC Adaptor. Disconnect the AC Adaptor from the wall outlet (wall socket) immediately if any malfunction occurs while using this product.
 - Do not use the AC Adaptor placed in a narrow space, such as between a wall and furniture.
 - Do not short-circuit the DC plug of the AC Adaptor or battery terminal with any metallic objects. This may cause a malfunction.

Hint


- It is recommended that you charge the battery in a temperature range of 10 °C to 30 °C (50 °F to 86 °F).

[12] How to Use | Getting started | Power source preparations


Charging the battery pack using your computer

Charge the battery pack by connecting this product and your computer with the Built-in USB Cable. Attach the battery pack in advance.

1. Close the LCD monitor.
 - When the viewfinder is pulled out, retract it.




2. Pull out the Built-in USB Cable from this product.



3. Connect this product to a running computer using the Built-in USB Cable.

- The POWER/CHG (charge) lamp turns orange.
- The POWER/CHG (charge) lamp turns off when the battery pack is fully charged.
Disconnect the Built-in USB Cable from the computer, and then store it in the pocket on the grip belt.
- If the Built-in USB Cable is not long enough for the connection, use the USB connection support cable.




①: Built-in USB Cable

②: To a wall outlet (wall socket)

To put the Built-in USB Cable away

Put the Built-in USB Cable back in the pocket on the grip belt after use.



Hint

- It is recommended that you charge the battery in a temperature range of 10 °C to 30 °C (50


°F to 86 °F).

[13] How to Use | Getting started | Power source preparations

Turning the power on

Turn on this product.

1. Open the LCD monitor of this product and turn the power on.
 - You can also turn on this product by pressing POWER or by pulling out the viewfinder.




To turn off the power

Close the LCD monitor.

If the viewfinder is pulled out, retract the viewfinder as shown in the illustration below.

- You can also turn off this product by pressing POWER.



On turning this product on or off using the LCD monitor or the viewfinder

The power of this product is turned on or off depending on the status of the LCD monitor or the viewfinder.

LCD monitor: Open, Viewfinder: Retracted

Power On

LCD monitor: Open, Viewfinder: Pulled out

Power On

LCD monitor: Closed, Viewfinder: Retracted

Power Off

LCD monitor: Closed, Viewfinder: Pulled out

Power On

Note

- Even if the LCD monitor is closed, if the viewfinder is pulled out, this product is not turned off. When you turn off the power of this product, make sure that the viewfinder is retracted to the original position.

[14] How to Use | Getting started | Power source preparations

Using this product supplying power from a wall outlet (wall socket)

Supply power to this product using the AC Adaptor.


1. Make the same connections as shown in “Charging the battery pack using the AC Adaptor” to use this product.
 - Even if the battery pack is attached, it will not be discharged.

[15] How to Use | Getting started | Initial setup

Setting the language, date and time

Set the language, date and time when using this product for the first time.

1. Open the LCD monitor of this product and turn the power on.
2. Select the desired language, then select [Next].




A: Touch the LCD monitor

3. Select the desired geographical area with /, then select [Next].



4. Set [Daylight Savings] or [Summer Time], select the date format and the date and time.

- If you set [Daylight Savings] or [Summer Time] to [On], the clock advances 1 hour.
- When you select the date and time, select one of the items and adjust the value with /.
- When you select - , the date and time setting operation is complete.



Hint


- The date and time are recorded automatically and can be displayed only during playback. To display them, select - [Setup] - [Playback Settings] - [Data Code] - [Date/Time].

[16] How to Use | Getting started | Initial setup

Adjusting the angle of the LCD monitor for easier viewing

You can adjust the angle of the LCD monitor for easier viewing.


1. First open the LCD monitor 90 degrees to this product (①), and then adjust the angle (②).



Adjusting the angle of the viewfinder for easier viewing

You can adjust the angle of the viewfinder for easier viewing.

1. Close the LCD monitor.
2. Pull out the viewfinder (①) and adjust the angle for easier viewing (②).



3. Move your eye close to the viewfinder.
 - As your eye moves closer to the viewfinder, the eye sensor detects your eye, and then indicators appear on the viewfinder.
 - If the indicators on the viewfinder appear blurred, adjust the appearance using the viewfinder lens adjustment dial located on the side of the viewfinder.

Displaying items on the LCD monitor

Items on the LCD monitor disappear if you do not operate this product for a few seconds after you turn this product on or switch between the movie recording and photo shooting modes. To display items on the LCD monitor again, touch anywhere on the LCD monitor other than buttons.


Hint

- To keep the LCD monitor active, use [Display Setting] to change the setting.

Inserting a memory card

Insert a memory card into this product.

1. Open the cover and insert the memory card until it clicks.



A: Access lamp

B: Insert the card with the notched edge in the direction as illustrated.

Note

- To ensure stable operation of the memory card, it is recommended to format the memory card with this product before the first use. Formatting the memory card will erase all the data stored on it and the data will be irrecoverable. Save your important data on your PC, etc.
- If [Failed to create a new Image Database File. It may be possible that there is not enough free space.] is displayed, format the memory card.
- Confirm the direction of the memory card. If you forcibly insert the memory card in the wrong direction, the memory card, memory card slot, or image data may be damaged.
- Do not insert any memory card other than those that fit into the memory card slot. Doing so may cause a malfunction.
- When inserting or ejecting the memory card, be careful so that the memory card does not pop out and drop.
- Memory card will not be recognized by this product unless it is inserted straight in the correct direction.
- If [Preparing image database file. Please wait.] is displayed, wait until the message disappears.

Hint

- To eject the memory card, open the cover and lightly push the memory card in once.

The following types of memory cards can be used with this product.

Types of Memory Stick media you can use with this product

In this Help Guide, the following types of Memory Stick media you can use with this product are called Memory Stick PRO Duo media.

- Memory Stick PRO Duo media (*)
- Memory Stick PRO-HG Duo media (*)
- Memory Stick XC-HG Duo media (**)

* Memory Stick PRO Duo media with a capacity up to 32 GB have been confirmed to operate properly with this product.

** Memory Stick PRO Duo media with a capacity up to 64 GB have been confirmed to operate properly with this product.

Types of SD memory card you can use with this product

In this Help Guide, the following types of SD cards you can use with this product are called “SD card.”

- SD memory card
- SDHC memory card
- SDXC memory card

Note


- When recording images in AVCHD format, use the card of Class 4 or faster.
- When recording images in XAVC S format, use an SDXC memory card of Class 10 or faster.
- SD memory cards with a capacity up to 64 GB have been confirmed to operate properly with this product.

[21] How to Use | Recording | Recording movies/photos

Recording movies


Record movies.

1. Remove the lens cap.
2. Open the LCD monitor of this product and turn the power on.
 - You can also turn on this product by pressing POWER or by pulling out the viewfinder.



3. Press START/STOP to start recording.

- To stop recording, press START/STOP again.



Note

- If you close the LCD monitor while recording movies, this product stops recording (only when the viewfinder is retracted).
- The maximum continuous recordable time of a movie is about 13 hours.
- When an AVCHD movie file exceeds 2 GB, the next movie file is created automatically.
- The following states will be indicated if data is still being written onto the recording media after recording has finished. During this time, do not apply shock or vibration to this product, or remove the battery pack or AC Adaptor.

Access lamp is lit or flashing

The media icon in the upper right of the LCD monitor is flashing

- The LCD monitor of this product can display recording images across the entire monitor (full pixel display). However, this may cause slight trimming of the top, bottom, right, and left edges of images when played back on a TV which is not compatible with full pixel display. It is recommended you record images with [Grid Line] set to [On] using the outer frame of [Grid Line] as a guide.
- While recording XAVC S 4K movies, you cannot output movies to an external monitor via an HDMI/video connection. Only the on-screen display is output (models with the 4K functionality).


Hint

- When [Dual Video REC] is set to [On], this product records an XAVC S movie and an MP4 movie simultaneously, or records an AVCHD movie and an MP4 movie simultaneously.
- In the default setting, [Dual Video REC] is set to [Off].


Shooting photos

Shoot photos.

1. Remove the lens cap.
2. Open the LCD monitor of this product to turn the power on. Press the  (Shooting Mode) button to select the photo recording mode.
 - You can also select the photo recording mode by selecting [MODE] on the LCD monitor.
 - You can also turn on this product by pressing POWER or by pulling out the viewfinder.



3. Press PHOTO lightly to adjust the focus, then press it fully.
 - When the focus is adjusted properly, the AE/AF lock indicator appears on the LCD monitor.



Note

- The following states will be indicated if data is still being written onto the recording media after recording has finished. During this time, do not apply shock or vibration to this product, or remove the battery pack or AC Adaptor.


Access lamp is lit or flashing

Capturing a photo from a movie (models with the USB IN/OUT jacks) or creating a photo

Controlling the image settings manually with the MANUAL dial

Use the menu assigned to the MANUAL button.

1. Press the MANUAL button to switch to the manual operation mode.
 - Pressing the MANUAL button switches the operation mode between manual and automatic.



A: MANUAL button

B: MANUAL dial

2. Rotate the MANUAL dial to make adjustments.

Note


- Manual settings will be retained even if you change the assigned item of the MANUAL dial. However, if you set [Exposure] after setting [AE Shift] manually, [Exposure] will override [AE Shift].

[24] How to Use | Recording | Changing the brightness manually for recording

Assigning frequently-used menu items to the MANUAL button

You can register your desired functions to the MANUAL button.

1. Press and hold the MANUAL button down for a few seconds.
 - The [Dial Setting] screen is displayed.
2. Rotate the MANUAL dial and select the item to be assigned.



3. Press the MANUAL button to confirm.

Items you can control with the MANUAL dial

- [Exposure]
- [AE Shift]
- [WB Color Temp.]
- [WB B-A]
- [WB G-M]

Hint

- The camera data that appears on the LCD monitor will differ, depending on the recording settings of this product. The settings will be displayed with the following icons.

AUTO: Automatic


MANUAL: Exposure is set manually.

[25] How to Use | Recording | Changing the brightness manually for recording


Adjusting the IRIS (aperture)

The procedure to adjust the IRIS (aperture) is explained as follows.

1. Press the PROGRAM AE button to set the IRIS (aperture), gain (ISO), shutter speed and exposure to [Auto].



2. Press the IRIS button to set the IRIS (aperture) to manual.
 - Each time you press the button, the setting switches between manual and auto.



A: Aperture value

B: Icon to switch operating mode

Descriptions of icons to switch operating mode

(no icon): manual operation

A: automatic operation

E: manual operation of [Exposure]

3. Rotate the MANUAL dial to adjust the IRIS (aperture).
 - When the setting value is highlighted, the IRIS (aperture) is adjustable using the MANUAL dial.

To restore the setting to automatic adjustment

Press the IRIS button again. **A** appears next to the IRIS (aperture) value.

Hint


- This function is useful when you want to blur or sharpen the background of an image.

[26] How to Use | Recording | Changing the brightness manually for recording

Adjusting the shutter speed

The procedure to set the shutter speed is explained as follows.

1. Press the PROGRAM AE button to set the IRIS (aperture), gain (ISO), shutter speed and exposure to [Auto].



2. Press the SHUTTER SPEED button to set the shutter speed to manual.
 - Each time you press the button, the setting switches between manual and auto.

3. Rotate the MANUAL dial to adjust the shutter speed.

To restore the setting to automatic adjustment

Press the SHUTTER SPEED button again. **A** appears next to the shutter speed value.

Hint

- Moving objects you record will look different depending on the shutter speed. Set the shutter speed faster to record a fast-moving object clearly without blurring, and set the shutter speed slower to emphasize the movement of a moving object.
- You can set the shutter speed as follows.

between 1/8 and 1/10,000 seconds in movie recording mode at 60p(*)/50p(**)/30p(*)

between 1/6 and 1/10,000 seconds in movie recording mode at 24p(*)/25p(**)

between 1/8 and 1/1,000 seconds in photo recording mode

* Models with the NTSC color system

** Models with the PAL color system


- Focusing automatically is difficult at lower shutter speed. It is recommended that manual focusing be performed with this product attached to a tripod.
- When recording using [Smth Slw REC], the range of shutter speed you can adjust manually changes to 1/250 - 1/10,000 seconds. When recording using [High Speed REC], the range changes to 1/125 - 1/10,000 seconds.
- When recording under fluorescent lamps, sodium lamps, mercury lamps, or LED light, horizontal bands may appear on the LCD monitor. You may be able to improve the situation by adjusting the shutter speed.

[27] How to Use | Recording | Changing the brightness manually for recording

Adjusting the gain (ISO)

The procedure to set the gain (ISO) is explained as follows. Adjust the gain (ISO) when you do not want to boost the gain using the AGC (Auto Gain Control).

1. Press the PROGRAM AE button to set the IRIS (aperture), gain (ISO), shutter speed and exposure to [Auto].



2. Press the GAIN/ISO button to set the gain (ISO) to manual.

- Each time you press the button, the setting switches between manual and auto.

3. Rotate the MANUAL dial to adjust the gain (ISO).

To restore the setting to automatic adjustment

Press the GAIN/ISO button again. **A** appears next to the gain (ISO) value.

At default, you can set in the range -3dB to +33dB.

Hint


- When recording using [Smth Slw REC], the range of the gain (ISO) you can adjust manually changes to -3dB - +27dB.
- In photo recording mode, the setting displayed will change to ISO and the range you can adjust will be ISO160 - ISO12800.

[28] How to Use | Recording | Changing the brightness manually for recording


Adjusting the exposure

The following is the procedure to adjust the exposure when [Exposure] is assigned to the MANUAL button (default setting).

1. Press the PROGRAM AE button to set the IRIS (aperture), gain (ISO), shutter speed and exposure to [Auto].



2. Press the MANUAL button to set the exposure to manual.
 - Each time you press the button, the setting switches between manual and auto.



A: Setting value

From left to right: IRIS (aperture), gain (ISO), shutter speed

B: Setting status

Descriptions of icons to switch operating mode

(no icon): manual operation

A: automatic operation

E: manual operation of [Exposure]

3. Rotate the MANUAL dial to adjust [Exposure].
 - The setting value of the IRIS (aperture)/gain (ISO)/shutter speed changes according to the number of dial rotations.

[29] How to Use | Recording | Changing the brightness manually for recording

Adjusting the light intensity (ND filter)

The ND filter allows you to record images clearly under too bright conditions.

1. Set the ND FILTER switch to MANUAL, and then select the appropriate ND FILTER position.

OFF:

Cancels the ND filter function.

1:

Reduces the light intensity to 1/4.

2:

Reduces the light intensity to 1/16.

3:

Reduces the light intensity to 1/64.

When adjusting the IRIS (aperture) automatically

When the ND filter indicator flashes, change the ND FILTER switch position setting accordingly.

The ND filter indicator will be lit solid.

Hint

- If you set the IRIS (aperture) too narrow to record a bright object, diffraction phenomenon may prevent you from focusing on the object. (Diffraction is a normal phenomenon on any video camera.) Using the ND filter allows you to suppress this phenomenon and obtain a better recording result.

Note

- If you change the ND filter setting during recording, the movie and sound may be distorted.
- While adjusting the IRIS (aperture) manually, the ND filter icon will not flash even when the ND filter setting needs adjusting.

[30] How to Use | Recording | Useful functions for recording

Zooming

You can record an image with the subject magnified.

1. Move the power zoom lever to magnify or reduce the size of the image.


W:

Wider range of view (Wide angle)

T:

Close view (Telephoto)

- Move the power zoom lever slightly for a slower zoom. Move it further for a faster zoom.



A: Wide angle

B: Telephoto

Note

- Zoom speed will be slightly slower while recording movies.
- Be sure to keep your finger on the power zoom lever. If you move your finger off the power zoom lever, the operation sound of the power zoom lever may also be recorded.
- You cannot change the zoom speed with the W/T button on the LCD monitor.
- The minimum possible distance between this product and subject while maintaining sharp focus is about 1 cm (about 13/32 in.) for wide angle and about 100 cm (about 39 3/8 in.) for telephoto.

[31] How to Use | Recording | Useful functions for recording

Adjusting the focus manually

You can adjust the focus manually by rotating the lens ring to right/left.

1. Press the AF/MF button to set the focus to manual.
 -  appears on the LCD monitor when the manual focus setting is selected.

Use this function in the following cases.


- To record a subject behind a window covered with raindrops.
 - To record horizontal stripes.
 - To record a subject with little contrast between the subject and its background.
 - When you want to focus on a subject in the background.
 - To record a stationary subject using a tripod.
2. Flip the ZOOM/FOCUS switch to the ZOOM or FOCUS side, and then rotate the lens ring.
ZOOM side: You can adjust the zoom manually by rotating the lens ring.
FOCUS side: You can adjust the focus by rotating the lens ring.

[32] How to Use | Recording | Useful functions for recording

Magnifying the image to obtain better manual focus (Focus Magnifier)

Magnify the image you are currently recording whether the object is in focus.

1. Press the FOCUS MAGNIFIER button, and then touch the part you want to magnify.
 - The  marks appear on the top/bottom/right/left sides of the center of the magnified part.
2. Touch one of the  marks to move the image in the direction you want.



Hint

- Each time you press the FOCUS MAGNIFIER button, the magnification scaling changes as follows:

Movies: between ×1 → ×2 → ×4 → Off

Photos: between ×1 → ×6.3 → ×12.6 → Off

Note


- Even though the image displayed on this product has been magnified, the recorded image is not magnified.
- When the focus is set to manual, you can adjust the focus when displaying a magnified image on the LCD monitor.

[33] How to Use | Recording | Useful functions for recording

Capturing photos during movie recording (Dual Capture)

You can shoot photos during movie recording.

1. Press PHOTO during movie recording to capture still photos.



Note


- You may not be able to shoot photos depending on the setting in [ REC Mode] and [ Frame Rate].
- You cannot capture photos during movie recording in the following situation(s):
 - When an item of [Picture Effect] is selected
 - When [Dual Video REC] is set to [On] and during movie recording

[34] How to Use | Recording | Useful functions for recording

Recording in mirror mode

You can rotate the LCD monitor 180 degrees so the LCD monitor faces toward you to record yourself.

1. Open the LCD monitor 90 degrees to this product (①), then rotate it 180 degrees to the lens side (②), and then start recording.



Hint

- A mirror-image of the subject appears on the LCD monitor, but the image will be normal when recorded.

[35] How to Use | Recording | Useful functions for recording

Intelligent Auto

This product records images after selecting the most suitable setting for the subjects or the situation automatically.

1. Select  - [On] -  on the recording screen of movies or photos.
 - To cancel the Intelligent Auto function, select  - [Off] - .



2. Point this product toward the subject and start recording.
 - The icons that correspond to the conditions detected are displayed.



About the detectable scenes

Face detection: 👤 (Portrait), 👶 (Baby)

Scene detection: 🌅 (Backlight), 🏞️ (Landscape), 🌙 (Night Scene), 🎯 (Spotlight), 📷 (Low light), 🌸 (Macro)

Camera-shake detection: 🚶 (Walk), 📵 (Tripod)

Sound detection: 🗣️, 🌬️ (Auto Wind NR)

Note


- This product may not detect the expected scene or subject, depending on the recording conditions.

[36] How to Use | Recording | Useful functions for recording

Decreasing the voice volume of the person recording the movie (My Voice Canceling)

You can record movies decreasing the voice volume of the person recording the movie.

1. Press the 🗣️ button.
 - When [My Voice Canceling] is set to [On], 🗣️ is displayed.



Note

- Set [My Voice Canceling] to [Off] if you want to record a movie without decreasing the voice volume of the person recording the movie.
- Depending on the recording condition, you cannot decrease the voice volume of the person recording the movie as expected.
- The [My Voice Canceling] function does not activate while an external microphone is connected to this product.

Hint


- You can also set [My Voice Canceling] from the menu.
-

Recording the selected subject clearly (Face Priority)

This product can track a face you select and adjust the focus, exposure, and skin tone of the face automatically.

1. Touch one of the faces targeted.

- To cancel the Face Priority function, select .



A: A double-line frame appears

B: Cancels the function

Note

- The subject you touched may not be detected, depending on the surrounding brightness or hairstyle of the subject.
- Make sure to set the [Face Detection] setting to [Auto].
- When the selected face is out of the LCD monitor or turns away, the double-line frame will disappear.


Recording subjects other than people (Tracking focus)

This product can track a subject you select and adjust the focus automatically.

1. When [Dual Video REC] is set to [On], set it to [Off].

2. Touch the subject you want to track while recording.

- To cancel the Tracking focus function, select .



Note


- When [Dual Video REC] is set to [On], this function is not available. Even if you touch the subject on the LCD monitor, it does not react.

[39] How to Use | Playback | Playing images using Event View


Playing movies and photos from the Event View screen

You can search for recorded images by date and time of recording (Event View).

1. Open the LCD monitor and press  (View Images) to enter the playback mode.
 - You can also operate by selecting  (View Images) on the LCD monitor.




2. Select  /  to move the desired event to the center (①) and then select it (②).
 - This product displays recorded images as an event automatically, based on the date and time.
 - Only movies saved in the format selected in [ File Format] will appear. You can change the displayed movies by selecting the format from **MENU** - [Image Quality/Size] - [ File Format].
 - When you select [ XAVC S 4K], change the [ Frame Rate] setting according to the movie you want to play as well (models with the 4K functionality and NTSC color system).
 [ Frame Rate]:
 When you select 30p, 24p movies will not appear.
 When you select 24p, 30p movies will not appear.




3. Select the image.

- This product plays from the selected image to the last image in the event.



4. Select the appropriate buttons on the LCD monitor for various playback operations.



Buttons for playback operations

 /  : Previous/Next

 : Delete

 /  : Fast-reverse/fast-forward

 : Context

 /  : Pause/Play

 : Stop

 : Play/stop slide show

Note

- To prevent your image data from being lost, save all your recorded images on external media periodically.
- Some buttons described above may not appear, depending on the image being played back.
- Displayed buttons may differ, depending on the model.


Hint

- As you repeat selecting  /  during playback, movies are played as fast as about 5 times - about 10 times - about 30 times - about 60 times.
- Select  /  during pause to play movies slowly.
- When playing only photos, to repeat Slideshow, select  - [Slideshow Set].

Screen display on the Event View screen


Explains items displayed on the Event View screen.

Event View screen



1. To the MENU screen
2. Event name
3. To the previous event
4. To the movie/photo recording mode
5. To play back short movies (Highlight Playback)
 - Appears only when [File Format] is set to [HD AVCHD].
6. Remaining battery
7. To switch movie format (XAVC S/AVCHD/MP4)
 - The displayed icon differs depending on the [File Format] setting.
8. Events
9. To the next event
10. Time-line bar
11. To change Event Scale (approx. 3 months/1.5 years)

Index screen



1. Event name

2. To close the index screen
3. To the previous event
4. To the next event
5. To the movie/photo recording mode
6. Last played image
7. Recorded time/number of photos
8. To switch between the movie/photo playback screen (VISUAL INDEX)
 Select the image type ( MOVIE,  PHOTO,  MOVIE/PHOTO) you want to play.
9. Movie
10. Photo

Note

- Displayed icons may differ, depending on the model.


Hint

- Reduced-size images which enable you to view many images at the same time on an index screen are called “thumbnails.”


Playing back a short movie (Highlight Playback)

You can enjoy movies and photos as a short movie.

- This function is available only when [ File Format] is set to [ AVCHD].
1. Open the LCD monitor and press  (View Images) to enter the playback mode.
 - You can also operate by selecting  (View Images) on the LCD monitor.




2. Display the desired event at the center of the Event View, and select [ Highlight].



3. Play a movie or a photo.



4. Select the desired operation when the highlight playback finishes.



A: This product plays the Highlight Playback scenes again.

B: You can change the settings for Highlight Playback.

Buttons for playback operations

 /  : Previous/Next

 : Volume

 : Context

 /  : Pause/Play

 : Stop

Note

- Movies other than AVCHD movies cannot be played using the Highlight Playback function.
- Highlight Playback scenes will change each time you select a Highlight Playback.
- The [Playback Range] setting is cleared when the Highlight Playback stops.
- After the music file is transferred to this product, if you cannot play the music, the music file may be damaged. Delete the music file by selecting **[MENU]** - [Setup] - [ Playback Settings] - [Empty Music], then transfer the music file again. You can restore the music data recorded on this product at the default using "Music Transfer." For operating instructions, see "Music Transfer" help (models with the NTSC color system and the USB IN/OUT jacks).
- The audio used for the Highlight Playback will be converted to 2ch stereo.

[42] How to Use | Playback | Playing images using Highlight Playback

Changing the settings for Highlight Playback

You can set the playback range of the Highlight Playback and select a theme for Highlight Playback.

- This function is available only when [File Format] is set to [AVCHD].



1. Select [Highlight Setting] on the LCD monitor before or after the Highlight Playback.
 - You can also change the setting by selecting  while this product is playing highlight scenes.

Descriptions of menu items

[Playback Range]

You can set the playback range (starting and ending date) of the Highlight Playback.

[Theme]

You can select a theme for Highlight Playback.

[Music]

You can select music.

[Length]

You can set the length of the Highlight Playback segment.

[Audio mix]

The original sound is played back with the music.

[Highlight Point]

You can set the points in a movie or photo that will be used in a Highlight Playback.

Play the desired movie, and select  - . Or play the desired photo and select .

 appears on the movie or photo that is used in a Highlight Playback.

To erase the points, select  - [Clear All Points].

[43] How to Use | Playback | Playing images using Highlight Playback

Saving Highlight Playback (Scenario Save)

You can save your favorite Highlight Playback as a “Scenario.” Up to 8 scenarios can be saved.

- This function is available only when [ File Format] is set to [ AVCHD].
1. Select [Replay] on the LCD monitor after a Highlight Playback has finished.
 2. When the Highlight Playback starts again, select  - [ Scenario Save].



Note

- The scenarios can be played on this product only.

[44] How to Use | Playback | Playing images using Highlight Playback Playing back a saved scenario

You can play back Highlight Scenarios saved on this product.

- This function is available only when [File Format] is set to [HD] AVCHD.
1. Select [MENU] - [Playback Function] - [Scenario], select the desired scenario, and then select [OK].



Hint

- To erase a saved scenario, select [Erase]/[Erase All] on the [Scenario] screen.

[45] How to Use | Playback | Playing MP4 movies (HD movie) (switching the movie format)


Playing MP4 movies (HD movie) (switching the movie format)

The format of a movie to be played or edited can be changed on the Event View screen.

1. Press (View Images) to enter the playback mode.



2. Select the movie format you want to play from  or  at the top right corner of the LCD monitor.
 - Another icon may appear instead of  depending on the [ File Format] setting.



- The format of a movie to be played or edited will be switched.

[46] How to Use | Playback | Editing images from the playback screen

Notes on editing

- Some basic editing operations can be done on this product. If you want to do advanced editing operations, install and use the PlayMemories Home software.
- You cannot restore images once they are deleted. Save important movies and photos before deleting.
- Do not remove the battery pack or the AC Adaptor from this product while deleting or dividing the images. Doing so may damage the recording media.
- Do not eject the memory card while deleting or dividing images saved on the memory card.
- If you delete or divide movies that are included in saved scenarios, the scenarios will also be deleted.


[47] How to Use | Playback | Editing images from the playback screen

Deleting the selected images


Select and delete unnecessary images.

1. Press the  button on this product to enter the playback mode.
2. On the Event View screen, select , and then select the movie format you want to delete.


- Another icon may appear instead of  depending on the [ File Format] setting and the movie playback format.



3.  - [Edit/Copy] - [Delete].
4. Select [Multiple Images], and then select the type of image you want to delete.



5. Add check marks to the movies or photos to be deleted and select .



Hint

- You cannot delete protected images (). Release the protection of the data before deleting.
- To delete the unwanted part of a movie, divide the movie and then delete that part.


[48] How to Use | Playback | Editing images from the playback screen

Deleting by date


Select unnecessary images by date of recording and delete them.

1. Press the  button on this product to enter the playback mode.
2. On the Event View screen, select , and then select the movie format you want to delete.
 - Another icon may appear instead of  depending on the [ File Format] setting

and the movie playback format.



3. [MENU] - [Edit/Copy] - [Delete].
4. Select [All In Event].
5. Select the date you want to delete using  /  , and then select  .




[49] How to Use | Playback | Editing images from the playback screen

Dividing a movie


Split a recorded movie at your desired point.

- This function is available only when [ File Format] is set to [ AVCHD].

1. Select  - [Divide] on the movie playback screen.



2. Select the point where you want to divide the movie into scenes using  /  , and then select  .



A: Returns to the beginning of the selected movie

B: Adjusts the dividing point with more precision

Note

- A slight difference may occur from the point where you select and the actual dividing point, as this product selects the dividing point based on about half-second increments.
- You cannot divide an XAVC S movie or an MP4 movie.


[50] How to Use | Playback | Editing images from the playback screen

Capturing a photo from a movie (models with the USB IN/OUT jacks)


You can capture images from movies recorded with this product.

- This function is available only when [File Format] is set to [H264/AVCHD].

1. Select  - [Photo Capture] that appears on the playback screen of a movie.



2. Select the scene you want to capture a photo using  / , and then select .



- The image size of the photo will be [2.1 M].

A: Returns to the beginning of the selected movie

B: Adjusts the capturing point with more precision

Note

- You cannot capture photos from an XAVC S movie.


Hint

- The recording date and time of captured photos are the same as the recording date and time of the movies.
- If the movie you are capturing from has no data code, the recording date and time of the photo will be the date and time you captured from the movie.

[51] How to Use | Playback | Playing images on a 4K TV

Viewing images on a 4K TV (models with the 4K functionality)

You can play images recorded in the movie format [4K XAVC S 4K], in high definition image quality by connecting this product to a TV with an HDMI jack.



1. Switch the input on the TV to the connected jack.

- [MENU] - [Setup] - [↔ Connection] - [HDMI Resolution] - desired setting.

The playback image quality differs, depending on the [HDMI Resolution] setting value.

When [HDMI Resolution] is set to [Auto] or [2160p/1080p]

Playback image quality: 4K

When [HDMI Resolution] is set to [1080p], [1080i] or [720p]

Playback image quality: High definition image quality


2. Connect the HDMI cable (①) (supplied) to the HDMI OUT jack (②) on this product and to the HDMI input jack (③) on the TV.

Note

- Refer to the instruction manuals of the TV as well.
 - Use the supplied AC Adaptor as the power source.
-

Using the Trimming Playback function with an XAVC S 4K movie (models with the 4K functionality)

You can trim & play a desired area of image recorded in the movie format [**4K** XAVC S 4K]. The trimmed image is played in high definition image quality.



1. Switch the input on the TV to the connected jack.
 - [MENU] - [Setup] - [↔ Connection] - [HDMI Resolution] - desired setting.

[HDMI Resolution]:

For a 4K TV: [Auto](*), [2160p/1080p](*), [1080p], [1080i], [720p]

For a high definition TV: [Auto], [1080p], [1080i], [720p]

*A black screen appears for a few seconds when you enable/disable the Trimming Playback function.

2. Connect the HDMI cable (①) (supplied) to the HDMI OUT jack (②) on this product and to the HDMI input jack (③) on the TV.
3. While playing a movie, with the  (trimming) button, select the area you want to trim.


Note

- You cannot use the Trimming Playback function only on the LCD monitor of this product.

Connecting this product to a high definition TV

You can play images recorded in XAVC S or AVCHD movie format, in high definition image

quality by connecting this product to a TV with an HDMI jack.



1. Switch the input on the TV to the connected jack.

- [MENU] - [Setup] - [↔ Connection] - [HDMI Resolution] - desired setting.

The playback image quality differs, depending on the [HDMI Resolution] setting value.

When the movie format is XAVC S 4K (models with the 4K functionality)

HDMI Resolution:

[Auto], [1080p], [1080i], [720p]

Playback image quality:

High definition image quality

HDMI Resolution:

[2160p/1080p]

Playback image quality:

4K (You cannot view images on a high definition TV.)

When the movie format is XAVC S HD or AVCHD

HDMI Resolution:

[Auto], [2160p/1080p], [1080p], [1080i], [720p]

Playback image quality:

High definition image quality, 4K(*)

* When you play only photos on a 4K TV, you can play them in 4K resolution from this product.

2. Connect the HDMI cable (①) (supplied) to the HDMI OUT jack (②) on this product and to the HDMI input jack (③) on the TV.


Note

- Refer to the instruction manuals of the TV as well.
- Use the supplied AC Adaptor as the power source.
- If the TV does not have an HDMI input jack, use an AV cable (sold separately). Images are output in standard definition.

Enjoying 5.1ch surround sound

You can record Dolby Digital 5.1ch surround sound with the built-in microphone (default setting). Realistic sound can be enjoyed when playing a movie on devices that support 5.1ch surround sound input.

- This function is available only when [ File Format] is set to [ AVCHD].



A: Built-in microphone

Note

- The sound of XAVC S or MP4 movies is recorded in 2ch sound.
- The built-in speaker does not output 5.1ch surround sound even if you play back a movie recorded with 5.1ch surround sound on this product.
- To enjoy the 5.1ch surround sound of the movies recorded in 5.1ch sound, you need a device compatible with 5.1ch surround.
- When you connect this product with the supplied HDMI cable, the sound of movies recorded in 5.1ch sound is automatically output in 5.1ch sound.

Using BRAVIA Sync

You can operate this product with the remote commander of your TV by connecting this product to a BRAVIA Sync compatible TV launched in 2008 or later with the HDMI cable.

You can operate the menu of this product by pressing the SYNC MENU button of the remote commander of your TV. You can display the LCD monitor of this product such as Event View, play selected movies or display selected photos by pressing up/down/left/right/enter buttons of

the remote commander of your TV.

Note

- There may be some operations you cannot do with the remote commander.
- Set [CTRL FOR HDMI] to [On].
- Also set your TV accordingly. Refer to the instruction manual of the TV for details.
- The operation of BRAVIA Sync differs according to each model of BRAVIA. Refer to the instruction manual of your TV for details.
- If you turn off the TV, this product is turned off simultaneously.

[56] How to Use | Playback | Playing images on a high definition TV

On Photo TV HD

This product is compatible with the Photo TV HD standard. Photo TV HD allows for highly-detailed, photo-like depiction of subtle textures and colors. By connecting Sony's Photo TV HD-compatible devices using the HDMI cable(*), a whole new world of photos can be enjoyed in breathtaking HD quality.

* The TV will automatically switch to the appropriate mode when displaying photos.

[57] How to Use | Playback | Playing images on a high definition TV


On the HDMI cable

- Use the supplied HDMI cable or an HDMI cable with the HDMI logo.
- Use an HDMI micro connector on one end (for this product), and a plug suitable for connecting your TV on the other end.
- Copyright-protected images are not output from the HDMI OUT jack of this product.
- Some TVs may not function correctly (e.g., no sound or image) with this connection.
- Do not connect the HDMI OUT jack of this product to an external device HDMI OUT jack, as malfunction may result. HDMI (High-Definition Multimedia Interface) is an interface to send both video/audio signals. The HDMI OUT jack outputs high quality images and digital audio.

[58] How to Use | Playback | Playing images on a non-high-definition TV

Connecting this product to a non-high-definition TV

Play back images with this product connected to a TV by an AV cable (sold separately).



A: AV cable (sold separately)

1. Switch the input on the TV to the connected jack.
2. Connect the Multi/Micro USB terminal of this product and the VIDEO/AUDIO jack of your TV using an AV cable (sold separately).
3. Play a movie or a photo on this product.

Note

- Refer to the instruction manuals of the TV as well.
- Use the supplied AC Adaptor as the power source.

[59] How to Use | Saving images with an external device | How to save movies

Saving movies

How to save images in each format is as follows.

XAVC S 4K (models with the 4K functionality)

How to save:

Save images on your computer using the PlayMemories Home software.

Saving format:

XAVC S 4K

XAVC S HD

How to save:

Save images on your computer using the PlayMemories Home software.

Saving format:

XAVC S HD

AVCHD

How to save:

Save images on external media or on your computer using the PlayMemories Home software.

Saving format:

AVCHD

Hint

- For the latest storage environment, visit the following website.
<http://www.sony.net/>
- You may also save by connecting a recorder with an AV cable (sold separately). The image quality will be standard definition.


To transfer images to your smartphone

Connect this product and your smartphone via Wi-Fi to transfer MP4 movies to the smartphone. MP4 is a movie format suitable for uploading to websites. This product records an MP4 movie simultaneously while recording a movie.

[60] How to Use | Saving images with an external device | Using the PlayMemories Home software

Using the PlayMemories Home software

You can import movies and still images to your computer to use them in a variety of ways. PlayMemories Home is necessary to import XAVC S or AVCHD movies to your computer.



A: Import images from this product

B: The functions below are also available on a Windows PC

C: View images in a calendar

D: Create a movie disc

E: Upload images to online services

F: Play the imported images

G: Share images on PlayMemories Online

Installing the PlayMemories Home software in your computer

PlayMemories Home can be downloaded from the following URL.

www.sony.net/pm/

[61] How to Use | Saving images with an external device | Using the PlayMemories Home software

Checking the computer system

You can check the system requirements for software at the following URL.

www.sony.net/pcenv/

[62] How to Use | Saving images with an external device | Using the PlayMemories Home software

Installing the PlayMemories Home software in your computer

Installing the PlayMemories Home software on your computer enables you to make use of your recorded images.


1. Access the following download page using an Internet browser on your computer to download the PlayMemories Home software.

www.sony.net/pm/

- Install the software according to the on-screen instructions.
- When the installation has completed, PlayMemories Home starts.
- If the PMB (Picture Motion Browser) software is installed on your computer, it will be overwritten by the PlayMemories Home software. Use PlayMemories Home, the successor software of PMB.

2. Connect this product and your computer with the Built-in USB Cable.

- If the PlayMemories Home software is already installed on your computer, connect this product to your computer. Functions that can be used with this product will then be available.



- ① Built-in USB Cable
- ② To the USB jack of your computer

Note

- Log on to your computer as an administrator.
- You may need to restart your computer. When prompted to restart, follow the on-screen instructions.
- Depending on the usage environment, DirectX can then be installed.

Hint

- For details on PlayMemories Home, refer to the help of PlayMemories Home.

Disconnecting this product from the computer

Disconnect this product from the computer connected with the Built-in USB Cable.

1. Click  in the task tray, and then click .
 - If you use a Windows Vista computer, click  in the task tray.
2. Click the message displayed on the computer screen.
3. Select - on the LCD monitor, and then disconnect the Built-in USB Cable.

Note

- If you use a Mac computer, drag and drop the memory card or the drive icon to the Trash before disconnecting. The connection with the computer is released.
- If you use a Windows 7 or Windows 8 computer, a disconnection icon may not be displayed. In this case, you can release the connection without performing the above operations.

[64] How to Use | Saving images with an external device | Using the PlayMemories Home software

About the dedicated software for this product

You can download the dedicated software from the Sony website.

Windows:

www.sony.co.jp/imsoft/Win/

Mac:

www.sony.co.jp/imsoft/Mac/

Note

- The software that can be used with this product will differ, depending on the countries/regions.

[65] How to Use | Saving images with an external device | Using the PlayMemories Home software

Creating a Blu-ray disc

You can create a Blu-ray disc with an AVCHD movie previously imported to a computer.

To create a Blu-ray disc, the “BD Add-on Software” must be installed.

<http://support.d-imaging.sony.co.jp/BDUW/>

- Your computer must support the creation of Blu-ray discs.
 - BD-R (unrewritable) and BD-RE (rewritable) media are available for creating Blu-ray discs. You cannot add contents to either type of disc after creating the disc.
 - To play back a Blu-ray disc that has been created with a movie that was recorded in [60p Quality **PS**] (models with the NTSC color system) / [50p Quality **PS**] (models with the PAL color system) image quality, you need a device that complies with the AVCHD Ver. 2.0 format.
 - You cannot save MP4 or XAVC S images onto a Blu-ray disc.
-

[66] How to Use | Saving images with an external device | Saving images on an external media device

Notes on use of the external media

Read the precautions when using external media.

Note

- For this operation, you need the USB Adaptor Cable VMC-UAM2 (sold separately).
- Connect the AC Adaptor to this product, and then connect the AC Adaptor to a wall outlet (wall socket).
- Refer to the instruction manual supplied with the external media device.
- You may not be able to use external media devices with a code function.
- The file systems this product recognizes are FAT/NTFS. To use an external media device formatted with a file system that this product cannot recognize, format it on your computer, etc. in advance. Before formatting, make sure that you have no important data saved on the external media device as formatting will delete the data.
- Operation is not guaranteed with all devices satisfying the operating requirements.
- The number of scenes you can save on the external media device is as follows. However, even if the external media device has free space, you cannot save scenes exceeding the following number.

XAVC S movies: Max. 9,999

AVCHD movies: Max. 3,999

The total of photos and MP4 movies: Max. 40,000

- The number of scenes may be smaller depending on the type of images recorded.
- If this product does not recognize the external media device, try the following operations.

Reconnect the USB Adaptor Cable to this product.

If the external media device has the AC power cord (mains lead), connect it to a wall outlet (wall socket).

- You cannot copy images from an external media device to this product.

Devices that cannot be used as an external media device

- The following devices cannot be used as an external media device:

ordinary disc drive such as CD or DVD drive

media devices connected via a USB hub

media devices with a built-in USB hub


card reader

[67] How to Use | Saving images with an external device | Saving images on an external media device

Saving images on an external media device

Easily save movies or photos on an external media device such as an external hard disk drive.


1. Connect this product to the external media device using a USB Adaptor Cable (sold separately).



A: USB Adaptor Cable (sold separately)

- Make sure not to disconnect the Built-in USB Cable while [Preparing image database file. Please wait.] is displayed on the LCD monitor.
- If [Repair Img. DB F.] is displayed on the LCD monitor of this product, select .

2. Select [Copy.] on the LCD monitor of this product.



- Movies and photos that are stored on the recording media, and that have not yet been saved on to an external media device can be saved on the connected media device at this time.
- This operation is available only when there are newly recorded images in this product.
- To disconnect the external media device, select  while either Event View or Event Index is displayed.

Note


- You cannot copy XAVC S movies.

[68] How to Use | Saving images with an external device | Saving images on an external media device

Saving the desired images in this product to the external media device

Save selected movies or photos on an external media device such as an external hard disk drive.


1. Connect this product to the external media device using a USB Adaptor Cable (sold separately).



A: USB Adaptor Cable (sold separately)

- Make sure not to disconnect the Built-in USB Cable while [Preparing image database file. Please wait.] is displayed on the LCD monitor.
- If [Repair Img. DB F.] is displayed on the LCD monitor of this product, select .

2. Select [Play without copying.].



3. Select [MENU] - [Edit/Copy] - [Copy], and then follow the on-screen instructions to save images.

Note

- You cannot copy XAVC S movies.

Hint


- If you want to copy images that have not yet been copied, select [MENU] - [Edit/Copy] - [Direct Copy] while this product is connected to the external media device.

[69] How to Use | Saving images with an external device | Saving images on an external media device

Playing back images in the external media device on this product


Play back images saved on an external media device from this product.

1. Connect this product to the external media device using a USB Adaptor Cable (sold separately).



A: USB Adaptor Cable (sold separately)

2. Select [Play without copying.], and then select the image you want to view.



Hint


- You can also view images on a TV connected to this product.
- When an external media device is connected,  will appear on the Event View screen.
- To play back the images saved on an external media device using your computer, select the drive that represents the external media device on the PlayMemories Home software, and then play movies.

[70] How to Use | Saving images with an external device | Saving images on an external media device

Deleting images in the external media device


Delete images saved on an external media device.

1. Connect this product to the external media device using a USB Adaptor Cable (sold separately).



A: USB Adaptor Cable (sold separately)

2. Select [Play without copying.].



3. Select **[MENU]** - [Edit/Copy] - [Delete], and then follow on-screen instructions to delete

images.


[71] How to Use | Saving images with an external device | Creating a disc with a recorder

Creating a disc with a recorder

You can copy images on this product onto a disc or video cassette. Connect this product to a disc recorder with an AV cable (sold separately).

Note

- Connect the AC Adaptor to this product, and then connect the AC Adaptor to a wall outlet (wall socket).
 - Refer to the instruction manual supplied with the device connected.
1. Insert the recording medium in the recording device (a disc recorder, etc.).
 - If your recording device has an input selector, set it to the input mode.
 2. Connect this product to the recording device with an AV cable (sold separately).
 - Connect this product to the input jacks of the recording device.



A: AV cable (sold separately)

3. Start playback on this product, and record it on the recording device.
4. When dubbing is finished, stop the recording device, and then this product.

Note

- You cannot copy XAVC S movies.
- You cannot copy images to recorders connected with the HDMI cable.
- Since copying is performed via analog data transfer, the image quality may deteriorate.
- Images will be copied with standard definition image quality.
- When you connect a monaural device, connect the yellow plug of an AV cable (sold

separately) to the video input jack, and the white (left channel) or the red (right channel) plug to the audio input jack on the device.

Hint


- Change the [Data Code] setting if you want to copy the date and time and the camera setting data information.
- Set [TV Type] to [4:3] if the screen size of your display device such as TV is 4:3.

[72] How to Use | Using the Wi-Fi function | What you can do with the Wi-Fi function


What you can do with the Wi-Fi function

Explains what you can do using the Wi-Fi function of this product.


Saving movies and photos to your computer




Transferring movies (MP4) and photos to your smartphone or tablet



Using your smartphone or tablet as a wireless remote commander



Playing images on a TV



Note

- You cannot use the Wi-Fi function of this product to connect to a public wireless network.
- PlayMemories Mobile is not guaranteed to work on all smartphones and tablets.

[73] How to Use | Using the Wi-Fi function | Controlling via a smartphone

Using your smartphone or tablet as a wireless remote commander

You can operate this product using your smartphone or tablet as a wireless remote commander.

1. Install PlayMemories Mobile on your smartphone.
 - If PlayMemories Mobile is already installed in your smartphone, update the software to the latest version.
2. On the LCD monitor of this product, select **MENU** - [Camera/Mic] - [ Shooting Assist] - [Ctrl with Smartphone].
 - The SSID and password are displayed on the LCD monitor of this product. This product is now ready to be operated using your smartphone.



A: SSID

B: Password

3. Start PlayMemories Mobile, then on the smartphone screen, select the SSID displayed on the LCD monitor of this product, and then enter the password displayed on the LCD monitor of this product.
 - Connect to this product using your smartphone.
4. Operate this product using your smartphone.

Note

- The photo size stored on the smartphone is [2M] except when the image size is [4:3 S (VGA)].
- Movies are recorded on this product and are not stored on the smartphone.
- The operation methods and display screens for the application are subject to change without notice by future upgrades.
- This application is not guaranteed to work on all smartphones and tablets.

Hint

- For the latest supported OS, refer to the download page of PlayMemories Mobile.

[74] How to Use | Using the Wi-Fi function | Controlling via a smartphone

Using your smartphone or tablet as a wireless remote commander using the NFC function (NFC one-touch remote)


You can operate this product using your NFC-enabled smartphone or tablet as a wireless remote commander.

Note


- Make sure that your smartphone is not in sleep mode and the screen is unlocked in advance.
1. Install PlayMemories Mobile on your smartphone.

- If PlayMemories Mobile is already installed in your smartphone, update the software to the latest version.

2. Select [Settings] on the smartphone, then select [More...] and place a checkmark next to [NFC].



3. Enter the recording mode, and then touch  (N mark) of this product to  (N mark) of your smartphone.



- Make sure that  (N mark) is displayed on the LCD monitor of this product.
- Hold this product and your smartphone together and keep them still for about 1-2 seconds until PlayMemories Mobile starts up on your smartphone.

4. Operate this product using your smartphone.

Note

- The photo size stored on the smartphone is [2M] except when the image size is [ S (VGA)].
- Movies are recorded on this product and are not stored on the smartphone.
- The operation methods and display screens for the application are subject to change without notice by future upgrades.
- This application is not guaranteed to work on all smartphones and tablets.
- If the connections is not made successfully, try the procedures shown in “Connecting to an Android smartphone or tablet.”



Hint


- For the latest supported OS, refer to the download page of PlayMemories Mobile.

[75] How to Use | Using the Wi-Fi function | Transferring images to a smartphone


Transferring movies (MP4) and photos to your smartphone or tablet

Transfer images to your smartphone or tablet.

1. Install PlayMemories Mobile on your smartphone.
 - If PlayMemories Mobile is already installed in your smartphone, update the software to the latest version.
2. Press the  button on this product to enter the playback mode.
3. On the LCD monitor of this product, select **MENU** - [Edit/Copy] - [Send to Smartphone] - [Select on This Device].
 - If you select [Select on Smartphone], all images stored on the memory card are displayed on the smartphone screen.
4. Select the type of image you want to transfer.



5. Select the image you want to transfer, and add  mark, and then select **OK** - **OK**.




- The SSID and a password are displayed on the LCD monitor of this product. This product is now ready to be connected from your smartphone.



A: SSID

B: Password

6. Start PlayMemories Mobile, then on the smartphone screen, select the SSID displayed on the LCD monitor of this product, and then enter the password displayed on the LCD monitor of this product.
7. The images are transferred from this product to the smartphone.
 - Transferred images will be stored in Gallery/Album on an Android smartphone/tablet or Album on an iPhone/iPad.



Note

- You cannot transfer XAVC S movies or AVCHD movies.
- [Send to Smartphone] is not available when MP4 movies or still images have not been saved on this product.
- This application is not guaranteed to work on all smartphones and tablets.

Hint

- For the latest supported OS, refer to the download page of PlayMemories Mobile.


[76] How to Use | Using the Wi-Fi function | Transferring images to a smartphone

Transferring movies (MP4) and photos to your smartphone or tablet using the NFC function (NFC one-touch sharing)


Transfer images to your NFC-enabled Android smartphone or tablet.

Note



- Make sure that your smartphone is not in sleep mode and the screen is unlocked in advance.
1. Install PlayMemories Mobile on your smartphone.
 - If PlayMemories Mobile is already installed in your smartphone, update the software to the latest version.
 2. Select [Settings] on the smartphone, then select [More...] and place a checkmark next to [NFC].



3. Press the  button on this product to enter the playback mode, and then display the image you want to transfer on the LCD monitor of this product.
4. Touch  (N mark) of this product to  (N mark) of your smartphone.



- Hold this product and your smartphone together and keep them still for about 1-2 seconds until PlayMemories Mobile starts up on your smartphone.
 - Make sure that  (N mark) is displayed on the LCD monitor of this product.
5. The images are transferred from this product to the smartphone.
 - Transferred images will be stored in Gallery/Album on an Android smartphone/tablet or Album on an iPhone/iPad.



Note

- You cannot transfer XAVC S movies or AVCHD movies.
- [Send to Smartphone] is not available when MP4 movies or still images have not been saved on this product.
- This application is not guaranteed to work on all smartphones and tablets.
- If the connections is not made successfully, try the procedures shown in “Connecting to an Android smartphone or tablet.”

Hint

- For the latest supported OS, refer to the download page of PlayMemories Mobile.

[77] How to Use | Using the Wi-Fi function | Transferring images to a computer

Send to Computer

You can transfer and save movies and photos to your computer.

1. Install the software on your computer.

For Windows: PlayMemories Home

www.sony.net/pm/

For Mac: Wireless Auto Import

www.sony.co.jp/imsoft/Mac/

- If connecting this product to your computer for the first time after installing the software, set [USB Connect Setting] to [Auto] or [MTP] on this product, and then connect this product to your computer with the Built-in USB Cable.
- If the software is already installed in your computer, update the software to the latest version.

2. Connect this product to the wireless network access point.

- If your access point does not support the WPS push button, refer to [Access point settings].

- If your access point supports the WPS push button, refer to [WPS Push].
 - Settings for steps 1 and 2 are required only the first time.
3. Press the  button on this product to enter the playback mode.
 4. On the LCD monitor of this product, select  - [Edit/Copy] - [Send to Computer].
 - Images are automatically transferred to and saved on the computer.
 - Only newly recorded images are transferred.

Note

- You must turn on the computer to execute [Send to Computer].
- Depending on the settings of the application on the computer, this product may turn off automatically after saving images.
- To import and save images recorded on a memory card to your computer, insert the memory card to this product in advance.
- Importing movies and multiple still images may take time.

[78] How to Use | Using the Wi-Fi function | Transferring images to a TV

Playing images on a TV (View on TV)

You can view images on your TV connected to the network by transferring images from this product without connecting this product and TV with a cable.

Operations may be required on your TV before playing depending on the TV you use. Refer to the instruction manuals of the TV as well.

1. Connect this product to a wireless network access point.
 - If your access point does not support the WPS push button, refer to [Access point settings].
 - If your access point supports the WPS push button, refer to [WPS Push].
 - Step 1 can be skipped from the second time.
2. Press the  button on this product to enter the playback mode.
3. Select  - [Edit/Copy] - [View on TV] - the type of image you want to transfer.
4. Play a movie or a photo on the TV.

Note


- This function is not available for [4K] XAVC S 4K] (models with the 4K functionality) and [HD] XAVC S HD] movies.
- This function is available with the DLNA player compatible TVs.
- You can view images only on TVs that are compatible with the network function (including wired network).
- It may take time until the images are played on the TV.
- This function is not available when using an access point without a security setting (WEP/WPA/WPA2) to protect from prying eyes.
- Select the access point you registered with this product when connecting your TV.
- To enjoy viewing movies comfortably, use a wired network connection for your TV.
Depending on the wireless network environment, movies may not be played smoothly.
- Depending on the settings of the recorded movie, it may not play smoothly.

[79] How to Use | Using the Wi-Fi function | Connecting a smartphone

Connecting to an Android smartphone or tablet

Shows how to connect this product to your Android smartphone or tablet. Display the SSID and password in advance by selecting [Send to Smartphone] or [Ctrl with Smartphone] on this product.

1. Start up PlayMemories Mobile on the smartphone.



2. Select the SSID displayed on this product.



3. Enter the password displayed on this product.



[80] How to Use | Using the Wi-Fi function | Connecting a smartphone


Connecting to an iPhone or iPad

Shows how to connect this product to your iPhone or iPad. Display the SSID and password in advance by selecting [Send to Smartphone] or [Ctrl with Smartphone] on this product.

1. Open the settings menu.



2. Select Wi-Fi.




3. Select the SSID displayed on this product.




4. Enter the password displayed on this product.



5. Confirm that the SSID displayed on this product is selected.



6. Go back to Home and start up PlayMemories Mobile.




[81] How to Use | Using the Wi-Fi function | Connecting a smartphone

Connecting to an NFC-enabled smartphone or tablet

You can easily connect this product to your NFC-enabled Android smartphone or tablet.

Note

- Make sure that your smartphone is not in sleep mode and the screen is unlocked in advance.
1. Touch  (N mark) of this product to  (N mark) of your smartphone.
 - Make sure that  (N mark) is displayed on the LCD monitor of this product.
 - Hold this product and your smartphone together and keep them still for about 1-2 seconds until PlayMemories Mobile starts up on your smartphone.



What you can do with the NFC connection

Operations available when you touch this product to an NFC-enabled smartphone differs depending on the status of this product.

When this product is in movie/photo recording mode
[Ctrl with Smartphone] starts up.

When images are being played back on this product

[Send to Smartphone] starts up and images being played back are transferred.

Note

- To use the one-touch functions of this product, an NFC-enabled smartphone or tablet is required.
- NFC (Near Field Communication) is an international standard for short-range wireless communication technology.
- If the connection is not made successfully, try the procedures shown in “Connecting to an Android smartphone or tablet.”

[82] How to Use | Using the Wi-Fi function | Installing PlayMemories Mobile

About the PlayMemories Mobile software

To perform operations such as [Ctrl with Smartphone] and [Send to Smartphone], the PlayMemories Mobile application for smartphone is required. Install the application from the applications store for your smartphone.

If PlayMemories Mobile is already installed in your smartphone, update the application to the latest version.

For details on PlayMemories Mobile, visit the PlayMemories Mobile support page (www.sony.net/pmm/).

[83] How to Use | Menu operations | Using menu items


Setting up menu items

This product has various menu items under each of 6 menu categories.


1. Select **MENU**.



2. Select a category.



3. Select your desired menu item.




Note

- Select to finish setting the menu or to return to the previous screen.

To find a menu item quickly

The [Camera/Mic] and [Setup] menus have sub-categories. Select the sub-category icon so that you can select your desired menu item.




A

A: Sub-category icons


When you cannot select a menu item

Some menu items or settings are not available, depending on the settings of this product. When you select grayed out menu items or settings, this product displays the reason why you cannot select the menu item.



How to use the keyboard

A keyboard is displayed on the LCD monitor when text needs to be entered.



1. Switch character types.

Each time you touch the key, the type of character to be input switches between letters, numerals and symbols.

2. Keyboard

Each time you touch the key, the displayed character switches between the choices available.

For example: If you want to enter "abd"

Select [abc], touching it once to display "a" - touch  - select [abc], touching it twice to display "b" - select [def] touching it once to display "d."

3. Space

Enters a space.

4. Input box

The characters you entered are displayed. ◀ indicates the limit to text length.

5. Move cursor

Moves the cursor in the input box to the right or left.

6. Delete

Deletes the character preceding the cursor.

7.

Switches the next character to a capital or small letter.

8. Fix

Finalizes the entry.

To cancel text entry, select  .

[85] How to Use | Menu operations | Shooting Mode

Movie

You can select the movie recording mode.

1. **MENU** - [Shooting Mode] - [Movie].

[86] How to Use | Menu operations | Shooting Mode

Photo

You can select the photo shooting mode.

1. **MENU** - [Shooting Mode] - [Photo].

[87] How to Use | Menu operations | Shooting Mode

Smth Slw REC

This product records approximately 3-second-long fast actions or motions as an approximately 12-second-long slow-motion movie.

1. **MENU** - [Image Quality/Size] - [File Format] - [AVCHD].
2. **MENU** - [Shooting Mode] - [Smth Slw REC].
3. Select  /  to change the timing at which this product starts recording.



[3sec After] (default setting):

This product records a movie of approximately 3 seconds after the START/STOP button is pressed.

[3sec Before]:

This product records a movie of approximately 3 seconds before the START/STOP button is pressed.

4. Press the START/STOP button.

- [Recording...] disappears when recording is finished.

Note


- You cannot record sound.
- Image quality is not as good as that of normal recording.
- [REC Mode] will be set to [Standard **HQ**] automatically.

[88] How to Use | Menu operations | Shooting Mode


Golf Shot

Divides 2 seconds of fast movement into frames which are then recorded as a movie and photos. You can view a series of movement when playing back, which is convenient in cases such as checking golf swing or tennis form.

1. [MENU] - [Image Quality/Size] - [File Format] - [AVCHD].
2. [MENU] - [Shooting Mode] - [Golf Shot].
3. Frame the subject in the white grid in the center of the LCD monitor, then press START/STOP right after the subject has taken a swing.



- If the moment when the largest sound in 1 second after the START/STOP button is pressed has been detected, this product assumes the moment as the sound of a club hitting the ball. When the sound of a club hitting the ball is detected, the recording time period is automatically adjusted according to at that moment.



* seconds

A: The point when you press START/STOP

B: The sound of a club hitting the ball

C: This product records images in this 2 second period.

Note

- If this product cannot detect the sound of a club hitting the ball, this product automatically sets the impact point at 0.5 second before the START/STOP button has been pressed, and records a movie in the time period between 1.5 seconds before the impact point to 0.5 second after the impact point.
- The size of photos becomes 1,920×1,080.
- You cannot record sound.
- Image quality is not as good as that of normal recording.
- [REC Mode] will be set to [Standard HQ] automatically.
- Impact sound may be detected by the built-in microphone even when an external microphone is attached.
- The image recorded may be noisy when this product has failed to analyze the shot properly because there may be movement in background of the recording screen. It is recommended that you record images under stable conditions (for example, using a tripod).

Hint

- You can check your form using self-timer. Select [ON] / [OFF] - [On], this product starts countdown of the timer after you press the START/STOP button. The point when the count reaches 0 is assumed as the moment of impact and motion before and after 0 is recorded.

[89] How to Use | Menu operations | Shooting Mode

High Speed REC

When you record [HD] XAVC S HD] movies, you can use the high-speed recording function.

1. [MENU] - [Image Quality/Size] - [File Format] - [HD] XAVC S HD].
2. [MENU] - [Shooting Mode] - [High Speed REC].

Note

- When you set [File Format] to [4K] XAVC S 4K] (FDR-AX100/FDR-AX100E) or [HD] AVCHD], this function is not available.
 - Image quality is not as good as that of normal recording.
-

[90] How to Use | Menu operations | Camera/Mic

White Balance

You can adjust the color balance to the recording environment.

1.  - [Camera/Mic] - [ Manual Settings] - [White Balance] - desired setting.
 - You can also use the WHITE BALANCE button for this setting.

Descriptions of menu items

 (Auto) (default setting):

The white balance is adjusted automatically.

If you have changed the battery pack while [Auto] was selected, or taken this product outdoors after inside use (or vice versa), aim this product at a nearby white object for about 10 seconds for better color balance adjustment.

 (Outdoor):

The white balance is appropriately adjusted for the following recording conditions:

- Outdoors
- Night views, neon signs and fireworks
- Sunrise or sunset
- Under daylight fluorescent lamps

 (Indoor):

The white balance is appropriately adjusted for the following recording conditions:

- Indoors
- At party scenes or studios where the lighting conditions change quickly
- Under video lamps in a studio, or under sodium lamps or incandescent-like color lamps

 (Color Temp.):

Adjust the white balance according to the color temperature of the light source.

- Select the color temperature and increase/decrease the value with  / .

 (One Push):

The white balance will be adjusted according to the ambient light.

1. Select .
2. Keep framing white object such as a piece of paper, to fill the LCD monitor under the same lightning conditions as you will shoot the subject.
3. Select .

If the lighting conditions changed by bringing this product outdoors from inside the house, or vice versa, you need to redo the [One Push] procedure to readjust the white balance.

Adjusting the white balance manually

1. Select [OPTION] on the [White Balance] setting screen.
2. Adjust the color balance using  /  (B-A) and  /  (G-M).
3. Select .

Hint

- You can check the currently selected color balance on the LCD monitor with the color chart.

Note

- Set [White Balance] to [Auto] or adjust the color in [One Push] under white or cool white fluorescent lamps.
- While you are recording a movie, ^{SET} (One Push) cannot be set.
- If you set [White Balance], [Scene Selection] is set to [Auto].

[91] How to Use | Menu operations | Camera/Mic

Spot Meter/Fcs

Exposure and focus can be adjusted for the selected subject automatically.

1.  - [Camera/Mic] - [ Manual Settings] - [Spot Meter/Fcs].
2. Touch the subject of which you want to adjust the exposure and focus.
 - To adjust the brightness and focus automatically, select [Auto].



Note


- [Exposure] and [Focus] are automatically set to [Manual].

[92] How to Use | Menu operations | Camera/Mic

Spot Meter

Exposure can be adjusted and set for the selected subject automatically. This function is useful when there is strong contrast between the subject and the background, such as subjects in the spotlight on stage.

1. [MENU] - [Camera/Mic] - [Manual Settings] - [Spot Meter].
2. Touch the subject of which you want to adjust the exposure.
 - To return the setting to automatic exposure, select [Auto].



Note

- [Exposure] is automatically set to [Manual].

[93] How to Use | Menu operations | Camera/Mic

Spot Focus

Focus can be adjusted automatically for the subject selected.

1. [MENU] - [Camera/Mic] - [Manual Settings] - [Spot Focus].
2. Touch the subject of which you want to adjust the focus.
 - To adjust the focus automatically, select [Auto].



Note

- [Focus] is automatically set to [Manual].

[94] How to Use | Menu operations | Camera/Mic

Exposure

You can fix the brightness of an image manually. Adjust the brightness when the subject is too bright or too dark.

1.  - [Camera/Mic] - [ Manual Settings] - [Exposure] - desired setting.

Descriptions of menu items

Auto (default setting):

The exposure is adjusted automatically.

Manual:

Select  if the subject is white or the backlight is bright, or select  if the subject is black or the light is dim.

[95] How to Use | Menu operations | Camera/Mic

Focus

You can adjust the focus manually. You can select this function also when you want to focus on a certain subject intentionally.

1.  - [Camera/Mic] - [ Manual Settings] - [Focus] - desired setting.

Descriptions of menu items

Auto (default setting):

The focus is adjusted automatically.

Manual :

 appears.

Adjust the focus using  (nearby subject) or  (distant subject).  appears when the focus cannot be adjusted any closer, and  appears when the focus cannot be adjusted farther away.

Note

- The minimum possible distance between this product and subject while maintaining sharp focus is about 1 cm (about 13/32 in.) for wide angle and about 100 cm (about 39 3/8 in.) for telephoto.

Hint

- It is easier to focus on the subject by moving the power zoom lever towards T (telephoto) to adjust the focus, then towards W (wide angle) to adjust the zoom for recording. When you want to record a subject at close range, move the power zoom lever to W (wide angle), then adjust the focus.

- This product displays the focal distance information for a few seconds when [Focus] is set to [Manual] or when you set the focus manually. You can use this information as a guide when the subject is dark and focus adjustment is difficult.

[96] How to Use | Menu operations | Camera/Mic

AGC Limit

You can select the upper limit for the AGC (Auto Gain Control).

1. - [Camera/Mic] - [ Manual Settings] - [AGC Limit] - desired setting.

Descriptions of menu items

Off (default setting):

The gain is automatically adjusted.

24dB/21dB/18dB/15dB/12dB/9dB/6dB/3dB/0dB (**AGC↑**):

The gain is automatically adjusted up to the selected limit.

Note

- At a higher gain, the brightness becomes more appropriate in dim scenes, but the noise increases. At a lower gain, the noise decreases, but the shutter speed becomes slower to compensate for the lack of brightness, causing camera shake or subject blur.

[97] How to Use | Menu operations | Camera/Mic

AE Shift

You can adjust the exposure according to your preference.

1. - [Camera/Mic] - [ Manual Settings] - [AE Shift] - desired setting.

Descriptions of menu items

Off (default setting):

The exposure is adjusted automatically.

On (Adjusted number and EV):

Adjust the automatic exposure level using when the subject is white or the background

is bright, and  when the subject is dark or the light is dim.

[98] How to Use | Menu operations | Camera/Mic

LOW LUX

You can record bright color images, even in dim light.

1.  - [Camera/Mic] - [ Manual Settings] - [Low Lux] - desired setting.

Descriptions of menu items

Off (default setting):

The Low Lux function is not used.

On ():

The Low Lux function is used.

[99] How to Use | Menu operations | Camera/Mic

Scene Selection

You can record images effectively in various situations.

1.  - [Camera/Mic] - [ Camera Settings] - [Scene Selection] - desired setting.

Descriptions of menu items

 (Auto)(default setting):

Adjusts image quality automatically.

 (Night Scene)(*):

Using a tripod (sold separately) allows you to shoot beautiful night scenes.



 (Sunrise&Sunset)(*):

Reproduces the atmosphere of scenes such as sunsets or sunrises.



 (Fireworks)(*):

Takes spectacular shots of fireworks.



 (Landscape)(*):

Shoots distant subjects clearly. This setting also prevents this product from focusing on glass or metal mesh in windows between this product and the subject.



 (Portrait):

Brings out the subject such as people or flowers while creating a soft background.



 (Spotlight):

Prevents people's faces from appearing excessively white when subjects are lit by strong light.



 (Beach):

Takes the vivid blue of the ocean or a lake.



 (Snow):

Takes bright pictures of a white landscape.



*Adjusted to focus on subjects farther away only.

Note

- If you set [Scene Selection], the following settings are canceled.

White Balance

 Cinematone

IRIS (aperture)

Shutter Speed

Gain (ISO)

[100] How to Use | Menu operations | Camera/Mic

Picture Effect

Allows you to shoot more impressive images by selecting the desired effect.

1. **[MENU]** - [Camera/Mic] - [ Camera Settings] - [Picture Effect] - desired setting.

Descriptions of menu items

Off (default setting):

Does not use the Picture Effect.

     (Toy Camera):

Allows you to shoot an image having a unique color tone with its surrounding colors dark. Select the effect you want with [OPTION].

 (Pop Color):

Allows you to shoot a pop art-like colorful image with emphasis on the color tone.

  (Posterization):

Creates a high contrast, abstract look by heavily emphasizing primary colors, or in black and white. Select the effect you want with [OPTION].

 (Retro Photo):

Creates the look of an aged photo with sepia color tones and faded contrast.

 (Soft High-key):

Allows you to shoot soft, clear images with an emphasis on brightness.

    (Partial Color):

Allows you to shoot an image that makes a strong impression by leaving a specified color on portions of a monochrome image. Select the effect you want with [OPTION].

 (High Contrast Mono.):

Creates an intense, high-contrast image in black and white.

Note

- When you select a [Picture Effect] item, the following functions are not available.
 - Recording photos in the movie recording mode
 - Some other functions

[101] How to Use | Menu operations | Camera/Mic

Cinematone

This product automatically adjusts the image quality of the movie to resemble the atmosphere of film camera images.

1.  - [Camera/Mic] -  Camera Settings -  Cinematone - desired setting.

Descriptions of menu items

Off (default setting):

Does not use the Cinematone function.

On :

Uses the Cinematone function.

Note

- When you switch this function on or off, the image will be paused temporarily.
- When  Cinematone is set to [On], the [Scene Selection] setting changes to [Auto].
- When  Cinematone is set to [On], the [Picture Effect] setting changes to [Off].



Fader

You can record a transition with the following effects adding to the interval between scenes. Select the desired effect in [STBY] (to fading in) or [REC] (to fading out) mode.

1. [MENU] - [Camera/Mic] - [📷 Camera Settings] - [🎞️ Fader] - desired setting.

Descriptions of menu items

Off (default setting):

Does not use an effect.

White Fader(**W**):

Fades in/out with the white effect.



A: Out

B: In

Black Fader(**B**):

Fades in/out with the black effect.

Images recorded using the [Black Fader] effect may appear dark on the index screen.



A: Out

B: In

Note

- When you press START/STOP, the setting is cleared.

Self-Timer

Press PHOTO to start the count down. A photo is recorded after about 10 seconds.

Note

- You can also operate by pressing PHOTO on the Wireless Remote Commander.
1.  - [Camera/Mic] - [ Camera Settings] - [ Self-Timer] - desired setting.

Descriptions of menu items

Off (default setting):

Cancels the self-timer.

On ():

Starts the self-timer recording. To cancel the recording, select .

[104] How to Use | Menu operations | Camera/Mic

SteadyShot (Movie)

You can compensate for camera shake.

1.  - [Camera/Mic] - [ Camera Settings] - [ SteadyShot] - desired setting.

Descriptions of menu items

Active :

Records a movie using a more effective SteadyShot function.

Standard (default setting):

This product reduces camera shake using the SteadyShot function in wide-angle shooting.

Off ():

This product does not use the SteadyShot function.

Note

- The angle of view will be changed after changing the settings of the [ SteadyShot] function.
- When you set [ SteadyShot] to [Active], the zoom magnification is 24x when recording an HD movie and 18x when recording a 4K movie (FDR-AX100/FDR-AX100E).

SteadyShot (Photo)

You can compensate for camera shake. Set [ SteadyShot] to [Off] when using a tripod (sold separately), then the image becomes natural.

1. [MENU] - [Camera/Mic] - [ Camera Settings] - [ SteadyShot] - desired setting.

Descriptions of menu items

On (default setting):

The SteadyShot function is used.

Off ():

The SteadyShot function is not used.

Digital Zoom

You can select the maximum zoom level. Note that the image quality decreases when you use the digital zoom.

1. [MENU] - [Camera/Mic] - [ Camera Settings] - [Digital Zoom] - desired setting.

Descriptions of menu items

Off (default setting):

Digital zoom cannot be used.

160:

Up to 160 zoom is performed digitally.

Auto Back Light

This product adjusts the exposure for backlit subjects automatically.

1. **MENU** - [Camera/Mic] - [ Camera Settings] - [Auto Back Light] - desired setting.

Descriptions of menu items

On (default setting):

The exposure for backlit subjects is adjusted automatically.

Off:

Does not adjust the exposure for backlit subjects.

[108] How to Use | Menu operations | Camera/Mic

Dial Setting

You can assign one menu item you often use to the MANUAL dial.

1. **MENU** - [Camera/Mic] - [ Camera Settings] - [Dial Setting] - desired setting.

Menu items that you can set

Exposure /AE Shift/WB Color Temp./WB B-A/WB G-M

[109] How to Use | Menu operations | Camera/Mic

NIGHTSHOT Light

When recording in a dark place with the NightShot function, you can change the infrared light setting.

1. **MENU** - [Camera/Mic] - [ Camera Settings] - [NIGHTSHOT Light] - desired setting.

Descriptions of menu items

On (default setting):

Emits infrared light.

Off :

Does not emit infrared light.

[110] How to Use | Menu operations | Camera/Mic

Face Detection

You can set this product to detect a face automatically. This product adjusts the focus/color/exposure automatically for the face of the selected subject.

1. **MENU** - [Camera/Mic] - [ Face] - [Face Detection] - desired setting.

Descriptions of menu items

Auto (default setting):

Detects faces.

Off ():

Does not detect faces.

Note

- Faces may not be detected depending on recording conditions.

Hint

- Recording conditions for better face detection performance are as follows.

Shoot in a sufficiently bright place.

The subject is not wearing glasses, a hat or mask.

The subject faces directly towards the camera.

[111] How to Use | Menu operations | Camera/Mic

Smile Shutter

The shutter is released automatically when this product detects a smile. If you do not want to take photos automatically, select [Off].

1. **MENU** - [Camera/Mic] - [ Face] - [Smile Shutter] - desired setting.

Descriptions of menu items

Dual Capture ([😊]📷):

Only during movie recording, the shutter is released automatically, when this product detects a smile.

Always On ([😊]ON):

The shutter is released when this product detects a smile whenever this product is in recording mode.

Off (default setting):

Smiles are not detected, so photos are not recorded automatically.

Note

- Smiles may not be detected depending on recording conditions, subject conditions, and the setting of this product.

[112] How to Use | Menu operations | Camera/Mic

Smile Sensitivity

Sets the smile detection sensitivity for using the Smile Shutter function.

1. [MENU] - [Camera/Mic] - [📷 Face] - [Smile Sensitivity] - desired setting.

Descriptions of menu items

Big Smile:

Detects a big smile.

Normal Smile (default setting):

Detects a normal smile.

Slight Smile:

Detects even a slight smile.

[113] How to Use | Menu operations | Camera/Mic

Flash (Only when connecting an external flash)

Select the flash setting.

Select the desired flash setting when you record photos using an external flash (sold

separately) compatible with this product.

1. **MENU** - [Camera/Mic] - [ Flash] - [Flash] - desired setting.

Descriptions of menu items

Auto (default setting):

Automatically flashes when there is insufficient ambient light.

On ():

Always uses the flash regardless of the surrounding brightness.

Off ():

Records without flash.

Note

- The flash does not operate in the movie recording mode.

Hint

- Particles (dust, pollen, etc.) floating close to the lens are accentuated by a flash, and they appear as white circular spots. To reduce this phenomenon, brighten the recording place and record the subject without a flash.

[114] How to Use | Menu operations | Camera/Mic

Flash Level (Only when connecting an external flash)

You can select the brightness of the flash light.

Select the desired brightness when you record photos using an external flash (sold separately) compatible with this product.

1. **MENU** - [Camera/Mic] - [ Flash] - [Flash Level] - desired setting.

Descriptions of menu items

High:

Makes the flash level higher.

Normal (default setting):

Normal flash level

Low:

Makes the flash level lower.

Red Eye Reduction (Only when connecting an external flash)

Prevent redevye by activating the pre-flash before the flash operates.

Set this function when you record photos using an external flash (sold separately) compatible with this product.

1.  - [Camera/Mic] - [ Flash] - [Red Eye Reduction] - desired setting.

Descriptions of menu items

Off (default setting):

Does not use Red Eye Reduction to prevent redevye.

On ():

Uses Red Eye Reduction to prevent redevye.

Note

- The redevye reduction may not produce the desired effect due to individual differences and other conditions.
- The redevye function does not work with automatic recording by [Smile Shutter].

My Voice Canceling

You can record the voice of the subject clearly by decreasing the voice volume of the person recording the movie.

1.  - [Camera/Mic] - [ Microphone] - [My Voice Canceling].

Descriptions of menu items

Off (default setting):

Does not decrease the voice volume of the person recording the movie.

On ():

Decreases the voice volume of the person recording the movie and records the voice of the subject clearly.

Note

- Set [My Voice Canceling] to [Off] if you want to record a movie without decreasing the voice volume of the person recording the movie.
- Depending on the recording condition, you cannot decrease the voice volume of the person recording the movie as expected.
- The [My Voice Canceling] function does not activate while an external microphone is connected to this product.

[117] How to Use | Menu operations | Camera/Mic

Blt-in Zoom Mic

You can record a movie with vivid sound appropriate to the zoom position.

1. **[MENU]** - [Camera/Mic] - [ Microphone] - [Blt-in Zoom Mic] - desired setting.

Descriptions of menu items

Off (default setting):

The microphone does not record sound following zooming in or out.

On ():

The microphone records sound following zooming in or out.

Note

- When you set [Audio Rec Level] to [Manual], [Blt-in Zoom Mic] is set to [Off] automatically.

[118] How to Use | Menu operations | Camera/Mic

Auto Wind NR

This function automatically cuts the low-range wind noise according to the noise level when recording using the built-in microphone.

1. **[MENU]** - [Camera/Mic] - [ Microphone] - [Auto Wind NR] - desired setting.

Descriptions of menu items

Off (🔇):

Does not reduce the wind noise.

On (default setting):

Reduces the wind noise.

Note

- When you set [Auto Wind NR] to [Off], Intelligent Auto is set to [Off].
- [Auto Wind NR] will not function while an external microphone is attached to this product.

[119] How to Use | Menu operations | Camera/Mic

Audio Mode

You can change the recording sound format.

1. [MENU] - [Camera/Mic] - [🔊 Microphone] - [Audio Mode] - desired setting.

Descriptions of menu items

5.1ch Surround (🔊5.1ch) (default setting):

Records sound in 5.1ch surround.

2ch Stereo (🔊2ch):

Records sound in 2ch stereo.

Hint

- [5.1ch Surround] is available only when [📁 File Format] is set to [📺 AVCHD].
- XAVC S movies are set to [2ch Stereo] automatically, and you cannot select the audio format.

[120] How to Use | Menu operations | Camera/Mic

Audio Rec Level

You can adjust the audio recording level.

1. - [Camera/Mic] - [ Microphone] - [Audio Rec Level] - desired setting.

Descriptions of menu items

Auto (default setting):

The audio recording level is adjusted automatically.

Manual ():

Adjust the audio recording level with to raise the audio recording level and to lower the audio recording level.

Note

- The setting will be reset each time you switch between [Auto] and [Manual].
- When [Audio Rec Level] is set to [Manual], the following will switch to [Off].
 - Blt-in Zoom Mic
- It is recommended that you wear headphones to operate while checking the level.
- When continuously recording loud sound, lower the recording level in advance to record dynamic sound.
- The limiter is always active regardless of the setting value of the recording level.
- When you are using a dedicated microphone that is connected with the Multi interface shoe, the recording level setting will be invalid, and you will not be able to adjust the recording level.
- After setting [My Voice Canceling] to [On], you cannot change the audio recording level anymore.

[121] How to Use | Menu operations | Camera/Mic

Ctrl with Smartphone

You can use your smartphone as a wireless remote commander.


1. - [Camera/Mic] - [ Shooting Assist] - [Ctrl with Smartphone].

[122] How to Use | Menu operations | Camera/Mic


My Button

You can assign functions that you frequently use when recording to one of the My Buttons.

1. - [Camera/Mic] - [ Shooting Assist] - [My Button].
2. Select the menu item that you want to assign to a My Button using / .



3. Select one of the My Buttons to which the menu item will be assigned.



4. Select .

[123] How to Use | Menu operations | Camera/Mic

Grid Line

You can display the lines and check that the subject is horizontal or vertical.

1. - [Camera/Mic] - [ Shooting Assist] - [Grid Line] - desired setting.

Descriptions of menu items

Off (default setting):

Does not display the grid lines.

On:

Displays the grid lines.

- Positioning the subject at the cross point of the grid lines makes a balanced composition.
- The lines is not recorded.
- The outer frame of grid lines shows the display area of a TV which is not compatible with full pixel display.

Zebra

You can display a zebra pattern as a guide for adjusting brightness.

1. **MENU** - [Camera/Mic] - [ Shooting Assist] - [Zebra] - desired setting.

Descriptions of menu items

Off (default setting):

Does not display the zebra pattern.

On :

Displays  and the brightness level (IRE). Adjust the brightness level using  / .

IRE (Institute of Radio Engineers) is a measure of the video signal level that is used as the bases of brightness; the reference level (pedestal level) is set to 0 (%) and the maximum level (completely white level) is set to 100 (%).

Note

- With a subject that exceeds a brightness level of 100 IRE, the image may become overexposed.

Hint

- The zebra pattern will not be recorded with the image.
-

Peaking

You can display an image on the LCD monitor with its outlines enhanced with colors. This function helps you to adjust the focus.

1. **MENU** - [Camera/Mic] - [ Shooting Assist] - [Peaking] - desired setting.

Descriptions of menu items

On /Off (default setting):

When [Peaking] is set to [On],  /  /  appears and images are displayed with their outlines enhanced. This helps you to adjust the focus. (The default setting is [Off].)

Color:

Select the color from [White], [Red] or [Yellow]. (The default setting is [White].)

Level:

Select the peaking sensitivity from [High], [Mid] or [Low]. (The default setting is [Mid].)

Note

- The enhanced outlines may not appear in a dark location.

Hint

- The enhanced outlines will not be recorded on the image.

[126] How to Use | Menu operations | Camera/Mic

Camera Data Disp.

Select which setting values to display.

1. **MENU** - [Camera/Mic] - [ Shooting Assist] - [Camera Data Disp.] - desired setting.

Off:

Displays only setting values you can adjust manually.

On (default setting):

Displays all setting values always.

[127] How to Use | Menu operations | Camera/Mic

Audio Level Display

You can select whether or not to display the audio level meter. Shape of the audio level meter differs depending on the [Audio Mode] setting.

1. **MENU** - [Camera/Mic] - [ Shooting Assist] - [Audio Level Display] - desired setting.

Descriptions of menu items

On (default setting):

Displays audio level meter.

Off:

Does not display the audio level meter.

[128] How to Use | Menu operations | Image Quality/Size

REC Mode

You can select your desired image quality for AVCHD movies. The recording time or the type of media device to which the images can be copied may differ, depending on the movie quality selected.

1. **MENU** - [Image Quality/Size] - [ REC Mode] - desired setting.

Descriptions of menu items

Highest Quality **FX** :

Records a movie in the highest quality possible for this product (when in 60i (*)/50i (**)/24p (*)/25p (**)).

High Quality **FH** :

Records a higher quality movie (when in 60i (*)/50i (**)/24p (*)/25p (**)).

Standard **HQ** :

Records a standard quality movie (when in 60i (*)/50i (**)).

Long Time **LP** :

Records a long movie (when in 60i (*)/50i (**)).

60p Quality **PS** (*)/50p Quality **PS** (**)

Records a movie in 60p (*)/50p (**).

* Models with the NTSC color system

** Models with the PAL color system

Hint

- Types of media that images can be saved on will depend on the image quality selected.

60p Quality **PS** (*)/50p Quality **PS** (**)/Highest Quality **FX** :

Memory card, external media, Blu-ray discs

High Quality **FH**/Standard **HQ**/Long Time **LP** :

Memory card, external media, Blu-ray discs, AVCHD recording discs

* Models with the NTSC color system: [60p Quality **PS**] can be set only when the [ Frame Rate] is set to [60p].

** Models with the PAL color system: [50p Quality **PS**] can be set only when the [ Frame Rate] is set to

Frame Rate

You can select the frame rate to be used to record [**4K**] XAVC S 4K] (FDR-AX100/FDR-AX100E), [**HD**] XAVC S HD] or [**HD**] AVCHD] movies. Set [**REC Mode**] first, before setting [**Frame Rate**].

1. [**MENU**] - [Image Quality/Size] - [**Frame Rate**] - desired setting.

Available frame rate settings vary as follows depending on the recording format.

Available frame rate settings

4K] XAVC S 4K (FDR-AX100/FDR-AX100E):
30p(*) (default setting)/24p(*)/25p(**) (default setting)

HD] XAVC S HD:
60p(*)/50p(**) (default setting)/30p(*)/24p(*)/25p(**)

HD] AVCHD:
60p(*)/50p(**)/60i(*)/50i(**) (default setting)/24p(*)/25p(**)

Descriptions of menu items

60i(*)/50i(**):

This is an ordinary setting for AVCHD movies.

60p(*)/50p(**):

You can record movies with a volume of data twice that of 60i(*), 50i(**) or 30p(*) per unit time. When you play a movie recorded with this setting on a TV, the TV must be compatible with 60p(*) or 50p(**) movie playback.

30p(*):

It is recommended that you record movies with this setting using a tripod.

24p(*)/25p(**)

You can record movies which provide an atmosphere closer to that of film images with this setting. It is recommended that you record movies with this setting using a tripod.

* Models with the NTSC color system

** Models with the PAL color system

- The media that the recorded images can be saved on will depend on the recording mode that has been set during recording.

[130] How to Use | Menu operations | Image Quality/Size

Dual Video REC

You can set the dual recording mode (recording an MP4 movie during movie recording) to on or off.

1. **MENU** - [Image Quality/Size] - [Dual Video REC] - desired setting.

Descriptions of menu items

On :

Records an MP4 movie while recording a 4K movie (FDR-AX100/FDR-AX100E) or HD movie.

Off (default setting):

Does not record an MP4 movie while recording an HD movie.

Note

- When [**File Format**] is set to [**XAVC S HD**] and [**Frame Rate**] is set to 60p (models with the NTSC color system)/50p (models with the PAL color system), [Dual Video REC] will be set to [Off].
- When [**File Format**] is set to [**AVCHD**] and [**REC Mode**] is set to [60p Quality **PS**] (models with the NTSC color system)/[50p Quality **PS**] (models with the PAL color system), [Dual Video REC] will be set to [Off].
- When [**File Format**] is set to [**AVCHD**] and [**Frame Rate**] is set to 60p (models with the NTSC color system)/50p (models with the PAL color system), [Dual Video REC] will be set to [Off].
- When [Dual Video REC] is set to [On], you cannot use the following functions.
 - Capturing photos during movie recording (Dual Capture)
 - Recording the selected subject clearly (Face Priority)

[131] How to Use | Menu operations | Image Quality/Size

File Format

Set the recording format for recording and playback.

1.  - [Image Quality/Size] - [ File Format] - desired setting.

Descriptions of menu items

FDR-AX100/FDR-AX100E

 XAVC S 4K (default setting):

Records 4K images in XAVC S format.

This setting is suitable for watching on a 4K TV. Both recording and playback switches.

Movies you can play are also switched according to the [ Frame Rate] setting value.

 XAVC S HD:

Records HD (high definition) images in XAVC S format.

This setting is suitable for watching on an HD (high definition) TV. Both recording and playback switches.

 AVCHD:

Records HD (high definition) images in AVCHD format.

This setting is suitable for watching on an HD (high definition) TV and Blu-ray disc recording. Both recording and playback switches.

HDR-CX900/HDR-CX900E

 XAVC S HD:

Records HD (high definition) images in XAVC S format.

This setting is suitable for watching on an HD (high definition) TV. Both recording and playback switches.

 AVCHD (default setting):

Records HD (high definition) images in AVCHD format.

This setting is suitable for watching on an HD (high definition) TV and Blu-ray disc recording. Both recording and playback will be switched.

[132] How to Use | Menu operations | Image Quality/Size

Image Size

You can select a size for the photos you are going to shoot. The number of photos you can shoot differs, depending on the image size selected.

1.  - [Image Quality/Size] - [ Image Size] - desired setting.

- The image size is set according to the format selected as [ File Format].

16:9 L (20.0M) (*)

4:3 L (15.0M)(*)

16:9 M (14.2M)

4:3 M (10.6M)

16:9 S (2.1M)

4:3 S (VGA)

* Only for FDR-AX100/FDR-AX100E

Note

- The default value is M.
- You cannot select L when [ File Format] is set to [ XAVC S HD] or [ AVCHD] (L will be changed to M automatically).
- The image size selected with this setting also is applied to photos taken by the Dual Capture function.
- [Clear Image Zoom] is used for capturing M size photos during movie recording (Dual Capture) in the [ AVCHD] or [ XAVC S HD] movie format and when recording L size photos.

[133] How to Use | Menu operations | Playback Function

Event View

You can play back recorded images by date of recording (Event View).

1.  - [Playback Function] - [Event View].

[134] How to Use | Menu operations | Playback Function

Scenario

You can view Highlight Scenario that you have saved.

1.  - [Playback Function] - [ Scenario].

Note

- This function is available only when [ File Format] is set to [ AVCHD].

[135] How to Use | Menu operations | Edit/Copy

Send to Smartphone

Transfer images recorded with this product to your smartphone.

1. Press the  button on this product to enter the playback mode.
2. [MENU] - [Edit/Copy] - [Send to Smartphone].

[136] How to Use | Menu operations | Edit/Copy

View on TV

You can view images on your TV that is compatible with the network function by transferring images from this product without connecting this product and TV with a cable. Operations may be required on your TV before playing depending on the TV you use. For details, refer to the instruction manuals of the TV.

1. Press  on this product to enter the playback mode.
2. [MENU] - [Edit/Copy] - [View on TV].

[137] How to Use | Menu operations | Edit/Copy

Send to Computer

Transfer images recorded with this product to your computer.

1. Press the  button on this product to enter the playback mode.
2. [MENU] - [Edit/Copy] - [Send to Computer].

Delete

You can delete unnecessary images.

1. Press the  button on this product to enter the playback mode.
2. On the Event View screen, select , and then select the movie format you want to delete.
 - Another icon may appear instead of  depending on the [ File Format] setting and the movie playback format.
3.  - [Edit/Copy] - [Delete] - desired setting.

Descriptions of menu items

Multiple Images :

You can select images to be deleted. Select the type of image you want to delete, then add  to the desired images, and then select .

All In Event :

You can delete all images in the selected date at one time. Select the date you want to delete using /, and then select .

Protect

Protect movies and photos to avoid deleting them by mistake.  will be displayed on the protected images.

1. Press the  button on this product to enter the playback mode.
2. On the Event View screen, select , and then select the movie format you want to protect.
 - Another icon may appear instead of  depending on the [ File Format] setting

and the movie playback format.

3. **MENU** - [Edit/Copy] - [Protect] - desired setting.

Descriptions of menu items

Multiple Images :

You can select images to be protected. Select the type of image you want to protect, then add  to the desired images, and then select **OK**.

Set All In Event :

You can protect all images in the selected date at one time. Select the date you want to protect using /, and then select **OK**.

Remove All In Event :

You can remove the protection from all images in the selected date at one time. Select the date you want to remove the protection using /, and then select **OK**.

Note

- You cannot select multiple dates.

[140] How to Use | Menu operations | Edit/Copy

Direct Copy

You can save images on an external media device manually while the device is connected to this product.

1. Press  (View Images).
2. **MENU** - [Edit/Copy] - [Direct Copy].

Note

- You can perform this operation when this product is connected to an external device.
- This function is not available for [**4K** XAVC S 4K] (FDR-AX100/FDR-AX100E) and [**HD** XAVC S HD] movies.

[141] How to Use | Menu operations | Setup

Media Info

You can check the remaining recordable time and the approximate free and used space of the recording media.

1. **MENU** - [Setup] -  Media Settings] - [Media Info].

Note

- Since there is a management file area, the used space is not displayed as 0% even if you perform [Format].

[142] How to Use | Menu operations | Setup

Format

Formatting deletes all the movies and photos to recover recordable free space.

1. **MENU** - [Setup] -  Media Settings] - [Format] - desired recording medium, and select **OK** .

Note

- Connect this product to a wall outlet (wall socket) using the supplied AC Adaptor for this operation.
- To avoid the loss of important images, you should save them before formatting the recording media.
- Protected movies and photos will also be deleted.
- Make sure not to do the following while [Executing...] is displayed.

Open/Close the LCD monitor.

Operate buttons on this product.

Eject the memory card from this product.

Disconnect the AC Adaptor.

Remove the battery pack.

[143] How to Use | Menu operations | Setup

Repair Img. DB F.

Repair the image database file when necessary, such as when the image database repair message appears.

1. - [Setup] - [ Media Settings] - [Repair Img. DB F.] - desired recording medium, and select .

- To play movie files edited on a computer or other equipment and written back to the recording media, but where no image appears on the Event View screen, perform [Repair Img. DB F.].

[144] How to Use | Menu operations | Setup

File Number

You can select the way to assign file number of photos/MP4 movies.

1. - [Setup] - [ Media Settings] - [File Number] - desired setting.

Descriptions of menu items

Series (default setting):

Assigns file numbers of photos/MP4 movies in sequence. The file number becomes larger each time you record a photo/MP4 movie.

Even if the memory card is replaced with another one, the file number is assigned in sequence.

Reset:

Assigns file numbers in sequence, following the largest file number existing on the recording medium. When the memory card is replaced with another one, the file number is assigned for each memory card.

[145] How to Use | Menu operations | Setup

Data Code

During playback, this product displays the information recorded automatically at the time of recording. You can check the following information.


1. [MENU] - [Setup] - [▶ Playback Settings] - [Data Code] - desired setting.

Descriptions of menu items

Off (default setting):

Data code is not displayed.

Date/Time :




1 Date


2 Time

Camera Data :

Movie



Photo



3 White Balance

4 SteadyShot off

5 Shutter Speed

6 F-stop

7 Gain

8 Brightness

9 Flash

10 Exposure

11 WB B-A/WB G-M

12 ISO

13 WB Color Temp.

Note

- The data code is displayed on the TV screen if you connect this product to a TV.
- Depending on the recording media condition, [-- -- --] may appear.

[146] How to Use | Menu operations | Setup

Volume

You can adjust the volume of playback sound.

1.  - [Setup] - [ Playback Settings] - [Volume] - adjust the volume using  /  .

[147] How to Use | Menu operations | Setup

Download Music (HDR-CX900/FDR-AX100)

You can transfer music files from audio CDs etc., to this product by connecting this product to a computer.

1.  - [Setup] - [ Playback Settings] - [Download Music].

[148] How to Use | Menu operations | Setup

Empty Music (HDR-CX900/FDR-AX100)

You can delete all music files stored on this product.

1.  - [Setup] - [ Playback Settings] - [Empty Music].
-

WPS Push

If your access point has a WPS button, you can register the access point to this product easily.

1. **MENU** - [Setup] - [↔ Connection] - [WPS Push].
2. Press the WPS button on the access point you want to register.


Note

- [WPS Push] requires that the security of the access point be WPA or WPA2 and that the WPS push button method is supported. If the security of your access point is set to WEP or your access point does not support the WPS push button method, register the access point manually.
- For details on the supported functions and settings for your access point, refer to the manual of your access point or contact the administrator of your access point.
- Depending on the surrounding conditions such as obstacles between this product and access point, signal condition and the materials of the wall, etc., connections may not be established or the communication distance may be shorter. Move this product or decrease the distance between this product and the access point.

Access point settings

You can register your access point manually. Before starting the procedure, check the SSID name, security mode, and password of the access point. The password may be preset in some devices. For details, see the access point operating instructions or contact the administrator.

1. **MENU** - [Setup] - [↔ Connection] - [Access point settings].
2. Select the access point you want to register.




The desired access point is displayed:
Select the access point.

The desired access point is not displayed:

Select [Manual setting], then enter the SSID name of the access point, and then select the security mode.

3. Enter the password, and then select [Next] - [Register].



- Access points without the  icon do not require a password to be entered.

Other setting items

Depending on the status or the setting method of your access point, there may be more setting items.

WPS PIN:

Displays the PIN to enter to the connected device.

IP address setting:

Select [Auto] or [Manual].

IP address:

If you are entering the IP address manually, enter the fixed address.

Subnet mask/Default gateway:

When you set [IP address setting] to [Manual], enter the IP address and subnet mask to match your network environment.

Priority Connection:

Select [On] or [Off].

Note

- To give the registered access point priority, set [Priority Connection] to [On].

Hint

- For input method, see “How to use the keyboard.”

You can change the device name for Wi-Fi Direct etc.

1. **MENU** - [Setup] - [**↔** Connection] - [Edit Device Name].
2. Select the input box, input the device name, and then select **OK** .

Hint

- For input method, see “How to use the keyboard.”

[152] How to Use | Menu operations | Setup

Disp MAC Address

Display the MAC address of this product.

1. **MENU** - [Setup] - [**↔** Connection] - [Disp MAC Address].
 - The MAC address is displayed.

[153] How to Use | Menu operations | Setup

SSID/PW Reset

This product shares the SSID/password for [Send to Smartphone] and [Ctrl with Smartphone] with a device that has permission to connect. If you want to change the device that is permitted to connect to this product, reset the SSID/password by the following procedure.

1. **MENU** - [Setup] - [**↔** Connection] - [SSID/PW Reset] - **OK** .

Note

- After resetting the SSID/password, you must set the smartphone again.

[154] How to Use | Menu operations | Setup

Network Info Reset

In addition to the SSID/password, you can also reset the information of the access point, etc. If you want to change the access point to connect to, reset the connection information by the following procedure.

1. **MENU** - [Setup] - [ Connection] - [Network Info Reset].

Note

- After resetting the connection information, you must set the smartphone or the access point again.

[155] How to Use | Menu operations | Setup

TV Type

You need to convert the signal depending on the horizontal to vertical ratio of the TV connected.

1. **MENU** - [Setup] - [ Connection] - [TV Type] - desired setting.

Descriptions of menu items

16:9 (default setting):

Select this to view your movies on a 16:9 (wide) TV.




A: Images recorded in 16:9 (wide) mode

B: Images recorded in 4:3 mode

4:3:

Select this to view your movies and photos on a 4:3 standard TV.



A: Images recorded in 16:9 (wide) mode

B: Images recorded in 4:3 mode

[156] How to Use | Menu operations | Setup

HDMI Resolution

Select the output image resolution when connecting this product to a TV with the HDMI cable.

1. **MENU** - [Setup] - [\rightleftarrows Connection] - [HDMI Resolution] - desired setting.

Descriptions of menu items

Auto (default setting):

Outputs the signal according to the TV automatically.

2160p/1080p (FDR-AX100/FDR-AX100E):

Outputs 4K movies at 2160p and HD movies at 1080p.

1080p:

Outputs the 1080p signal. 4K movies are down-converted to HD before outputting.

1080i:

Outputs the 1080i signal. 4K movies are down-converted to HD before outputting.

720p:

Outputs the 720p signal. 4K movies are down-converted to HD before outputting.

[157] How to Use | Menu operations | Setup

CTRL FOR HDMI

When connecting this product to a BRAVIA Sync compatible TV with an HDMI cable, you can play back movies on this product by aiming the TV's Remote Commander at the TV.

1. **MENU** - [Setup] - [↔ Connection] - [CTRL FOR HDMI] - desired setting.

Descriptions of menu items

On (default setting):

Operates this product using the TV's Remote Commander.

Off:

Does not operate this product using the TV's Remote Commander.

[158] How to Use | Menu operations | Setup

USB Connect

Select this item if a USB connection does not start even when you connect this product to an external device with the Built-in USB Cable.

1. **MENU** - [Setup] - [↔ Connection] - [USB Connect].

[159] How to Use | Menu operations | Setup

USB Connect Setting

You can set the USB transfer mode for connecting this product to a computer or other USB device.

1. **MENU** - [Setup] - [↔ Connection] - [USB Connect Setting] - desired setting.

Descriptions of menu items

Auto (default setting):

This product automatically selects the USB transfer mode depending on the connected device.

MTP:

This is a USB transfer mode compatible with certain types of computers.

Mass Storage:

This is a USB transfer mode compatible with many types of USB devices.

Note

- When this product is connected to an external device in the [MTP] mode, image files will be displayed with the recorded date, however, some information included in the image files cannot be displayed on the connected device. To import images from this product to your computer, use the PlayMemories Home software.
- If the “Device Stage**” window does not open when you connect this product to a computer equipped with Windows 7 or Windows 8, set [USB Connect Setting] to [Auto].

*“Device Stage” is a menu of Windows 7 or Windows 8, that is used to manage devices (camcorder, camera, etc.) that are connected to the computer.

[160] How to Use | Menu operations | Setup

USB Power Supply

Set whether to use USB power supplied function when this product is connected to a USB device such as a computer.

Attach the supplied battery pack to this product.

1. **[MENU]** - [Setup] - [ Connection] - [USB Power Supply].

Descriptions of menu items

On (default setting):

Power is supplied when connected using the Built-in USB Cable.

Off :

Does not supply power when connected using the Built-in USB Cable.

Note

- This operation may consume the battery power.
- It is recommended that you connect a USB device that is compatible with the 1,500 mA power supply standard.

[161] How to Use | Menu operations | Setup

USB LUN Setting

Improves compatibility with external devices by limiting the functions of the USB connection.

1. **MENU** - [Setup] - [ Connection] - [USB LUN Setting] - desired setting.

Descriptions of menu items

Multi (default setting):

Use this setting for ordinary operations.

Single:

Try this setting only if you cannot connect to an external device.

[162] How to Use | Menu operations | Setup

Beep

You can turn on or off the melody which sounds when you start/stop recording, or operate this product.

1. **MENU** - [Setup] - [ General Settings] - [Beep] - desired setting.

Descriptions of menu items

On (default setting):

A melody sounds.

Off:

Cancels the melody.

[163] How to Use | Menu operations | Setup

Monitor Brightness

You can adjust the brightness of the LCD monitor.

1. **MENU** - [Setup] - [ General Settings] - [Monitor Brightness] - desired setting.

Descriptions of menu items

Normal (default setting):

Normal setting (normal brightness).

Bright :

Select this when the LCD monitor is not bright enough. This adjustment does not affect the recorded images in any way.

- When using the AC Adaptor, [Monitor Brightness] is set to [Bright] automatically.

[164] How to Use | Menu operations | Setup

Display Setting

You can set the duration of displaying the icons or indicators on the LCD monitor while recording.

1. **MENU** - [Setup] - [ General Settings] - [Display Setting] - desired setting.

Descriptions of menu items

Auto (default setting):

Displays for about 3 seconds.

The rec and zoom buttons on the LCD monitor are displayed.

On :

Always displays. The rec and zoom buttons on the LCD monitor are not displayed.

Note

- You cannot change the setting of the icons or indicators on the LCD monitor while in playback mode.

[165] How to Use | Menu operations | Setup

Airplane Mode

When you board an airplane, you can deactivate the Wi-Fi function temporarily.

1. **MENU** - [Setup] - [ General Settings] - [Airplane Mode] - desired setting.

Descriptions of menu items

Off (default setting):

Normal setting.

On (✈):

Use the setting when you are on board an airplane.

[166] How to Use | Menu operations | Setup

REC Lamp

You can make the camera recording lamp on the front of this product not to turn on.

1. [MENU] - [Setup] - [🔧 General Settings] - [REC Lamp] - desired setting.

Descriptions of menu items

On (default setting):

The camera recording lamp lights up.

Off :

The camera recording lamp does not light up.

[167] How to Use | Menu operations | Setup

Remote Ctrl

You can lock the Wireless Remote Commander buttons to prevent accidental operation by remote controls for other devices.

1. [MENU] - [Setup] - [🔧 General Settings] - [Remote Ctrl] - desired setting.

Descriptions of menu items

On (default setting):

Select this when you use the supplied Wireless Remote Commander.

Off:

Select this when you do not use supplied Wireless Remote Commander.

Language Setting

You can select the language to be used on the LCD monitor.

1. **MENU** - [Setup] - [ General Settings] - [Language Setting] - desired language.

24p Mode (HDR-CX900E/FDR-AX100E)

You can record 24p movies with changing the signal format.

1. **MENU** - [Setup] - [ General Settings] - [24p Mode] - **OK**.
If you want to return the system to 50i mode, select **OK** in the [Cancel 24p Mode] screen.

Note

- This product reboots each time you change the setting.
- When you change the setting, formatting the recording media is required.
- When you select [24p Mode], the following settings will be limited.

The movie recording format is limited to AVCHD 24p (FX, FH), XAVC S HD 24p and XAVC S 4K 24p (FDR-AX100E).

Depending on the connected TV, images may not be played back normally because the video signal output from this product is in the NTSC format.

You cannot set [ Frame Rate].

Cancel 24p Mode (HDR-CX900E/FDR-AX100E)

Return the system to 50i mode by canceling 24p mode.

1. **MENU** - [Setup] - [ General Settings] - [Cancel 24p Mode] - **OK**.

Calibration

Use this function if the buttons on the touch panel does not work correctly.

1. **MENU** - [Setup] - [ General Settings] - [Calibration].
2. Touch “x” displayed on the LCD monitor with the corner of memory card or the like 3 times.



Note

- If you did not press the right spot, try the calibration again.
- Do not use a sharp-pointed object for calibration. Doing so may damage the LCD monitor.
- You cannot calibrate the LCD monitor if it is rotated, or closed with the LCD monitor facing out.

Hint

- Select [Cancel] to cancel calibration.

Battery Info

You can check the estimated remaining capacity of the battery pack.

1. **MENU** - [Setup] - [ General Settings] - [Battery Info].

Power Save

You can change the settings for the backlight of the LCD monitor and the power status of this product.

1. **MENU** - [Setup] - [ General Settings] - [Power Save].

Descriptions of menu items

Standard (default setting):

The backlight of the LCD monitor turns dark automatically if you do not attempt to operate this product for more than about 1 minute. This product turns off automatically if you do not attempt to operate this product for more than about 2 minutes.

Max :

The brightness of the LCD monitor is adjusted to the surrounding brightness automatically. The backlight of the LCD monitor turns dark automatically if you do not attempt to operate this product for more than about 15 seconds. This product turns off automatically if you do not attempt to operate this product for more than about 1 minute.

Off :

The backlight of the LCD monitor is always on brightly. This product does not turn off automatically.

Note

- This setting works only when using the battery pack.

[174] How to Use | Menu operations | Setup

Initialize

All the settings return to the default.

1. **MENU** - [Setup] - [ General Settings] - [Initialize] - **OK** .

Hint

- Even if you use this function, all movies and photos are retained.
-

Date & Time Setting

Set the date & time settings.

1. **MENU** - [Setup] - [🕒 Clock Settings] - [Date & Time Setting] - desired setting.

Descriptions of menu items

Date & Time Format:

You can select the order of year, month and day displayed.

Daylight Savings/Summer Time:

Sets the summertime. The clock is set to move the time forward 1 hour.

Date & Time:

You can set the clock.

Area Setting

You can adjust a time difference without stopping the clock. Select your local area when using this product in other time zones.

1. **MENU** - [Setup] - [🕒 Clock Settings] - [Area Setting] - [Home] - desired setting.

Hint

- You can set another place as a [Destination].
-

Charging time

Approximate time (min.) required when you fully charge a fully discharged battery pack.

When using the AC Adaptor

HDR-CX900/HDR-CX900E

NP-FV50 (supplied):

140 min

NP-FV70 :

205 min

NP-FV100 :

360 min

When using the AC Adaptor

FDR-AX100/FDR-AX100E

NP-FV70 (supplied):

205 min

NP-FV100

360 min

When using your computer

HDR-CX900/HDR-CX900E

NP-FV50 (supplied):

305 min

NP-FV70 :

555 min

NP-FV100 :

930 min

When using your computer

FDR-AX100/FDR-AX100E

NP-FV70 (supplied):

555 min

NP-FV100 :

930 min

Hint

- The charging times shown in the table above are measured when charging this product at a temperature of 25 °C (77 °F). It is recommended that you charge the battery in a temperature range of 10 °C to 30 °C (50 °F to 86 °F).

The charging times are measured without using the USB Connection support cable.

[178] How to Use | Charging time/recording time of movies/number of recordable photos | Expected recording and playback times for individual batteries

Expected recording time with each battery pack

Approximate recording time with each battery pack is shown as follows.

Continuous recording time

HDR-CX900/HDR-CX900E

NP-FV50 (supplied):

105 min

115 min

NP-FV70 :

220 min

240 min

NP-FV100 :

440 min

485 min

FDR-AX100/FDR-AX100E

NP-FV70 (supplied):

135 min

145 min

NP-FV100 :

270 min

290 min

Typical recording time

HDR-CX900/HDR-CX900E

NP-FV50 (supplied):

50 min

55 min

NP-FV70 :

110 min

120 min

NP-FV100 :

220 min

240 min

FDR-AX100/FDR-AX100E

NP-FV70 (supplied):

65 min

70 min

NP-FV100 :

135 min

145 min

Top:

When the LCD monitor is opened

Bottom:

When recording with the viewfinder without opening the LCD monitor

Hint

- Recording times are those at the default settings.

When [File Format] is set to [4K] XAVC S 4K and [Frame Rate] is set to 30p(*)/25p(**)
(FDR-AX100/FDR-AX100E)

When [File Format] is set to [HD] AVCHD and [REC Mode] is set to [Standard HQ] (HDR-
CX900/HDR-CX900E)

* Models with the NTSC color system

** Models with the PAL color system

- Typical recording time shows the time when you repeat recording start/stop, switching the [Shooting Mode], and zooming.
- Times measured when using this product at 25 °C (77 °F). 10 °C to 30 °C (50 °F to 86 °F) is recommended.
- The recording and playback time will be shorter, depending on the conditions under which you use this product, such as when use this product in low temperatures.

[179] How to Use | Charging time/recording time of movies/number of recordable photos | Expected recording and playback times for individual batteries

Expected playback time with each battery pack

Approximate playback time with each battery pack is shown as follows.

HDR-CX900/HDR-CX900E

NP-FV50 (supplied):

135 min

145 min

NP-FV70 :

280 min

300 min

NP-FV100 :

555 min

600 min

FDR-AX100/FDR-AX100E

NP-FV70 (supplied):

180 min

185 min

NP-FV100 :

360 min

375 min

Top:

When the LCD monitor is opened

Bottom:

When recording with the viewfinder without opening the LCD monitor

[180] How to Use | Charging time/recording time of movies/number of recordable photos | Expected movie recording time and number of recordable photos for memory cards

Notes on recording

Read the following precautions regarding recording.

Note

- The recordable time may vary depending on the recording and subject conditions and [ REC Mode].
- You can record movies of a maximum of 9,999 scenes in XAVC S format or 3,999 scenes in AVCHD format. And you can record a maximum of 40,000 MP4 movies and photos collectively.
- The maximum continuous recording time of a movie is approximately 13 hours.
- This product uses the VBR (Variable Bit Rate) format to automatically adjust image quality to

suit the recording scene. This technology causes fluctuations in the recording time of the media. Movies containing quickly moving and complex images are recorded at a higher bit-rate, and this reduces the overall recording time.

[181] How to Use | Charging time/recording time of movies/number of recordable photos | Expected movie recording time and number of recordable photos for memory cards

Expected recording time of movies

The expected recording time of movies when saving on a memory card is shown as follows.

16 GB

60p Quality **PS** (*) / 50p Quality **PS** (**):

[Dual Video REC] is set to [Off]: 1 h 15 min (1 h 15 min)

Highest Quality **FX** :

[Dual Video REC] is set to [On]: 1 h 15 min (1 h 15 min)

[Dual Video REC] is set to [Off]: 1 h 25 min (1 h 25 min)

High Quality **FH** :

[Dual Video REC] is set to [On]: 1 h 40 min (1 h 40 min)

[Dual Video REC] is set to [Off]: 2 h (2 h)

Standard **HQ** :

[Dual Video REC] is set to [On]: 2 h 40 min (2 h 5 min)

[Dual Video REC] is set to [Off]: 3 h 30 min (2 h 40 min)

Long Time **LP** :

[Dual Video REC] is set to [On]: 3 h 50 min (3 h 25 min)

[Dual Video REC] is set to [Off]: 6 h 10 min (5 h)

32 GB

60p Quality **PS** (*) / 50p Quality **PS** (**):

[Dual Video REC] is set to [Off]: 2 h 30 min (2 h 30 min)

Highest Quality **FX** :

[Dual Video REC] is set to [On]: 2 h 35 min (2 h 35 min)

[Dual Video REC] is set to [Off]: 3 h (3 h)

High Quality **FH** :

[Dual Video REC] is set to [On]: 3 h 25 min (3 h 25 min)

[Dual Video REC] is set to [Off]: 4 h 5 min (4 h 5 min)

Standard **HQ** :

[Dual Video REC] is set to [On]: 5 h 20 min (4 h 20 min)

[Dual Video REC] is set to [Off]: 7 h 10 min (5 h 25 min)

Long Time **LP** :

[Dual Video REC] is set to [On]: 7 h 50 min (6 h 50 min)

[Dual Video REC] is set to [Off]: 12 h 20 min (10 h 10 min)

64 GB

4K XAVC S 4K (FDR-AX100/FDR-AX100E):

[Dual Video REC] is set to [On]: 2 h 5 min (2 h 5 min)

[Dual Video REC] is set to [Off]: 2 h 10 min (2 h 10 min)

HD XAVC S HD :

[Dual Video REC] is set to [On]: 2 h 25 min (2 h 25 min)

[Dual Video REC] is set to [Off]: 2 h 35 min (2 h 35 min)

60p Quality **PS** (*) / 50p Quality **PS** (**):

[Dual Video REC] is set to [Off]: 5 h 5 min (5 h 5 min)

Highest Quality **FX** :

[Dual Video REC] is set to [On]: 5 h 15 min (5 h 15 min)

[Dual Video REC] is set to [Off]: 6 h (6 h)

High Quality **FH** :

[Dual Video REC] is set to [On]: 6 h 50 min (6 h 50 min)

[Dual Video REC] is set to [Off]: 8 h 10 min (8 h 10 min)

Standard **HQ** :

[Dual Video REC] is set to [On]: 10 h 45 min (8 h 40 min)

[Dual Video REC] is set to [Off]: 14 h 25 min (10 h 55 min)

Long Time **LP** :

[Dual Video REC] is set to [On]: 15 h 40 min (13 h 50 min)

[Dual Video REC] is set to [Off]: 24 h 50 min (20 h 25 min)

* Models with the NTSC color system

** Models with the PAL color system

Note

- When using a Sony memory card.
 - When recording AVCHD movies with [Audio Mode] set to [5.1ch Surround].
 - The number in () is the minimum recordable time.
-

Expected number of recordable photos

The expected number of images you can save on a memory card is shown as follows.

When recording 20.0 M size of images

16 GB:

1,350 images

32 GB:

2,750 images

64 GB:

5,500 images

When recording 14.2 M size of images

16 GB:

1,850 images

32 GB:

3,750 images

64 GB:

7,400 images

Note

- When using a Sony memory card.
- The number of recordable photos of memory card shown is for the maximum image size of this product. The actual number of recordable photos is displayed on the LCD monitor during recording.
- The number of recordable photos of memory card may vary depending on the recording conditions.
- The unique pixel array of Sony's ClearVid and the image processing system (BIONZ X) allow still image resolution equivalent to the sizes described.

Bit-rate and recording pixels

The following list shows the bit-rate, pixels and aspect ratio of each recording mode for movies

(movie + audio, etc.).

4K XAVC S 4K (FDR-AX100/FDR-AX100E):

Approx. 60 Mbps 3,840 × 2,160 pixels/30p(*), 3,840 × 2,160 pixels/24p(*) or 3,840 × 2,160 pixels/25p(**), 16:9

HD XAVC S HD :

Approx. 50 Mbps 1,920 × 1,080 pixels/60p(*), 1,920 × 1,080 pixels/50p(**), 1,920 × 1,080 pixels/30p(*), 1,920 × 1,080 pixels/24p(*) or 1,920 × 1,080 pixels/25p(**), 16:9

AVCHD:

PS: Max. 28 Mbps 1,920 x 1,080 pixels/60p(*) or 1,920 x 1,080 pixels/50p(**), AVCHD 28 M (PS), 16:9

FX: Max. 24 Mbps 1,920 x 1,080 pixels/60i(*), 1,920 x 1,080 pixels/50i(**), 1,920 x 1,080 pixels/24p(*) or 1,920 x 1,080 pixels/25p(**), AVCHD 24 M (FX), 16:9

FH: Approx. 17 Mbps (average) 1,920 x 1,080 pixels/60i(*), 1,920 x 1,080 pixels/50i(**), 1,920 x 1,080 pixels/24p(*) or 1,920 x 1,080 pixels/25p(**), AVCHD 17 M (FH), 16:9

HQ: Approx. 9 Mbps (average) 1,440 x 1,080 pixels/60i(*) or 1,440 x 1,080 pixels/50i(**), AVCHD 9 M (HQ), 16:9

LP: Approx. 5 Mbps (average) 1,440 x 1,080 pixels/60i(*) or 1,440 x 1,080 pixels/50i(**), AVCHD 5 M (LP), 16:9

MP4:

Approx. 3 Mbps (average) 1,280 x 720 pixels/30p(*), 1,280 x 720 pixels/24p(*) or 1,280 x 720 pixels/25p(**), 16:9

* Models with the NTSC color system

** Models with the PAL color system

[184] How to Use | Charging time/recording time of movies/number of recordable photos | Pixels recorded at each image size of photos

Recording pixels and aspect ratio

The photo recording pixels and the aspect ratio.

Photo recording mode, Dual Capture:

5,968 × 3,352 dots/16:9

4,464 × 3,352 dots/4:3 (*)

5,024 × 2,824 dots/16:9

3,760 × 2,824 dots/4:3 (*)

1,920 × 1,080 dots/16:9

640 × 480 dots/4:3 (*)

*Not available for Dual Capture

Capturing a photo from a movie (models with the USB IN/OUT jacks) :

1,920 × 1,080 dots/16:9

[185] [How to Use](#) | [Additional information](#) | [Precautions](#)

About the AVCHD format

What is the AVCHD format?

The AVCHD format is a high definition digital video camera format used to record a high definition (HD) signal using efficient data compression coding technology. The MPEG-4 AVC/H.264 format is adopted to compress video data, and the Dolby Digital or Linear PCM system is used to compress audio data.

The MPEG-4 AVC/H.264 format is capable of compressing images at higher efficiency than that of the conventional image compressing format.

Hint

- As the AVCHD format uses a compression coding technology, the picture may be disturbed in scenes where picture, field angles or brightness, etc. change drastically, but this is not a malfunction.
-

[186] [How to Use](#) | [Additional information](#) | [Precautions](#)

About the memory card

- A memory card formatted by a computer (Windows OS/Mac OS) is not guaranteed to be compatible with this product.
- Data read/write speed may vary depending on the combination of the memory card and memory card compliant product you use.
- Data may be damaged or lost in the following cases (the data will not be compensated for):
 - If you eject the memory card, or turn off this product while this product is reading or writing image files on the memory card (while the access lamp is lit or flashing)
 - If you use the memory card near magnets or magnetic fields
- It is recommended that you make a back-up of important data on the hard disk of a

computer.

- Do not attach a label or the like on memory card or memory card adaptor.
- Do not touch, or allow metallic objects to come into contact with the terminals.
- Do not bend, drop or apply strong force to the memory card.
- Do not disassemble or modify the memory card.
- Do not allow the memory card to get wet.
- Keep the memory card out of the reach of small children. There is danger that a child might swallow it.
- Do not insert anything other than the compliant size of memory card into the memory card slot. Doing so may cause a malfunction.
- Do not use or keep the memory card in the following locations:
 - Places subject to extremely high temperature, such as a car parked outside in the sun
 - Places under direct sunlight
 - Places with extremely high humidity or subject to corrosive gases

On types of memory card you can use with this product

- You can use only Memory Stick PRO Duo media which is half as large as that of Memory Stick media or a standard sized SD card.

On the memory card adaptor

- If using the memory card adaptor to allow use of a memory card in a device compatible with memory cards, make sure that the memory card is inserted facing in the correct direction. If the memory card is not inserted to the end, it may not work correctly.

On image data compatibility

- Image data files recorded on memory card by this product conform to the “Design rule for Camera File system” universal standard established by the JEITA (Japan Electronics and Information Technology Industries Association).
- If you cannot use memory cards that have been used with another device, format it with this product. Note that formatting erases all information on the memory card.
- You may not be able to play back images with this product:
 - When playing back image data modified on your computer
 - When playing back image data recorded with other devices

About the Memory Stick media

Memory Stick PRO Duo media (Mark2):

Recording/Playback: supported (*)

Memory Stick PRO-HG Duo media :

Recording/Playback: supported (*)

Memory Stick XC-HG Duo media :

Recording/Playback: supported (*)

* Except for XAVC S format

- This product does not support 8-bit parallel data transfer but it supports 4-bit parallel data transfer the same as with Memory Stick PRO Duo media.
- This product cannot record or play back data that uses MagicGate technology. MagicGate is a copyright protection technology that records and transfers the contents in an encrypted format.
- Movies saved on Memory Stick XC-HG Duo media or SDXC memory cards cannot be imported to or played back on computers or AV devices not supporting the exFAT(*) file system by connecting this product to these devices with the USB cable. Confirm in advance that the connecting equipment is supporting the exFAT system. If you connect equipment not supporting the exFAT system and the format screen appears, do not perform the format. All the data saved will be lost.
* The exFAT is a file system that is used for Memory Stick XC-HG Duo media or SDXC memory cards.

[187] How to Use | Additional information | Precautions

About the InfoLITHIUM battery pack

This product operates only with an InfoLITHIUM V series battery packs. InfoLITHIUM V series battery packs have the  mark.

What is an InfoLITHIUM battery pack?

- An InfoLITHIUM battery pack is a lithium-ion battery pack that has functions for communicating information related to operating conditions between this product and an AC Adaptor/charger (sold separately).
- The InfoLITHIUM battery pack calculates the power consumption according to the operating conditions of this product, and displays the remaining battery capacity in minutes.

To charge the battery pack

- Be sure to charge the battery pack before you start using this product.
- We recommend that you charge the battery pack in an ambient temperature range of 10 °C to 30 °C (50 °F to 86 °F) until the POWER/CHG (charge) lamp turns off. If you charge the battery pack outside of this temperature range, you may not be able to charge it efficiently.
- The POWER/CHG (charge) lamp flashes during charging under the following conditions.

The battery pack is not inserted correctly.

The battery pack is damaged.

The temperature of the battery pack is low.

Remove the battery pack from this product and put it in a warm place.

The temperature of the battery pack is high.

Remove the battery pack from this product and put it in a cool place.

To use the battery pack effectively

- Battery pack performance decreases when the ambient temperature is 10 °C (50 °F) or below, and the length of time you can use the battery pack becomes shorter. If that happens, one of the following is recommended to enable longer use of the battery pack:

Put the battery pack in a pocket to warm it up, and install it on this product immediately before you start shooting.

Use a large capacity battery pack.

- Frequent use of the LCD monitor or a frequent playback, fast forward or reverse operation wears out the battery pack faster.
- Be sure to close the LCD monitor when not recording or playing back on this product. The battery pack is also consumed when this product is in recording standby or playback pause.
- Have spare battery packs ready for 2 or 3 times the expected recording time, and make trial recordings before making the actual recording.
- Do not expose the battery pack to water. The battery pack is not water resistant.

About the remaining battery power indicator

- When the power goes off even though the remaining battery power indicator indicates that the battery pack has enough power to operate, charge the battery pack fully again. Remaining battery power will be indicated correctly. Note, however, that the battery indication will not be restored if it is used in high temperatures for a long time, or if left in a fully charged state, or when the battery pack is frequently used.
- Depending on the operating conditions or ambient temperature, the  icon that indicates a low battery may flash even if there are still 20 minutes of power remaining.

About storage of the battery pack

- If the battery pack is not used for a long time, fully charge the battery pack and use it up on this product once a year to maintain proper function. To store the battery pack, remove it from this product and put it in a dry, cool place.
- To discharge the battery pack on this product completely, select **[MENU]** - **[Setup]** -  **[General Settings]** - **[Power Save]** - **[Off]**, and leave this product in recording standby until the power goes off.

About battery life

- Battery capacity decreases over time and through repeated use. If the interval between charges becomes significantly short, the battery pack may need to be replaced with a new

one.

- Each battery's life depends on storage, operating and environmental conditions.

[188] How to Use | Additional information | Handling of this product


On use and care

On recording

- Before starting to record, test the recording function to make sure the image and sound are recorded without any problems.
- Compensation for the contents of recordings cannot be provided, even if recording or playback is not possible due to a malfunction of this product, recording media, etc.
- TV color systems differ depending on the country/region. To view your recordings on a TV, you need a TV that supports the signal format for this product.
- Television programs, films, video tapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to the copyright laws.

LCD monitor

- The LCD monitor is manufactured using extremely high-precision technology, so over 99.99% of the pixels are operational for effective use. However, there may be some tiny black points and/or bright points (white, red, blue, or green in color) that appear constantly on the LCD monitor. These points are normal results of the manufacturing process and do not affect the shooting in any way.



A: White, red, blue or green points

B: Black points


About this Help Guide, illustrations and on-screen displays

- The example images used in this Help Guide for illustration purposes are captured using a digital still camera, and therefore may appear different from images and screen indicators that actually appear on this product. And, the illustrations of this product and its screen indication are exaggerated or simplified for understandability.
- Design and specifications of this product and accessories are subject to change without notice.
- In this Help Guide, DVD discs recorded with high definition image quality (HD) are called

AVCHD disc.

On use and storage place

- This product is not dustproofed, dripproofed or waterproofed.
- Do not hold this product by the following parts, and also do not hold this product by the jack covers.



A: LCD monitor

B: Built-in USB Cable

C: Viewfinder

D: Shoe cover

- Do not aim this product at the sun. Doing so might cause this product to malfunction. Take images of the sun only in low light conditions, such as at dusk.
- Do not use or store this product and accessories in the following locations:
 - Anywhere extremely hot, cold or humid. Never leave them exposed to temperatures above 60 °C (140 °F), such as under direct sunlight, near heaters or in a car parked in the sun. They may malfunction or become deformed.
 - Near strong magnetic fields or mechanical vibration. This product may malfunction.
 - Near strong radio waves or radiation. This product may not be able to record properly.
 - Near tuner devices such as TVs or radio. Noise may occur.
 - On a sandy beach or anywhere dusty. If sand or dust gets in this product, it may malfunction. Sometimes this malfunction cannot be repaired.
 - Near windows or outdoors, where the LCD monitor, the viewfinder, or the lens may be exposed to direct sunlight. This damages the inside of the LCD monitor or the viewfinder.
- For DC or AC operation, use the accessories recommended in these operating instructions.
- Do not let your product get wet, for example, from rain or sea water. If your product gets wet, it may malfunction. Sometimes this malfunction cannot be repaired.
- If any solid object or liquid gets inside the casing, unplug your product and have it checked by a Sony dealer before operating it any further.
- Avoid rough handling, disassembling, modifying, physical shock, or impact such as hammering, dropping or stepping on the product. Be particularly careful with the lens.
- Keep the LCD monitor closed and the viewfinder retracted when you are not using your product.
- Do not operate your product with it wrapped in an object such as a towel.
- When disconnecting the cable, pull it by the plug and not the cord.
- Do not damage the cable such as by placing anything heavy on it.
- Do not use a deformed or damaged battery pack.
- Keep metal contacts clean.
- If the battery electrolytic liquid has leaked:

Consult your local authorized Sony service facility.

Wash off any liquid that may have contacted your skin.

If any liquid gets in your eyes, wash with plenty of water and consult a doctor.

When not using this product for a long time

- To keep this product in optimum state for a long time, turn it on and let it run by recording and playing back images about once a month.
- Use up the battery pack completely before storing it.

Note on this product/battery pack temperature

- When the temperature of this product or battery pack becomes extremely high or extremely low, you may not be able to record or play back on this product, due to the protection features of this product being activated in such situations. In this case, an indicator appears on the LCD monitor or the viewfinder.

Notes on charging through the Built-in USB Cable

- Charging may not be possible with all computers.
- If you connect this product to a laptop computer that is not connected to a power source, the battery of the laptop computer will continue to use up its charge. Do not leave this product connected to a computer in this manner.
- Charging with a personally assembled computer, with a converted computer, or through a USB hub are not guaranteed. This product may not function correctly depending on the USB device which is used with the computer.

LCD monitor

- Do not apply excessive pressure on the LCD monitor, as it may cause uneven color and other damage.
- If this product is used in a cold place, a residual image may appear on the LCD monitor. This is not a malfunction.
- While using this product, the back of the LCD monitor may heat up. This is not a malfunction.

Multi interface shoe

- When using a dedicated microphone or portable speaker, their power turns on or off according to the power of this product.
- Refer to the operating instructions supplied with the accessory used for details.
- To attach an accessory, insert and fix the accessory to the Multi interface shoe by pressing down and sliding forward until it stops. Remove the accessory by pressing it down.
- When you are recording movies with an external flash (sold separately) connected to the Multi interface shoe, turn off the power of the external flash to prevent charging noise from being recorded.
- When an external microphone (sold separately) is connected, it takes precedence over the built-in microphone.

ZEISS lens

- This product is equipped with a ZEISS lens, which was developed jointly by ZEISS, in Germany, and Sony Corporation, and produces superior images. It adopts the MTF(*) measurement system for video cameras and offers a quality typical of a ZEISS lens.
- Also, the lens for this product is T*-coated to suppress unwanted reflections and faithfully reproduce colors.

* MTF= Modulation Transfer Function. The number value indicates the amount of light from a subject coming into the lens.

On the pre-installed rechargeable battery

- This product has a pre-installed rechargeable battery to retain the date, time, and other settings even when the LCD monitor is closed. The pre-installed rechargeable battery is always charged while this product is connected to a wall outlet (wall socket) via the AC Adaptor or while the battery pack is inserted. The rechargeable battery will be fully discharged in about 2 months if you do not use this product at all. Charge the pre-installed rechargeable battery before you start using this product. However, even if the pre-installed rechargeable battery is not charged, this product operation other than date recording will not be affected.

How to charge the pre-installed rechargeable battery

Connect this product to a wall outlet (wall socket) using the supplied AC Adaptor, and leave it with the LCD monitor closed for more than 24 hours.

[189] [How to Use](#) | [Additional information](#) | [Handling of this product](#)

On connecting to a computer or accessory etc.

- Do not try to format the recording media of this product with a computer. If you do so, this product may not operate correctly.
- When connecting this product to another device with communication cables, be sure to insert the connector plug in the correct way. Pushing the plug forcibly into the terminal will damage the terminal and may result in a malfunction of this product.
- When this product is connected to other devices through a USB connection and the power of this product is turned on, do not close the LCD monitor. The image data that has been recorded may be lost.

[190] [How to Use](#) | [Additional information](#) | [Handling of this product](#)

Notes on optional accessories

- We recommend using genuine Sony accessories.
 - Genuine Sony accessories may not be available in some countries/regions.
-

[191] How to Use | Additional information | Handling of this product

On moisture condensation

If this product is brought directly from a cold place to a warm place, moisture may condense inside this product. This may cause a malfunction to this product.

If moisture condensation occurs

Leave this product for about 1 hour without turning it on.

Where moisture condensation frequently occurs

Moisture may condense when you bring this product from a cold place into a warm place (or vice versa) or when you use this product in a humid place as follows:

- You bring this product from a ski slope into a place warmed up by a heating device.
- You bring this product from an air conditioned car or room into a hot place outside.
- You use this product after a squall or a rain.
- You use this product in a hot and humid place.

How to prevent moisture condensation

When you bring this product from a cold place into a warm place, put this product in a plastic bag and seal it tightly. Remove the bag when the air temperature inside the plastic bag has reached the surrounding temperature (after about 1 hour).

[192] How to Use | Additional information | Handling of this product

Note on disposal/transfer of the memory card


Even if you delete data in the memory card or format the memory card on this product or a computer, you may not delete data from the memory card completely. When you give the memory card to somebody, it is recommended that you delete data completely using data deletion software on a computer. Also, when you dispose of the memory card, it is

recommended that you destroy the actual body of the memory card.

[193] How to Use | Additional information | Handling of this product

Notes on the Wireless Remote Commander

Remove the insulation sheet before using the Wireless Remote Commander.



- Point the Wireless Remote Commander towards the remote sensor to operate this product.
- When no commands have been sent from the Wireless Remote Commander within a certain period, the light blue frame disappears. When you press any of ▲ / ▼ / ◀ / ▶ , or ENTER again, the frame appears at the position where it was last displayed.
- You cannot select some buttons on the LCD monitor or on the viewfinder using ▲ / ▼ / ◀ / ▶ .

To change the battery of the Wireless Remote Commander

1. While pressing on the tab, inset your fingernail into the slit to pull out the battery case.
2. Place a new battery with the + side facing up.
3. Insert the battery case back into the Wireless Remote Commander until it clicks.



- When the lithium battery becomes weak, the operating distance of the Wireless Remote Commander may shorten, or the Wireless Remote Commander may not function properly. In this case, replace the battery with a Sony CR2025 lithium battery. Use of another battery may present a risk of fire or explosion.

[194] How to Use | Additional information | Maintenance

On handling the LCD monitor

- If you leave fingerprints, hand cream, etc. on the LCD monitor, the coating of the LCD monitor will come off easily. Wipe those off as soon as possible.
 - If you wipe the LCD monitor strongly with a tissue, etc., the coating of the LCD monitor may be scratched.
 - If the LCD monitor becomes dirty with fingerprints or dust, it is recommended that you gently remove those from the screen then clean it with a soft cloth, etc.
-

[195] [How to Use](#) | [Additional information](#) | [Maintenance](#)

To clean the casing surface

- Wipe the casing with a soft cloth such as a cleaning cloth or eyeglass cleaning cloth.
 - If the casing is very dirty, clean the casing of this product with a soft cloth lightly moistened with water, and then wipe the casing with a dry soft cloth.
 - Avoid the following so as not to deform the casing, damage the finish or scratch the lens:
 - Using chemicals such as thinner, benzine, alcohol, chemical cloths, insect repellent, insecticide and sunscreen
 - Handling this product with the above substances on your hands
 - Leaving this product in contact with rubber or vinyl objects for a long period of time
-

[196] [How to Use](#) | [Additional information](#) | [Maintenance](#)

About care and storage of the lens

- Wipe the surface of the lens clean with a soft cloth in the following instances:
 - When there are fingerprints on the lens surface
 - In hot or humid locations
 - When the lens is exposed to salty air such as at the seaside
 - Store in a well-ventilated location subject to little dirt or dust.
 - To prevent mold, periodically clean and store the lens as described above.
-

[197] [How to Use](#) | [Additional information](#) | [Using this product abroad](#)

Using this product abroad

Power supply

- You can use this product in any countries/regions using the AC Adaptor supplied with this product within the AC 100 V to 240 V, 50 Hz/60 Hz range. You can also charge the battery pack.

Viewing images on a TV connected

- To view images on a TV (or monitor), you need to connect this product to a TV (or monitor) using the HDMI cable (supplied) or AV cable (sold separately). Refer to “On TV color systems” for countries and regions where the playback signal format of this product is supported.

Viewing images in 4K (models with the 4K functionality)

- To view 4K images in 4K, you need the HDMI cable and a 4K compatible TV (or a monitor). Refer to “On TV color systems” for countries and regions where the playback signal format of this product is supported.

Viewing high definition image quality (HD) movies

- In countries/regions where high definition image quality (HD) broadcasts are supported, you can view recorded movies on a TV at the same high definition image quality (HD) as they were recorded with this product.

To view images at the same high definition image quality (HD) as they were recorded with this product, you need the HDMI cable and a high definition TV (or monitor) that supports the signal format for this product and is equipped with an HDMI jack.

On TV color systems

- For signal formats supported by this product, refer to “Model Information.” To view images in this product on TV, use a TV (or monitor) that supports the signal format of this product.

PAL:

Australia, Austria, Belgium, China, Czech Republic, Denmark, Finland, Germany, Holland, Hong Kong, Hungary, Italy, Kuwait, Malaysia, New Zealand, Norway, Poland, Portugal, Singapore, Slovak Republic, Spain, Sweden, Switzerland, Thailand, United Kingdom, etc.

PAL-M:

Brazil

PAL-N:

Argentina, Paraguay, Uruguay

NTSC:

Bahama Islands, Bolivia, Canada, Central America, Chile, Colombia, Ecuador, Guyana, Jamaica, Japan, Korea, Mexico, Peru, Surinam, Taiwan, the Philippines, the USA, Venezuela, etc.

SECAM:

Bulgaria, France, Guiana, Iran, Iraq, Monaco, Russia, Ukraine, etc.

Setting to the local time

- You can easily set the clock to the local time by setting a time difference when using this product abroad. Select **MENU** - [Setup] - [Clock Settings] - [Daylight Savings] or [Summer Time], and **MENU** - [Setup] - [Clock Settings] - [Area Setting].

[198] How to Use | Additional information | Using this product abroad

World time difference

The time difference for cities worldwide is shown as follows.

GMT:

Lisbon/London

+01:00:

Berlin/Paris

+02:00:

Helsinki/Cairo/Istanbul

+03:00:

Nairobi

+03:30:

Tehran

+04:00:

Moscow/Abu Dhabi/Baku

+04:30:

Kabul

+05:00:

Karachi/Islamabad

+05:30:

Kolkata/New Delhi

+06:00:

Almaty/Dhaka

+06:30:

Yangon

+07:00:

Bangkok/Jakarta

+08:00:

HongKong/Singapore/Beijing

+09:00:

Tokyo/Seoul

+09:30:

Adelaide/Darwin

+10:00:

Melbourne/Sydney

+11:00:

Solomon Is

+12:00:

Fiji/Wellington

-11:00:

Midway Island

-10:00:

Hawaii

-09:00:

Alaska

-08:00:

LosAngeles/Tijuana

-07:00:

Denver/Arizona

-06:00:

Chicago/MexicoCity

-05:00:

New York/Bogota

-04:00:

Santiago

-03:30:

St. John's

-03:00:

Brasilia/Montevideo

-02:00:

Fernando de Noronha

-01:00:

On trademarks

- Handycam and **HANDYCAM** are registered trademarks of Sony Corporation.
- AVCHD, AVCHD logotype, AVCHD Progressive and AVCHD Progressive logotype are trademarks of Panasonic Corporation and Sony Corporation.
- PlayMemories Home, the PlayMemories Home logo, PlayMemories Online, the PlayMemories Online logo, PlayMemories Mobile and the PlayMemories Mobile logo are trademarks of Sony Corporation.
- Memory Stick,  , Memory Stick Duo, **MEMORY STICK DUO**, Memory Stick PRO Duo, **MEMORY STICK PRO DUO**, Memory Stick PRO-HG Duo, **MEMORY STICK PRO-HG DUO**, Memory Stick XC-HG Duo, **MEMORY STICK XC-HG DUO**, MagicGate, **MAGICGATE**, MagicGate Memory Stick and MagicGate Memory Stick Duo are trademarks or registered trademarks of Sony Corporation.
- InfoLITHIUM is a trademark of Sony Corporation.
- BIONZ X is a trademark of Sony Corporation.
- BRAVIA and Photo TV HD are trademarks of Sony Corporation.
- Blu-ray Disc™ and Blu-ray™ are trademarks of the Blu-ray Disc Association.
- Dolby and the double-D symbol are trademarks of Dolby Laboratories.
- The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.
- Microsoft, Windows, Windows Vista, and DirectX are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Mac is a registered trademarks of Apple Inc. in the United States and other countries.
- iPhone and iPad are trademarks of Apple Inc., registered in the U.S. and other countries.
- iOS is a registered trademark or trademark of Cisco Systems, Inc.
- Intel, Pentium and Intel Core are trademarks of Intel Corporation in the U.S. and/or other countries.
- Android and Google Play are trademarks of Google Inc.
- Wi-Fi, the Wi-Fi logo, Wi-Fi PROTECTED SET-UP, Wi-Fi Direct, WPA and WPA2 are registered trademarks of the Wi-Fi Alliance.
- DLNA and DLNA CERTIFIED are trademarks of Digital Living Network Alliance.
- The N mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.

- “” and “PlayStation” are registered trademarks of Sony Computer Entertainment Inc.
- SDXC logo is a trademark of SD-3C, LLC.
- Facebook and the “f” logo are trademarks or registered trademarks of Facebook, Inc.
- YouTube and the YouTube logo are trademarks or registered trademarks of Google Inc.
- Other system names and product names mentioned in this Help Guide are generally registered trademarks or trademarks of respective developers. Note that ™ and ® are not always used in this Help Guide.



Add further enjoyment with your PlayStation 3 by downloading the application for PlayStation 3 from PlayStation Store (where available.)

The application for PlayStation 3 requires PlayStation Network account and application download. Accessible in areas where the PlayStation Store is available.

[200] How to Use | Additional information | License

Notes on the License

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO

(i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD (“AVC VIDEO”) AND/OR
(ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO.

NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE.

ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C.

SEE <[HTTP://WWW.MPEGLA.COM](http://www.mpegla.com)>

We provide the software in this product based on license agreements with the owners of the respective copyrights. Based on requests by the owners of copyright of these software applications, we have an obligation to inform you of the following. Please read the following sections.

Copies of the licenses (in English) are stored in the internal memory of this product. Establish a Mass Storage connection between this product and a computer, and read the files in the “LICENSE” folder in “PMHOME.”

On GNU GPL/LGPL applied software

The software that is eligible for the following GNU General Public License (hereinafter referred to as “GPL”) or GNU Lesser General Public License (hereinafter referred to as “LGPL”) are included in this product.

This informs you that you have a right to have access to, modify, and redistribute source code for these software programs under the conditions of the supplied GPL/LGPL.

Source code is provided on the web. Use the following URL to download it. When downloading the source code, select FDR-AX100/HDR-CX900 as the model for this product.

<http://www.sony.net/Products/Linux/>

We would prefer you do not contact us about the contents of source code.

Copies of the licenses (in English) are stored in the internal memory of this product. Establish a Mass Storage connection between this product and a computer, and read the files in the "LICENSE" folder in "PMHOME."

[201] How to Use | Additional information | Zoom magnifications

Zoom magnifications

When recording a movie with  SteadyShot set to [Active] ([Clear Image Zoom])

4K (FDR-AX100/FDR-AX100E):

18 times

HD:

24 times

When recording a movie or photo with  SteadyShot set to [Standard] or [Off]

12 times

When [Digital Zoom] is set to [160x]

160 times

[202] Troubleshooting | Troubleshooting | If you have problems

If you have problems

If you run into any problems using this product, follow the steps below.

1. Check the items under "Troubleshooting," and inspect this product.
2. Disconnect the power source, attach the power source again after about 1 minute, and

turn this product on.

3. Perform [Initialize].

- If you select [Initialize], all settings, including the clock setting, are reset.

4. Contact your Sony dealer or local authorized Sony service facility.

[203] Troubleshooting | Troubleshooting | Overall operations

The power does not turn on.

- Attach a charged battery pack to this product.
- The plug of the AC Adaptor has been disconnected from a wall outlet (wall socket). Connect it to a wall outlet (wall socket).

[204] Troubleshooting | Troubleshooting | Overall operations

This product does not operate even when the power is set to on.

- Disconnect the AC Adaptor from a wall outlet (wall socket) or remove the battery pack, then reconnect it after about 1 minute.

[205] Troubleshooting | Troubleshooting | Overall operations

The menu settings have been changed automatically.

- While Intelligent Auto is active, some menu settings related to image quality will be changed automatically.
- The following menu items return to the default settings when you switch between movie recording, photo recording and playback modes.

[ Fader]

[ Self-Timer]

[206] Troubleshooting | Troubleshooting | Overall operations

This product gets warm.

- This product may become warm during operation. This is not a malfunction.
-

[207] Troubleshooting | Troubleshooting | Overall operations

Intelligent Auto is canceled.

- The Intelligent Auto setting is canceled if you change the following settings:

- [Smth Slw REC]
- [Golf Shot]
- [High Speed REC]
- [White Balance]
- [Spot Meter/Fcs]
- [Spot Meter]
- [Spot Focus]
- [Exposure]
- [Focus]
- [AGC Limit]
- [AE Shift]
- [Low Lux]
- [Scene Selection]
- [Picture Effect]
- [ Cinematone]
- [Auto Wind NR]
- [ SteadyShot]
- [Auto Back Light]
- [Face Detection]
- IRIS
- Shutter Speed
- Gain (ISO)

[208] Troubleshooting | Troubleshooting | Batteries/power sources

The power abruptly turns off.

-
- Use the AC Adaptor.
 - In the default setting, this product turns itself off when no operations are performed for more than about 2 minutes ([Power Save]). Change the setting of [Power Save], or turn on the power again.
 - Charge the battery pack.
-

[209] Troubleshooting | Troubleshooting | Batteries/power sources

The POWER/CHG (charge) lamp does not light while the battery pack is being charged.

- Turn off this product.
 - Attach the charged battery pack to this product correctly.
 - Connect the power cord (mains lead) to a wall outlet (wall socket) properly.
 - The battery charge is completed.
-

[210] Troubleshooting | Troubleshooting | Batteries/power sources

The POWER/CHG (charge) lamp flashes while the battery pack is being charged.

- When the battery is being charged using the Built-in USB Cable, disconnect the Built-in USB Cable and connect it again.
 - If the temperature of the battery pack is too high or too low, you may not be able to charge it.
 - Attach the charged battery pack to this product correctly. If the problem persists, disconnect the AC Adaptor from a wall outlet (wall socket) and contact your Sony dealer. The battery pack may be damaged.
-

[211] Troubleshooting | Troubleshooting | Batteries/power sources

The remaining battery power is not displayed correctly.

- The ambient temperature is too high or too low. This is not a malfunction.
 - The battery pack has not been charged enough. Fully charge the battery again. If the problem persists, replace the battery pack with a new one.
 - The indicated remaining battery power may not be correct depending on the environment in which this product is used.
-

[212] Troubleshooting | Troubleshooting | Batteries/power sources

The battery pack is quickly discharged.

- The ambient temperature is too high or low. This is not a malfunction.
 - The battery pack has not been charged enough. Fully charge the battery again. If the problem persists, replace the battery pack with a new one.
-

[213] Troubleshooting | Troubleshooting | Monitor

Menu items are grayed out.

- You cannot select grayed out items in the current recording/playback situation.
 - There are some functions you cannot activate simultaneously.
-

[214] Troubleshooting | Troubleshooting | Monitor

The buttons do not appear on the LCD monitor.

- Touch the LCD monitor lightly.
-

[215] Troubleshooting | Troubleshooting | Monitor

The buttons on the touch panel do not work correctly or do not work at all.

- Adjust the touch panel ([Calibration]).
-

[216] Troubleshooting | Troubleshooting | Monitor

The buttons on the LCD monitor quickly disappear.

- If you set [Display Setting] to [On], the buttons do not disappear from the LCD monitor.
-

[217] Troubleshooting | Troubleshooting | Monitor

There are dots in the shape of a grid on the monitor.

- These dots are a normal result of the manufacturing process of the monitor and do not affect the recording in any way.
-

[218] Troubleshooting | Troubleshooting | Monitor

The backlight of the LCD monitor turns off if you do not attempt to operate this product for a while.

- In the default setting, the backlight of the LCD monitor turns off automatically if you do not attempt to operate this product for more than about 1 minute ([Power Save]).
-

[219] Troubleshooting | Troubleshooting | Viewfinder

The image in the viewfinder is not clear.

- Move the viewfinder lens adjustment dial until the image appears clearly.
-

[220] Troubleshooting | Troubleshooting | Viewfinder

The image in the viewfinder is no-longer displayed.

- Close the LCD monitor. Even if the viewfinder is pulled out, no image is displayed in the viewfinder when the LCD monitor is open.
-

[221] Troubleshooting | Troubleshooting | Memory card

Operations using the memory card cannot be performed.

- If you use the memory card formatted on a computer, format it again on this product.
 - When you select XAVC S format in [ File Format], use an SDXC memory card Class 10 or faster.
-

[222] Troubleshooting | Troubleshooting | Memory card

Images stored on the memory card cannot be deleted.

- The maximum number of images that you can delete on the index screen at one time is 100.
 - You cannot delete the protected images.
-

[223] Troubleshooting | Troubleshooting | Memory card

The data file name is not indicated correctly or flashes.

- The file is damaged.
 - The file format is not supported by this product.
-

[224] Troubleshooting | Troubleshooting | Memory card

Images cannot be played back or the memory card is not recognized.

-
- The playback device does not support playing back memory cards.

[225] Troubleshooting | Troubleshooting | Wireless Remote Commander

The supplied Wireless Remote Commander does not function.

-
- Set [Remote Ctrl] to [On].
 - Insert a battery into the battery holder with the +/- polarities correctly matching the +/- marks.
 - Remove any obstructions between the Wireless Remote Commander and the remote sensor.
 - Point the remote sensor away from strong light sources such as direct sunlight or overhead lighting. Otherwise, the Wireless Remote Commander may not function properly.

[226] Troubleshooting | Troubleshooting | Wireless Remote Commander

Another DVD device operates when you use the supplied Wireless Remote Commander.

-
- Select a commander mode other than DVD 2 for your DVD device, or cover the sensor of your DVD device with black paper.

[227] Troubleshooting | Troubleshooting | Recording

Pressing START/STOP or PHOTO does not record images.

-
- The playback screen is displayed. Stop playback, and select MENU - [Shooting Mode] - [Movie] or [Photo].
 - This product is recording the image you have just shot on the recording media. You cannot make new recording during this period.

- The recording media is full. Delete unnecessary images.
 - Total number of movie scenes or photos exceeds the recordable capacity of this product. Delete unnecessary images.
-

[228] Troubleshooting | Troubleshooting | Recording

Photos cannot be recorded.

- You cannot record photos together with:
 - [Smth Slw REC]
 - [Golf Shot]
 - [High Speed REC]
 - [ Fader]
 - When [Dual Video REC] is set to [On], you cannot shoot photos while recording a movie in movie recording mode.
 - This product cannot shoot photos while it is in movie recording mode, depending on the [ REC Mode] or [ Frame Rate] selected.
 - When you select a [Picture Effect] item, you cannot record photos in the movie recording mode.
-

[229] Troubleshooting | Troubleshooting | Recording

The access lamp remains lit or flashing even if recording has stopped.

- This product is recording the scene you have just shot on the memory card.
-

[230] Troubleshooting | Troubleshooting | Recording

The imaging field looks different.

- The imaging field may look different depending on the condition of this product. This is not a malfunction.

[231] Troubleshooting | Troubleshooting | Recording

The actual recording time for movies is less than the expected recording time of the recording media.

-
- Depending on the recording conditions, the time available for recording may be shorter, for example when recording a fast moving object, etc.

[232] Troubleshooting | Troubleshooting | Recording

This product stops recording.

-
- If you keep applying vibration on this product, recording may stop.

[233] Troubleshooting | Troubleshooting | Recording

There is a slight time lag between the moment when START/STOP is pressed and the actual movie recording starts or stops.

-
- On this product, there may be a slight time difference between the moment when you press START/STOP and when the actual movie recording starts/stops. This is not a malfunction.

[234] Troubleshooting | Troubleshooting | Recording

The auto focus does not function.

-
- Set [Focus] to [Auto].
 - If the auto focus does not lock on the subject, adjust the focus manually.
-

SteadyShot does not function.

- Set [ SteadyShot] to [Active] or [Standard], [ SteadyShot] to [On].
 - Even when [ SteadyShot] is set to [Active] or [Standard], or [ SteadyShot] is set to [On], this product may not be able to compensate for excessive vibrations.
-

Images cannot be recorded or played back correctly.

- If you record and delete images repeatedly for a long time, the files on the recording media may become fragmented and images cannot be recorded or played back correctly. After backing up the images on other media, perform [Format] of the recording media on this product.
-

The subjects passing across this product very fast appear crooked.

- This is called the focal plane phenomenon. This is not a malfunction. Because of the way the image device (CMOS sensor) reads out image signals, the subjects passing by the lens rapidly might appear crooked depending on the recording conditions.
-

Horizontal stripes appear on the images.

- Horizontal stripes may appear on the LCD monitor when recording images under a fluorescent lamp, sodium lamp, mercury lamp, or LED light.
You may be able to improve the situation by adjusting the shutter speed.

[239] Troubleshooting | Troubleshooting | Recording

[Monitor Brightness] cannot be set.

- You cannot set [Monitor Brightness] when:

The LCD monitor is closed on this product with the LCD monitor facing out.

The power is supplied from the AC Adaptor.

[240] Troubleshooting | Troubleshooting | Recording

Sound is not recorded correctly.

- If you connect or disconnect an external microphone, etc. while recording movies, the sound may not be recorded correctly. The sound will be recorded correctly by restoring the microphone connection at the start of movie recording.
 - If you turn the volume down to the minimum level by adjusting in [Audio Rec Level], the sound of movies cannot be recorded.
-

[241] Troubleshooting | Troubleshooting | Recording

Photos are recorded automatically.

- When [Smile Shutter] is set to [Dual Capture] or [Always On], photos are recorded automatically when this product detects a smile.
-

[242] Troubleshooting | Troubleshooting | Playback

Images cannot be played back.

- Select the movie type (XAVC S/AVCHD/MP4) you want to play with the movie format select button.
- Images recorded on other devices may not be played back. This is not a malfunction.

To play movie files edited on a computer or other equipment and written back to the recording media, but where no image appears on the Event View screen, perform [Repair Img. DB F.].

- To play a movie recorded in [4K] XAVC S 4K] format, make sure to set [Frame Rate] to the same value (30p or 24p) you set when recording. If not, you cannot play the movie, and a thumbnail does not appear on the LCD monitor (models with the 4K functionality and NTSC color system).

[243] Troubleshooting | Troubleshooting | Playback

Photos cannot be played back.

- You may not be able to play back photos if you have changed file or folder names, or have edited the data on a computer. (The file name flashes in that case.) This is not a malfunction.

[244] Troubleshooting | Troubleshooting | Playback

The movie freezes.

- Photos which were recorded while recording a movie are played back. In the default setting, movies and photos are played back continuously.

[245] Troubleshooting | Troubleshooting | Playback

An icon appears on a thumbnail.

- The image data base file may be damaged. Check the data base file by selecting [MENU] - [Setup] - [Media Settings] - [Repair Img. DB F.] - the recording medium. If it still appears, delete the image with .
 -  may appear on an image recorded on other devices, edited on a computer, etc.
 - You removed the AC Adaptor or the battery pack while the recording media icon at the top right corner of the screen is lit, or before the access lamp is turned off after recording. This may damage your image data and  is displayed.
-

[246] Troubleshooting | Troubleshooting | Playback

No sound or only a quiet sound is heard during playback.

- Turn up the volume.
 - If you turn the volume down to the minimum level by adjusting in [Audio Rec Level], the sound of movies cannot be recorded.
 - Sounds are not recorded while shooting with [Smth Slw REC] or [Golf Shot].
-

[247] Troubleshooting | Troubleshooting | Playback

Left and right sound is heard unbalanced when playing back movies on computers or other devices.

- Change the sound conversion type (downmix type) when playing back on 2ch stereo devices. Refer to the instruction manual supplied with your playback device for details.
 - Change the sound to 2ch when creating a disc using the PlayMemories Home software.
 - This happens when sound recorded in 5.1ch surround is converted to 2ch (normal stereo sound) by a computer or other device. This is not a malfunction.
 - Record sound with [Audio Mode] set to [2ch Stereo].
-

[248] Troubleshooting | Troubleshooting | Wi-Fi

The wireless access point you want to connect to does not appear.

- Depending on the signal conditions, the wireless access point may not appear on this product. Move this product closer to the wireless access point.
 - Depending on its setting, the wireless access point may not appear on this product. Refer to the instruction manual for the wireless access point for the correct settings.
-

[249] Troubleshooting | Troubleshooting | Wi-Fi

[WPS Push] does not work.

-
- Depending on the wireless access point setting, [WPS Push] may not be available. Confirm the password and SSID of the wireless access point to set [Access point settings].

[250] Troubleshooting | Troubleshooting | Wi-Fi

[Ctrl with Smartphone], [Send to Smartphone], [Send to Computer] or [View on TV] terminates prematurely.

-
- If the battery level is low, [Ctrl with Smartphone], [Send to Smartphone], [Send to Computer] or [View on TV] may terminate prematurely. Connect the AC Adaptor or charge the battery pack before use.

[251] Troubleshooting | Troubleshooting | Wi-Fi

Cannot transfer movies to your smartphone.

-
- To send a movie to your smartphone, be sure to record it in the MP4 format. Before shooting a movie to be transferred to a smartphone, set [Dual Video REC] to [On].

[252] Troubleshooting | Troubleshooting | Wi-Fi

The shooting screen does not display smoothly. The connection is cut off.

-
- Depending on the signal conditions, communication between the smartphone and this product may not work correctly. Reduce the distance between this product and the smartphone.

[253] Troubleshooting | Troubleshooting | Wi-Fi

The NFC connection does not work.

- Change the position of the compatible device to reduce the distance between  (N mark) on the smartphone and  (N mark) on this product.
If this still does not solve the problem, move the smartphone a few millimeters, or move the smartphone away from this product and wait for 10 seconds or more before touching again.
 - This product is in [Airplane Mode]. Set [Airplane Mode] to [Off].
 - Make sure that the smartphone is ready for communication. Refer to the instruction manual of your smartphone for details.
 - Do not put any metal products other than the smartphone close to  (N mark) on this product.
 - Do not touch  (N mark) on this product with 2 or more smartphones at the same time.
 - When running another application that uses the NFC function on your smartphone, close the application.
-

[254] Troubleshooting | Troubleshooting | Editing movies/photos on this product

Unable to edit.

- Unable to edit because of the condition of the image.
-

[255] Troubleshooting | Troubleshooting | Editing movies/photos on this product

A movie cannot be divided.

- The following movies cannot be divided.
 - Movies that are too short
 - XAVC S 4K (models with the 4K functionality) and XAVC S HD movies
 - MP4 movies
 - Release the protection, and then divide.
-

[256] Troubleshooting | Troubleshooting | Playback on a TV

Neither image nor sound is played on the connected TV.

-
- Images are not output from the HDMI OUT jack, if copyright protection signals are recorded in the images.
-

[257] Troubleshooting | Troubleshooting | Playback on a TV

The top, bottom, right, and left edges of images are trimmed slightly on a connected TV.

- The LCD monitor of this product can display recording images across the entire LCD monitor (full pixel display). However, this may cause slight trimming of the top, bottom, right, and left edges of images when played back on a TV which is not compatible with full pixel display.
 - It is recommended you record images using the outer frame of [Grid Line] as a guide.
-

[258] Troubleshooting | Troubleshooting | Playback on a TV

The image appears distorted on the 4:3 TV.

- This happens when viewing an image on a 4:3 TV. Set [TV Type] correctly and play back the image.
-

[259] Troubleshooting | Troubleshooting | Playback on a TV

Black bands appear at the top and bottom of the LCD monitor of the 4:3 TV.

- This happens when viewing an image on a 4:3 TV. This is not a malfunction.
-

[260] Troubleshooting | Troubleshooting | Copying/Connecting to other devices

Images are not copied correctly.

- You cannot copy images using the HDMI cable.
 - An AV cable (sold separately) is not connected properly. Make sure that the cable is connected to the input jack of the device.
 - You cannot copy XAVC S movies.
-

[261] Troubleshooting | Troubleshooting | Connecting to a computer

PlayMemories Home cannot be installed.

- An Internet connection is required to install PlayMemories Home.
 - Check the computer environment or installation procedure required to install PlayMemories Home.
-

[262] Troubleshooting | Troubleshooting | Connecting to a computer

PlayMemories Home does not work correctly.

- Quit PlayMemories Home and restart your computer.
-

[263] Troubleshooting | Troubleshooting | Connecting to a computer

This product is not recognized by the computer.

- Disconnect all USB devices from the USB jack of your computer except the keyboard, mouse, and this product.
 - Disconnect the Built-in USB Cable from the computer and restart the computer, then connect the computer and this product again in the correct order.
 - When both the Built-in USB Cable and the Multi/Micro USB terminal of this product are connected to the external devices at the same time, disconnect the one that is not connected to a computer.
-

[264] Troubleshooting | Self-diagnosis display/Warning indicators | Self-diagnosis

Self-diagnosis display

If indicators appear on the LCD monitor or in the viewfinder, check the following. If the problem persists even after you have tried to fix a couple of times, contact your Sony dealer or local authorized Sony service facility. When you contact them, give them the complete error code beginning with C or E displayed on the LCD monitor.



You may hear a melody when an important warning indicator appears on the LCD monitor.

C:(or E:) □ □ : □ □ (Self-diagnosis display)

C:04: □ □

You are not using the designated battery pack. Make sure to use the designated battery pack. Connect the DC plug of the AC Adaptor to the DC IN jack of this product firmly.

C:06: □ □

The battery pack temperature is high. Change the battery pack or place it in a cool place.

C:13: □ □ / C:32: □ □

Remove the power source. Reconnect it and operate this product again.

E: □ □ : □ □

Follow the steps from 2 on "If you have problems."

 (Battery level warning)

The battery pack is nearly used up.

Depending on the operating environment or battery conditions,  may flash even with about 20 minutes of power remaining.

 (Warning indicator pertaining to battery pack temperature)

The battery pack temperature is high. Change the battery pack or place it in a cool place.

 (Warning indicator pertaining to memory card)

Slow flashing

Free spaces for recording images are running out.

No memory card is inserted.

Fast flashing

There is not enough free spaces for recording images. After storing the images on other media,

delete unnecessary images, or format the memory card.

The image data base file may be damaged. Check the data base file by selecting **MENU** - [Setup] - [ Media Settings] - [Repair Img. DB F.] - the recording medium.

The memory card is damaged.

 (Warning indicators pertaining to memory card formatting)

The memory card is damaged.

The memory card is not formatted correctly.

 (Warning indicator pertaining to incompatible memory card)

Incompatible memory card is inserted.

 (Warning indicator pertaining to the write-protect of the memory card)

The memory card is write-protected.

Access to the memory card was restricted on another device.

 (Warning indicator pertaining to the external device)

The image data base file may be damaged. Check the data base file by selecting **MENU** - [Setup] - [ Media Settings] - [Repair Img. DB F.] - the recording medium.

The external device is damaged.

 (Warning indicators pertaining to external device formatting)

The external device is damaged.

The external device is not formatted correctly.

 (Warning indicator pertaining to camera-shake warning)

This product is unsteady, so camera-shake easily occurs. Hold this product steady with both hands and record the image. However, note that the camera shake warning indicator does not disappear.

 (Warning indicator pertaining to photo recording)

The recording media is full.

Photos cannot be recorded during processing. Wait for a while, then record.

You cannot capture photos while recording movies in the following situations:

- When [ REC Mode] is set to [Highest Quality **FX**]
- When the [ Frame Rate] is set to [60p] (models with NTSC color system) or [50p] (models with PAL color system)
- When an item of [Picture Effect] is selected
- When [Dual Video REC] is set to [On]

If messages appear on the LCD monitor, follow the instructions.

Data error.

- This may occur when you keep applying shock to this product.
- Movies recorded on other devices may not be played back.

The Image Database File is damaged. Do you want to create a new file?

HD movie management information is damaged. Create new information?

- The management file is damaged. When you select [Yes], a new management file is created. The old recorded images on the media cannot be played back (Image files are not damaged). If you execute [Repair Img. DB F.] after creating new information, playing back the old recorded images may become possible. If it does not work, copy the image using the PlayMemories Home software.

There is no Image Database File Movies cannot be recorded or played Create a new file?

There is no HD movie management information. Create new information?

- You cannot record or play back movies because no movie management information exists. If you select [Yes], new management information is created and you can record or play back movies.

Inconsistencies found in image database file. Do you want to repair the image database file?

The Image Database File is damaged. Do you want to repair the Image Database File?

Inconsistencies found in image database file. Cannot record or play HD movies. Do you want to repair the image database file?

- You cannot record or play back movies because no movie management information exists. If you select OK, new management information is created and you can record or play back movies.

Inconsistencies found in the image database file. Back up and recover.

Recover, then import using the included PC software.

- Since the database information of high definition image quality (HD) movies has been damaged, there are inconsistencies between the information in the database and the

information in the file. Select to back up the high definition image quality (HD) movies and repair the database file. You cannot see the backed-up movies on this product. By connecting this product to a computer after repairing the database, you can import backed-up high definition image quality (HD) movies to the computer using the PlayMemories Home software installed on the computer. However, it is not guaranteed that all movies can be imported to the computer.

Buffer overflow. Writing to the media was not completed in time.

- You have performed recording and erasing operations repeatedly, or a memory card that has been formatted by other device is used. Copy and take data backup to other device (such as a computer), and then format the memory card on this product.
- The size of the inserted memory card is not sufficient for copying the movie(s). Use the recommended memory card.

Restoring data...

- Writing data onto the media of this product has failed. Attempts were made to recover the data, but they were unsuccessful.

Cannot recover data.

- Writing data onto the media of this product has failed. Attempts were made to recover the data, but they were unsuccessful.

 Reinsert the memory card.

- Reinsert the memory card a few times. If the indicator continues to flash even after reinserting, the memory card could be damaged. Try with another memory card.

 Cannot recognize this memory card. Format and use again.

- Format the memory card. Note that when you format the memory card, all the recorded movies and photos are deleted.

This memory card does not support recording of XAVC S movies.

- You can record XAVC S movies using the following memory card.

SDXC memory card of Class 10 or faster

 The maximum number of still image folders has been reached. Cannot record still images.

- You cannot create folders exceeding 999MSDCF. You cannot create or delete created folders using this product.
- Format the memory card, or use other media.

This memory card may not be able to record or play movies.

This memory card may not be able to record or play images correctly.

- Use a memory card recommended for this product.

Do not eject the memory card during writing. Data may be damaged.

- Reinsert the memory card.

External media cannot execute functions.

- **MENU** - [Setup] - [ Media Settings] - [Repair Img. DB F.] - the recording.
- If even then the indicator flashes, format the external media using your computer, and then reconnect this product with the external media. Note that if you format the external media device, all the recorded movies and photos in it are deleted.
- If the same message still appears after formatting, the external media may not be supported by this product, or it may be damaged. Try with another external media.

Unable to access external media.

- Use the external media device in stable condition (the environment such as no vibration and room temperature, etc.).
- Make sure that the power source of the external media device is connected.

Others

Maximum number of images already selected.

- You can select only 100 images at one time for:
 - Deleting movies/photos
 - Protecting movies/photos, or releasing the protection
 - Copying movies/photos

Data protected.

- You tried to delete protected data. Release the protection of the data.