




CLIFF


PUSHBUTTON KNOB CS12



Part No. **CP3427**
CS12 PUSHBUTTON KNOB GREY



Part No. **CP3431**
CS12 PUSHBUTTON KNOB RED



Part No. **CP3433**
CS12 PUSHBUTTON KNOB BLACK