

# LABORATORY POWER SUPPLY

JT-RD6012-C



## 1. GENERAL INFORMATION


Dear customer,  
thank you very much for choosing our product.  
In the following, we will introduce you to what to observe while starting up and using this product.  
Should you encounter any unexpected problems during use, please do not hesitate to contact us.

The RD6012-C is a laboratory power supply that can be used in various operating modes (e.g. constant current or constant voltage operation, etc.). A keypad and a push and turn encoder make the operation of the power supply very comfortable. Furthermore, the keypad allows you to conveniently save and reload up to nine settings. The high-resolution 2.4-inch color display clearly shows all the important information. The USB interface and an optional Wifi interface allow you to operate the device via PC or with an app from mobile devices.

## 2. TECHNICAL SPECIFICATIONS


Display	2.4 " colour LCD
Input voltage range	230 V AC
Output voltage range	0 - 60 V DC
Output current range	0 - 12 A
Output power range	0 - 720 W
Input voltage accuracy	± 1 % + 5 digits
Output voltage accuracy	± 0,3 % + 3 digits
Output current accuracy	± 0,5% + 5 digits
Battery voltage measurement accuracy	± 0,5% + 3 digits
Input voltage measurement resolution	0,01 V
Output voltage measurement resolution	0,01 V
Current setting measurement resolution	0,01 A
Battery voltage measurement resolution	0,01 V
Constant voltage mode response time	2 ms at 0,1 - 5 A load
Constant voltage mode load regulation	± 0,1 % + 2 digits
Constant current mode load regulation	± 0,1 % + 3 digits
Capacity measurement range	0 - 9999,99 Ah
Energy measurement range	0 - 9999,99 Wh
Capacity and Energy statistical error	± 2 %
Output ripple	typ. 100mV VPP
Sensor temperature detection range	-10 - 100°C / 0- 200 ° F
Sensor temperature detection accuracy	± 3° C / ± 6 ° F
Working mode	step down (buck) mode
Voltage drop	min. 1V and min. 10 %
Screen brightness setting	Level 0 - 5, 6 levels total
Working temperature range	- 10° - 40 ° C

## 3. SCREEN OVERVIEW




## 4. DEVICE OVERVIEW


### 4.1. Front Panel



### 4.2. Back Panel



### 4.3. Case Back Panel



## 5. MENU INTRODUCTION

### 1. Operation Menu

Press '**SHIFT**+'0' to enter the system setting menu. In the menu operation, the icon in red or cursor is the currently selected menu; the icon in blue is the unselected menu; press **ENTER** to confirm; press the encoder to cancel or return; press the direction key to move the cursor or switch menu; rotate the encoder to change the setting; the settings will be automatically saved when returning from the menu page. Press and hold the 0 button and power on to restore the factory settings; press and hold the 1 button and power on to restore the factory calibration value; press and hold **ENTER** and power on to enter the boot mode.

### 2. Battery Charging mode

The RD6006 and RD6012 have their own battery charging function to facilitate the charging of batteries and accumulators. To do so, close the negative pole of the battery with the black port and the positive pole with the green port. The battery charging function can detect when a battery is connected by changing the battery symbol on the display from blue to red. You have to set the charging end voltage and charging current using "**I-SET**" and "**V-SET**". You can start and stop charging with **ON/OFF**. **IMPORTANT! You have to do this according to your battery otherwise there is danger to life!** As a safety measure you can use the temperature sensor of the power supply unit to observe the behaviour of the battery. With the temperature sensor the device is able to stop the charging process when the battery has reached a temperature of 80 °C. As the battery approaches the final charge voltage, the device will reduce the charge current until it falls below 10 mA and it will stop charging. The device indicates charging with a green symbol of the battery. Note that **NO** batteries with a protection circuit are suitable for charging with the RD6006 or RD6012.

**It is your responsibility to make the correct settings to charge the battery according to the manufacturer's specifications, which can be obtained from the battery manufacturer. We strongly recommend that you also use the temperature sensor and a suitable protective equipment.**

**Do not charge damaged batteries. The device and the batteries must be supervised during the charging process, in case of doubt stop charging.**


**Incorrect settings or faulty batteries pose a considerable risk of injury or death from heat, fire, burns, explosion and electric shock.**

### 3. Main Page Output Voltage and Output Current Setting

Press '**I-SET**' button to set the output current value, you can use the encoder to adjust the output value directly, press the direction button to move the cursor. Of course, you can use the keypad to set the value and press '**ENTER**' to confirm.

If you set the wrong value, you can press the encoder to cancel.


Press '**V-SET**' button to set the output voltage value, the operation method is similar to the output current setting. Press '**SHIFT**+' **I-SET**' button or '**SHIFT**+' **V-SET**' button to set the value of overcurrent protection (OCP) and overvoltage protection (OVP). The overcurrent protection switches off the output of the unit as soon as the current set at OCP is exceeded at the output. The overvoltage protection switches off the output of the device as soon as the voltage at the output exceeds the voltage set on OVP.




#### 4. **Data Group Quick Storage and Callout**

Press '**MEM**' + keypad button **1-9**, you can store the output voltage value, output current value, overvoltage protection value, overcurrent protection value into the corresponding data group (as shown above), then press '**ENTER**' to confirm, or press the encoder to cancel. Press '**SHIFT**' + keypad button 1-9 to quickly call out the saved data (as shown above). Press '**ENTER**' to confirm, or press the encoder to cancel.

#### 5. **Keypad lock and unlock**

Press '**SHIFT**'+'.' to lock or unlock the keyboard. And the keypad will be automatically locked when communication starts, there will be displayed  on the top (can not unlock manually) and the keypad will be automatically unlocked when the connection disconnected manually.

There will be displayed , the keypad will be automatically unlocked when the connection disconnected abnormally and the power-off button can be used when the keypad is locked.


#### 6. **System Setting**


Press '**SHIFT**'+'0' to enter the system setting menu as shown on the right, press '**ENTER**' to enter the menu, press direction button to select option, the option in red is the option be chosen, rotate the encoder to change this setting.

Turn on the '**Call OK**', a confirmation window will pop up when you quick call out a data group. If you turn it off, the setting values will be modified directly when you call out a data group.

Turn on the '**Call out**', the output will be turned on automatically when you call out a data group. If you turn it off, the output will keep the previous status.

Turn on the '**Power On**', it will turn on the output automatically when start. If you turn it off, the output will keep OFF status when started.


Turn on the '**Beeper**', you will hear button tune when pressing the button and there will be  on the top.


If you turn it off, there will not be button tune when press the button and there will be  on the top.

Turn on the "**Logo**", it will display Logo first and then enter the main page when booting RD6006 or RD6012. If you turn it off, you will enter the main page directly.

The system language supports English, German, French and Simplified Chinese.


The screen brightness can be set from level 0 to level 5.


The communication interface can be set to USB, Wi-Fi or TTL, **USB** interface is the Micro-USB interface on the front panel interface, you can see the  on the top when communication starts.

**Wi-Fi** interface is the Wi-Fi module connected to the communication interface, you can see the  on the top when communication starts (connect mobile phone by Wi-Fi, but you need to choose Wi-Fi interface first, Wi-Fi module can not be installed or removed when RD6006 or RD6012 is powered on), TTL is not available for the time being.

When the interface is changed, you need to reboot the device to apply the modification. The baud rate can be set 9600/19200/38400/57600/115200 under USB mode; The Baud rate under Wi-Fi is fixed at 115200. The device address can be set from 001-255. You can set the date and time by rotating the encoder, the setting will be saved immediately after modification. Please do not set a wrong time, it may cause the date to not be automatically accumulated. Press the encoder to return and the set value will be saved automatically.

**Measure** is the refresh rate of read back voltage and current on the main page, you can set it to low, middle and high. Press rotary encoder to return and it will be automatically saved.





7. **Main Page Style setting**


You can press '**SHIFT**' + '**0**' to enter the system setting menu and then press the right button to enter the main page style setting menu as shown above. Press **ENTER** and then use the direction button to set classic style or curve style. The pattern in red is the style be chosen. The classic style is the system default style and the large font shows the voltage, current and power. The curve style is, as shown above, the colour of the three curves corresponds to the output voltage, current and power. **D** is the scale of the value, Press '**ENTER**' to start or pause the curve and the rotary encoder to scale the values of the curve.

8. **Storage Data Setting**

You can press '**SHIFT**' + '**0**' to enter the system setting menu, then press the right button twice to enter the data storage setting menu as shown below, press **ENTER** to enter the setting menu, the icon in red is the chosen data group, press the direction button to select data group number. Press '**I-SET**' button to set the storage output current value, then rotate the encoder to adjust the output value, press the direction button to move the cursor. You can also set the value with keypad, press **ENTER** to confirm. If you set the wrong value, you can press the encoder potentiometer to cancel. Press '**V-SET**' button to set the storage output voltage value, the operation method is similar to storage output current setting. Press '**SHIFT**'+ '**I-SET**' button or '**SHIFT**'+ '**V-SET**' button to set the storage overcurrent protection/ storage overvoltage protection value. The operation method is similar to storage output current value setting. Press the **Encoder Potentiometer** to return and the data will be automatically saved.

9. **System Information**

You can press '**SHIFT**' + '**0**' to enter the system setting menu, then press the right button three times to enter the system information menu as shown here. You can view the SN number, firmware version and system temperature here.




## 6. PC-SOFTWARE

To control the power supply from the app, you must first enable WiFi.

To do so, press Shift and then 0 to enter the menu.

Now press Enter and use the arrow keys to navigate to Interface.

Now turn the knob to select WiFi and press the knob several times to confirm and go back.



The changes will be applied after restart of the power supply. The power supply will automatically use the strongest WLAN network. Make sure that your computer is on the same network.

Download the PC software [here](#).



Click WiFi, enter the name and password of your wireless network under your displayed IP address, press WiFi Distribution and restart your power supply.



Once your IP address is displayed on your power supply, click Next.

If an incorrect IP address is displayed on your power supply, navigate to Reset using the arrow keys and confirm with ENTER.  
The IP is now determined again.



Your power supply unit now receives the necessary information to connect to your computer. This may take a few seconds.



You can then connect your power supply unit to the PC software by clicking on Connect in the lower left corner.

Graphical representation

Batteriestatus

Call up data groups

Info

The screenshot shows the main interface of the Riden Power Supply Software. It features a top navigation bar with tabs: Basic Functions, Advanced Functions, Firmware Update, Startup Logo Update, Software Update, Language, and About. The main area is divided into several sections:

- Left Panel:** Contains network settings (Local Ip: 192.168.1.63, Wifi Name: Simac, Password: \*\*\*\*\*) and device information (Device Address: 001, Product Model: RD6006, Serial Number: 00001046, Firmware Version: V1.25). A 'Break' button is at the bottom.
- Top Center:** 'Output Voltage And Current Graph' showing a plot of Output Voltage (V) and Output Current (A) over Read Number (Num).
- Bottom Center:** Two large circular gauges: 'V-Set' (set to 20.00 V) and 'I-Set' (set to 1.000 A). Below them are 'Maximum Output voltage' and 'Maximum Output current' labels.
- Right Panel:** 'Basis Info' section showing real-time readings: Input Voltage (64.67 V), Output Voltage (00.00 V), Output Current (0.000 A), Output Power (00.00 W), and System Temperature (33 °C). It also includes status indicators for Normal, OVP, OCP, and OTP, and an 'On/Off' switch.
- Other Sections:** 'Battery Charging' (Voltage: 00.00 V, Temperature: 31 °C), 'Call Out' (Data1-Data9), and 'Time Synchronization' (Synchronize button).

Red arrows point from external labels to these specific elements:

- 'Connect / Disconnect' points to the 'Break' button.
- 'Selected output voltage' points to the 'V-Set' gauge.
- 'Maximum Output voltage' points to the 'V-Set' gauge's 'Max. Value' field.
- 'Selected output current' points to the 'I-Set' gauge.
- 'Maximum Output current' points to the 'I-Set' gauge's 'Max. Value' field.
- 'Background-brightness' points to the 'Backlight Adjust' slider.
- 'Output ON/OFF' points to the 'On' button.

Data group selection

The screenshot shows the 'Data Array Operation' and 'Programming Output' screens. The 'Data Array Operation' screen has a dropdown menu set to 'Data0' and several input fields for V-SET, I-SET, S-OVP, and S-OCP. The 'Programming Output' screen features a table with columns for No., V-SET(V), I-SET(A), Delay(S), and Status. Below the table are 'Automatic Mode' and 'Manual Mode' radio buttons, and 'Start', 'Pause', 'End', and 'Carry On' buttons. A 'Read' button is also visible at the bottom left.

Red arrows point from external labels to these elements:

- 'Read data groups' points to the 'Read' button.
- 'Write data groups' points to the 'Write' button.
- 'Intervals Setting' points to the 'Delay(S)' column in the table.

Read data groups

Write data groups

Intervals Setting

## 7. ANDROID APP


To control the power supply from the app, you must first enable WiFi.

To do so, press Shift and then 0 to enter the menu.

Now press Enter and use the arrow keys to navigate to Interface.


Now turn the knob to select WiFi and press the knob several times to go back.

The power supply will automatically use the strongest WLAN network.




You must now restart the power supply.

Now install the App RdPower from Ruideng Technology from the Play Store.




You must give the app the permissions it requires to work.

Open the app and press the button in the upper left corner to enter the menu.




Here you can see your IP address, you will need this later.

Now go to Distribution Network and also restart the power supply.




You should now see the following in your app:



Once your IP address, which you could see in the app before, is displayed on the screen of your power supply, you can click NEXT.

If an incorrect IP address is displayed on your power supply, use the arrow keys to navigate to Reset and confirm with ENTER. The IP is now determined again.


Now you have to enter the password of your WLAN network and click Click CONFIRM.



After a short wait, you can now connect your smartphone to your power supply by clicking on CONNECT.



Now you can operate the power supply with your smartphone. Please note, however, that the power supply cannot be adjusted manually as long as your smartphone is connected.




## 8. IOS APP

To control the power supply from the app, you must first enable WiFi.

To do so, press Shift and then 0 to enter the menu.


Now press Enter and use the arrow keys to navigate to Interface.

Now turn the knob to select WiFi and press the knob several times to go back.



You must now restart the power supply.

Now install the App RdPower from Ruideng Technology from the App Store.



You must give the app the permissions it requires to work.

Open now the app and move to the area named *Distribution network* where you have to establish the connection with the device.

10:12 📶 🔋

**Distribution network**

WIFI Name

Local IP

Password

Device

Pending configuration...

[Init](#) [Distribution](#) [Cancel](#)

WIFI Connect **Distribution network** Control Center

Click now on *Init* to start with the configuration.

10:12 📶 🔋

**Distribution network**

WIFI Name

Local IP

Password

Device

Initialize, wait for RD6006 to display the local IP address, click on the distribution network to start network configuration


[Init](#) [Distribution](#) [Cancel](#)

WIFI Connect **Distribution network** Control Center

Enter now your password of your network in case that the IP-address on your iPhone is identical with the IP-address of your device. Afterwards, click on *Distribution* to establish the connection.


If an incorrect IP address is displayed on your power supply, use the arrow keys to navigate to Reset and confirm with ENTER. The IP is now determined again.





After, you have successfully connected, you can access the home screen in the *WiFi Connect* area. There, you can activate the direct connection to the device and use the functions of the RD6006.

Note, however, that the power supply can no longer be adjusted manually while your phone is connected.



## 9. ADDITIONAL INFORMATION

Our information and take-back obligations according to the Electrical and Electronic Equipment Act (ElektroG)



### **Symbol on electrical and electronic equipment:**

This crossed-out dustbin means that electrical and electronic appliances do not belong in the household waste. You must return the old appliances to a collection point.

Before handing over waste batteries and accumulators that are not enclosed by waste equipment must be separated from it.

### **Return options:**

As an end user, you can return your old device (which essentially fulfils the same function as the new device purchased from us) free of charge for disposal when you purchase a new device.

Small appliances with no external dimensions greater than 25 cm can be disposed of in normal household quantities independently of the purchase of a new appliance.

### **Possibility of return at our company location during opening hours:**

Simac GmbH, Pascalstr. 8, D-47506 Neukirchen-Vluyn, Germany

### **Possibility of return in your area:**

We will send you a parcel stamp with which you can return the device to us free of charge. Please contact us by e-mail at [Service@joy-it.net](mailto:Service@joy-it.net) or by telephone.

### **Information on packaging:**

If you do not have suitable packaging material or do not wish to use your own, please contact us and we will send you suitable packaging.

## 10. SUPPORT

If there are still any issues pending or problems arising after your purchase, we will support you by e-mail, telephone and with our ticket support system.

E-Mail: [service@joy-it.net](mailto:service@joy-it.net)

Ticket system: <http://support.joy-it.net>

Telephone: +49 (0)2845 98469-66 (10-17 o'clock)

For further information please visit our website:

[www.joy-it.net](http://www.joy-it.net)