



# 8+2 Port Gigabit PoE Switch



## Quick Installation Guide

DN-95357

# Table of Contents

1. Introduction .....	3
2. Main Features .....	3
3. Package Contents .....	3
4. Product Specification.....	4
5. Hardware Description.....	5

# 1. Introduction

DN-95357 has a CCTV function for 250 meters of ultra-long-distance transmission. Users can choose to turn on or off the CCTV function. Improve network security and restrain network storms, facilitate management and maintenance, and meet the networking and access requirements of enterprises, communities, hotels. office networks, and campus networks.

## 2. Main Features

- Support IEEE802.3 at standard, compatible with IEEE802.3 af by electrical equipment (PD)
- Stand-up output power up to 30W
- Support IEEE802.3 x full duplex flow control and Backpressure half duplex flow control
- Panel lights to monitor working state and help fault analysis
- Perfect security mechanism
- Line-speed forwarding intelligent identification
- Support CCTV Function
- Support Energy-Efficient Ethernet (EEE) function (IEEE802.3az)
- Support PD-ALIVE function

## 3. Package Contents

- PoE Switch
- User Guide
- Power Cord

## 4. Product Specification


Technical	
Interface	10 * 10/100/1000Mbps auto-negotiation RJ45 port
PoE port	1 ~ 8
PoE stand	IEEE802.3af/at
PoE total	60 W
Power supply	65 W
Key function	CCTV
PoE port output	Max 30W
RJ45 PoE power supply	Mode A, Anode 1/2, Cathode 3/6
Indicator	PWR (Green), LNK/ACT (Green) PoE (Orange)
Network media	10 BASE-T: UTP category 3,4,5 cable (≤100m), 100 BASE-TX: UTP category 5, 5e cable (≤100m), 1000 BASE-T: UTP category 5, 5e cable (≤100m)
MAC Address Table	2K, Automatic study, automatic updates
Jumbo frame	9216 Bytes
Packet buffer	2Mbit
Transfer Mode	Store-and-forward
Packet Forward Speed	14.88Mpps
Bandwidth	20Gbps
Device Dimension	168 x 93 x 32mm
Green energy saving	Support IEEE (802.3az)
Mains input	100 ~ 240V AC, 50/60Hz

Operating Temperature	0°C ~ 40 °C
Storage Temperature	-40 °C ~ 70 °C
Operating Humidity	10% ~ 90% non-condensing
Storage Humidity	5% ~ 90% non-condensing
Surge Protection	Common mode $\pm$ 2KV, differential mode $\pm$ 1KV
MTBF	>50000 hour
Electrostatic standard	Contact $\pm$ 6KV, air $\pm$ 8KV

## 5. Hardware Description

### Front Panel

The Front Panel Consists of Ethernet Ports. The LED indicators are also located on the panel.



**DIP Switch:** The DIP switch located on the right of the panel.

**Default:** the factory default mode, can normal communication between port 1~10.

**CCTV mode:** 1-8 port can be isolated each other, but 1-8 port can connect to 9, 10 port after open CCTV to stop broadcast storm to increase forwarding rate of frame. The CCTV mode, up to 250m PoE distance allows you to expand you network via Ethernet cable to where there is no power line or outlet but where you want to fix device such as IP Cameras.

**Note:** After change the mode, there is no need to restart manually to make the corresponding configuration take effect.

#### LED indicator

LED	Color	Function
PWR	Green	<b>Off:</b> No Power supply. <b>Light:</b> Indicates the switch has power.
LNK/ ACT	Green	<b>Off:</b> No device is connected to the corresponding port. <b>Light:</b> Indicates the link through that port is successfully established at 10/100Mbps. <b>Blink:</b> Indicates that the Switch is actively sending or receiving data over that port.
PoE	Orange	<b>Off:</b> No PoE powered device (PD) connected. <b>Light:</b> There is a PoE PD connected to be port, which supply power successfully. <b>Blink:</b> Indicates port abnormal power supply.

## Rear Panel

The rear panel of the PoE Switch indicates an AC inlet power socket, which accepts input power from 100 to 240V AC, 50/60HZ.



### Power socket

Connect the female connector of the power cord here, and the male connector to the AC (Alternating Current) power outlet. Please make sure the voltage of the power supply meets the requirement of the input voltage.

### Grounding column

The switch already comes with lightning protection mechanism. You can also ground the switch through the PE (Protecting Earth) cable of AC cord or with Ground Cable.

## **Installation the Switch**


This part describes how to install your Ethernet Switch and make connections to it. Please follow the following instructions in avoid of incorrect installation causing device damage and security threat.

- Before cleaning the switch, unplug the power plug of the switch first. Do not clean the switch with wet cloth or liquid;
- Do not place the switch near water or any damp area. Prevent water or moisture from entering the switch chassis;
- Do not place the switch on an unstable case or desk. The switch might be damaged severely in case of a fall;
- Ensure proper ventilation of the equipment room and keep the ventilation vents of the switch free of obstruction;
- Make sure that the operating voltage is the same one labeled on the switch;
- To avoid the danger of electric shock, do not open the chassis without authorization;



## Desktop Installation

Install the Switch on a desktop, please attach these cushioning rubber feet provided on the bottom at each corner of the Switch in case of the external vibration. Allow adequate space for ventilation between the device and the objects around it.



### Wall-mounted installation

In the first two fixed screw on the wall as shown in the figure below. Aim at the two fixed hole switches (M4 screw, nut diameter 7mm) and the machine smoothly on the screw.



### Turn on the switch

Please connect the AC power cord into the rear of the switch and to an electrical outlet (preferably one that is grounded). When the switch is power on, the LED indicators flash momentarily for one second, which represents a resetting of the system. The Power LED indicator turns on green.

**Note:** Please confirm the voltage is correct before power on, otherwise the switch will be damaged.  
(The power input is: 100V-240Vac, 50/60Hz)

## Disclaimer

This is a Class A product. In home environment, this product may cause radio interference.

In this case, the user may be required to take appropriate measures.

Hereby Assmann Electronic GmbH, declares that the Declaration of Conformity is part of the shipping content. If the Declaration of Conformity is missing, you can request it by post under the below mentioned manufacturer address.

**[www.assmann.com](http://www.assmann.com)**

Assmann Electronic GmbH

Auf dem Schüffel 3

58513 Lüdenscheid

Germany

