

BENNING

Operating manual

Translation of the German original version

BENNING CM 3-PV

5358 / 07/2025 en



Legal notice

Notes concerning the documentation

Ensure that the applicable documentation is used for this product. For safe handling, knowledge that is provided in these instructions is required.

The product may only be handled while following this documentation, particularly the safety instructions and warnings it contains. The personnel must be qualified for the respective task and have the capability to recognise risks and prevent possible dangers.

Manufacturer and holder of rights

BENNING Elektrotechnik und Elektronik GmbH & Co. KG

Münsterstraße 135 – 137

46397 Bocholt

Germany

Phone: +49 2871 / 93-0

E-mail: dupol@benning.de

Internet: www.benning.de

Commercial register Coesfeld HRA no. 4661

Copyright

All rights reserved.

This document – particularly all of the contents, texts, photographs and graphics that it contains – are protected by copyright.

No part of this documentation or the associated contents may be reproduced or edited, copied or distributed using electronic media in any form (printed, photocopied or using any other method) without express written permission.

Disclaimer

The contents of the documentation has been checked to ensure that it corresponds to the hardware and software described. Nevertheless, deviations cannot be ruled out, so Benning cannot guarantee complete correspondence. The contents of this documentation are checked at regular intervals, and any corrections that are needed are contained in the versions that follow.

General non-discrimination

Benning is aware of the importance of language with regard to the gender equality and endeavors to take this into account at all times. To improve readability, we have refrained from consistently using differentiating formulations.

Table of contents

1	Introduction.....	7
1.1	General notes.....	8
1.2	History	8
1.3	Service & support.....	9
2	Safety	10
2.1	Warning system	10
2.2	Standards applied	10
2.3	Symbols used.....	11
2.4	Intended use	12
2.5	Special types of risks	14
3	Scope of delivery	15
4	Device description.....	17
4.1	Device structure	17
4.2	Functions.....	19
4.2.1	“SELECT / ZERO” key	19
4.2.2	“HOLD / BACKLIGHT” key.....	20
4.2.3	“MIN/MAX / INRUSH” key	20
4.2.4	“TORCH / LPF” key.....	21
4.2.5	Wireless data transmission	21
4.3	Measuring ranges	22
4.3.1	Voltage ranges	23
4.3.2	Current ranges	23
4.3.3	Resistance ranges	24
4.3.4	Continuity test	24
4.3.5	Diode test.....	25
4.3.6	Capacitance ranges	25
4.3.7	Frequency ranges	25
5	Operation.....	26
5.1	Requirements for tests and measurements	26
5.2	Connecting the safety measuring lines	27
5.3	Voltage measurement	28
5.4	Current measurement (A)	29
5.5	Current measurement (µA)	30
5.6	Frequency measurement	31
5.7	Resistance measurement	32
5.8	Continuity testing.....	33

5.9	Capacitance measurement	33
5.10	Diode testing	34
5.11	Voltage indicator	34
5.11.1	Non-contact phase testing	35
6	Maintenance	36
6.1	Maintenance schedule	36
6.2	Making the device free of voltage	36
6.3	Cleaning the device.....	37
6.4	Replacing the batteries	37
6.5	Calibrating the device.....	38
7	Technical data.....	39
8	Disposal and environmental protection	40
	Index	41

Table of figures

Figure 1	BENNING CFlex 1	15
Figure 2	BENNING TA 1	15
Figure 3	BENNING TA 2	16
Figure 4	BENNING TA 3	16
Figure 5	Ø 4 mm silicone measuring lines with 2 mm and 4 mm measuring probes.....	16
Figure 6	BENNING CM 3-PV device structure.....	17
Figure 7	Rotary switch	18
Figure 8	Digital display.....	18
Figure 9	DC and AC voltage measurement	28
Figure 10	Current measurement via measuring clamp (A)	29
Figure 11	Current measurement via safety measuring lines (µA).....	30
Figure 12	Frequency measurement.....	31
Figure 13	Resistance, capacitance measurement, continuity or diode testing	32
Figure 14	Non-contact phase test.....	35

List of tables

Table 1	History.....	8
Table 2	Symbols on the device.....	11
Table 3	Symbols used in the operating manual.....	11
Table 4	Selecting a function	19
Table 5	Low-pass filter.....	21
Table 6	AC voltage ranges (V-AC)	23
Table 7	DC voltage ranges (V-DC).....	23
Table 8	AC current ranges (A-AC).....	23
Table 9	DC ranges (A-DC).....	24
Table 10	AC current ranges (μ A-AC).....	24
Table 11	DC ranges (μ A-DC)	24
Table 12	Resistance ranges (Ω).....	24
Table 13	Diode test.....	25
Table 14	Capacitance ranges (μ F)	25
Table 15	Frequency ranges (Hz)	25
Table 16	Maintenance schedule.....	36
Table 17	Technical data	39

1 Introduction

The TRUE RMS digital current clamp multimeter BENNING CM 3-PV described here (in the following only referred to as “device”) is intended for testing in electric circuits with a nominal voltage up to a maximum of 1 000 V-AC or 1 500 V-DC. The device enables you to perform the following tests and measurements:

- DC and AC voltage measurement
- DC and AC measurement
- Resistance measurement
- Diode and continuity test
- Capacitance measurement
- Frequency measurement

Further information

<https://tms.benning.de/cm3-PV>



On the Internet, you will find the following additional information directly at the specified link or at www.benning.de (product search):

- Operating manual of the device in several languages
- Further information depending on the device (e. g. brochures, technical reports, FAQs)

1.1 General notes

Target group

This operating manual is intended for the following groups of people:

- Qualified electricians and electrotechnically trained personnel

Required basic knowledge

To understand these operating manual, you will need general knowledge of testing and measuring equipment. Moreover, you will need basic knowledge of the following issues:

- General electrical engineering

Purpose of the operating manual

This operating manual describes the device and provides you information about how to handle it.

Keep this operating manual in a safe place for later use. Read this operating manual before handling the device and follow the instructions.

NOTE

Disclaimer of liability

Please make sure that any person using the device has read and understood the instructions of this operating manual before handling the device and that the instructions are adhered to in all points. Non-observance of this operating manual might result in product damage, property damage and/or personal injury.

Benning assumes no liability for damage and malfunctions resulting from the failure to observe the instructions in this operating manual.

The devices are subject to continuous further development. Benning reserves the right to make changes to the device's design, configuration and technology. The information in this operating manual corresponds to the state of technical knowledge at the time of printing. For this reason, no claims for certain device characteristics can be derived from the contents of this operating manual.

Information in this operating manual can be changed at any time without prior notice. Benning is not obligated to make amendments to this operating manual or to keep it up to date.

Direct any technical questions to Technical Support [► page 9].

Trademarks

All trademarks used are the property of their respective owners, even if they are not separately marked as such.

1.2 History

Release number	Amendments
07/2025	• Initial release

Table 1: History

1.3 Service & support

Please contact your specialty retailer or the BENNING Service Center for any repair or service work that might be required.

Technical Support

Please contact our Technical support for technical questions on handling the device.

Phone:	+49 2871 93-555
Fax:	+49 2871 93-6555
E-Mail:	helpdesk@benning.de
Internet:	www.benning.de

Returns management

Easily and conveniently use the BENNING returns portal for a quick and smooth returns processing:

<https://www.benning.de/service-de/retourenabwicklung.html>

Phone:	+49 2871 93-554
E-Mail:	returns@benning.de

Return address

BENNING Elektrotechnik und Elektronik GmbH & Co. KG
Retourenmanagement
Robert-Bosch-Str. 20
D - 46397 Bocholt

2 Safety

2.1 Warning system

This operating manual contains notes that must be taken into consideration for your personal safety and in order to avoid injuries and damage to property. Warnings about your personal safety and to prevent personal injuries are marked with a warning triangle. Warnings on sole prevention of material damage are shown without a warning triangle. The warnings are shown in descending order depending on the hazard level as follows.



DANGER

Extremely dangerous situation for humans

If you do not pay attention to this warning, irreversible or deadly injuries will occur.



WARNING

Hazard to humans

If you do not pay attention to this warning, irreversible or deadly injuries could occur.



CAUTION

Minor hazard to humans

If you do not pay attention to this warning, minor or moderate injuries could occur.



NOTICE

Danger to property, not to persons

If you do not pay attention to this warning, material damage could occur.

If multiple hazard levels occur, the warning for the highest respective hazard level will be used. In addition, a warning about personal injuries can also include a warning about material damage.

2.2 Standards applied

The device has been built and tested in compliance with the following standards and has left the factory in perfectly safe condition.

- IEC / DIN EN 61010-1 (VDE 0411-1)
- IEC / DIN EN 61010-2-032 (VDE 0411-2-032)
- IEC / DIN EN 61010-2-033 (VDE 0411-2-033)
- IEC / DIN EN 61010-031 (VDE 0411-031)

2.3 Symbols used

Symbols on the device

Symbol	Meaning
	Application around and removal from hazardous live conductors is permitted.
	Please observe the information provided in this operating manual in order to avoid dangers.
	Warning of electrical danger! Please observe the information provided in this operating manual in order to avoid dangers.
CAT IV	Measuring category CAT IV is applicable to testing and measuring circuits connected to the feeding point of the low-voltage mains installation of a building.
	The device complies with EU directives.
	The device complies with directives applicable in Great Britain.
	At the end of product life, dispose of the unserviceable device via appropriate collecting facilities provided in your community.
	The device is provided with protective insulation (protection class II).
	This symbol indicates the inserted batteries.
	Please observe the operating manual.
	(DC) direct voltage or direct current
	(AC) alternating voltage or alternating current
	Earth (voltage to earth)
NCVD)))	Position of the NCV antenna for non-contact phase test

Table 2: Symbols on the device

Symbols used in the operating manual

Symbol	Meaning
	General warning
	Warning of electric voltage!

Table 3: Symbols used in the operating manual

2.4 Intended use

Only use the device within the framework of the corresponding technical data. Any operating conditions that deviate from this shall be considered as improper use. Solely the user of the device shall be liable for any resulting damage.

Please note the following:

- In case of improper use, the liability and warranty claims become void. Solely the user of the device shall be liable for any damage resulting from improper use. Uses not complying with the intended use include e. g.:
 - Use of components, accessories, spare or replacement parts that have not been released and approved for the respective application by Benning
 - Non-observance, manipulation, changes or misuse of the operating manual or the instructions and notes contained therein
 - Any form of misuse of the device
 - Any use other than or beyond that described in this operating manual
- Warranty and liability claims are generally excluded if the damage is the result of force majeure.
- If any prescribed services are not performed regularly or not on time, according to the manufacturer's specifications during the warranty period, a decision about a warranty claim can only be made once the findings are available.

Direct any questions to Technical Support [► page 9].

Using the device

Please observe the following basic obligations when using the device:

- The device may only be used in a technically perfect and safe condition. Always check the device for damages before using it.
- The personnel must be qualified for the respective task.
- Observe relevant regulations on occupational safety and health as well as those on environmental protection.
- The device may only be used inside buildings and in dry environments.
- Do not use the device in potentially explosive environments.
- Use the device only in electric circuits up to overvoltage category IV with a conductor for a maximum of 1 000 V to earth.
- Use suitable (approved) safety measuring lines. For measurements in electric circuits of overvoltage category III or IV, the protruding conductive part of a contact tip of the safety measuring line must not be longer than 4 mm. Before measuring, attach the enclosed protective caps onto the contact tips (marked with CAT III and CAT IV).
- In order to detect a dangerous voltage and to prevent any danger, always measure a present voltage first without low-pass filter (LPF).
- In order to prevent any danger due to incorrect measurements, replace discharged batteries immediately.



⚠ WARNING

Dangerous voltage

Danger to life or serious injury is possible due to contact with high electric voltage in case of incorrect operation.

- Do not touch the bare measuring probe tips of the safety measuring lines or the bare contacts of the optional alligator clips. Only touch the safety measuring lines in the area intended for your hands.
- Connect the safety measuring lines to the correspondingly marked measuring jacks of the device and check them for tight fit.
- Only use approved safety measuring lines.
- Attach the protective caps to the contact tips of the safety measuring lines (circuits of overvoltage category III or IV).
- When disconnecting the measuring circuit, first remove the live safety measuring line (phase) and then the neutral safety measuring line from the measuring point.



⚠ WARNING

Opening the device

Danger to life or serious injury is possible due to contact with high electric voltage when opening the device. The device might get damaged.

- Make sure that the device is free of voltage before opening the battery compartment.
- Do not open the device (except for the battery compartment).
- Please contact your specialty retailer or the returns management for any repairs [► page 9].

Securing the device

If the device is not in a technically perfect and operationally safe condition, safe operation is no longer guaranteed. Make sure that the following measures are taken:

- Switch off the device.
- Remove the device from the measuring point.
- Secure the device against unintentional operation.

The following characteristics indicate that safe operation is no longer guaranteed:

- The device (housing or safety measuring lines) shows visible damage or is damp/wet.
- The insulation of the safety measuring lines is damaged.
- The device does not work properly in compliance with regulations (e. g. errors during measurements).
- The device shows recognisable consequences of prolonged storage under inadmissible conditions.
- The device shows recognisable consequences of extraordinary stress due to transport.

2.5 Special types of risks



DANGER

Bare conductors or main line carriers

Danger to life or serious injury is possible due to contact with high electric voltage when working with bare conductors or main line carriers.

- Please observe relevant regulations on occupational safety and health.
- If necessary, use appropriate protective equipment.



WARNING

Dangerous voltage

Danger to life or serious injury is possible due to contact with high electric voltage when working on live components or equipment. Even low voltages from 30 V-AC and 60 V-DC on can be dangerous to human life!

- Please observe relevant regulations on occupational safety and health.
- If necessary, use appropriate protective equipment.

3 Scope of delivery

The scope of delivery of the device includes the following components:

- 1 x TRUE RMS digital current clamp multimeter BENNING CM 3-PV
- Safety measuring lines:
 - 1 x safety measuring line (red, l = 1.0 m)
 - 1 x safety measuring line (black, l = 1.0 m)
- 1 x compact protective pouch
- 2 x 1.5 V micro batteries (AAA / IEC LR03)
- 1 x operating manual

Optional accessories

- Flexible AC current transformer BENNING CFlex 1 (item no.: 044068)
AC range: 30 A / 300 A / 3 000 A



Figure 1: BENNING CFlex 1

- Set of safety measuring lines BENNING TA 1 (item no.: 044124)
Ø 4 mm alligator clips, 2-piece, red / black, professional version, CAT III 1 000 V, 36 A



Figure 2: BENNING TA 1

- Set of safety measuring lines BENNING TA 2 (item no.: 044125)
Set of Ø 4 mm measuring lines, 6-piece, red / black, professional version, consisting of:
 - Measuring lines (silicone) (CAT III 1 000 V)
 - Test probes (4 mm measuring probe, CAT II 1 000 V)
 - Alligator clips (CAT III 1 000 V)



Figure 3: BENNING TA 2

- Set of safety measuring lines BENNING TA 3 (item no.: 044126)
Set of Ø 4 mm measuring lines, 8-piece, red / black, professional version, CAT III 1 000 V, consisting of:
 - Measuring lines (silicone)
 - Test probes (slender measuring probe)
 - Grabber clips
 - Alligator clips



Figure 4: BENNING TA 3

- Ø 4 mm silicone measuring lines with 2 mm and 4 mm measuring probes (item no.: 10231315)
6-piece, red / black, l = 1.0 m, with gold-plated Ø 2 mm and Ø 4 mm measuring probes (screw-on type, l = 18 mm), CAT IV / CAT III 1 000 V (with protective caps), CAT II 1 000 V (without protective caps)



Figure 5: Ø 4 mm silicone measuring lines with 2 mm and 4 mm measuring probes

4 Device description

4.1 Device structure



Figure 6: BENNING CM 3-PV device structure

1	Measuring clamp (for clamping the conductor)	2	Current clamp bulge (protection against contact with conductor)
3	Rotary switch	4	Digital display
5	Function keys	6	"V Ω μA Hz" jack
7	COM jack	8	Opening lever
9	NCV detection LED	10	Torch LED

Rear panel of the device

- Battery compartment with battery compartment cover
- Serial number (label)
- Notes and information about the device

Rotary switch

You can set the desired test or measurement by means of the rotary switch.




Figure 7: Rotary switch

1	Non-contact phase test (NCV)	2	Setting of the rotary switch
3	Device switched off	4	Current measurement via measuring clamp (A)
5	Voltage measurement	6	Resistance, capacitance measurement, continuity or diode testing
7	Current measurement via safety measuring lines (μA)	8	Frequency measurement

Digital display

The digital display is divided into different sections:

- Display of the currently set function and unit
- Battery status: Indicates the state of charge of the batteries (max. 4 segments). The batteries are discharged as soon as all segments have disappeared and the symbol is flashing.
- Display range: 3 3/4-digit liquid crystal display (LCD) with a font size of 9 mm and decimal points. The highest display value is 4 000 digits.
- Polarity display (automatic): Indicates a polarity contrary to the jack definition with “-”.

The background lighting [► page 20] can be enabled using the “HOLD / BACKLIGHT” function key.



Figure 8: Digital display

1	Display of functions	2	Battery status
3	Display range	4	Display of units
5	Polarity		

4.2 Functions

Use the rotary switch to switch the device on (desired measuring function) or off ("OFF").

The device switches off automatically after approx. 15 minutes (APO, Auto-Power-Off). To switch the device back on, first set the rotary switch to switch position "OFF" and then set the desired measuring function.

Press and hold the "SELECT / ZERO" key and move the rotary switch from "OFF" to any position to disable automatic switch-off. The "APO" symbol is hidden on the digital display.

Press and hold the "HOLD / BACKLIGHT" key and move the rotary switch from "OFF" to any position to enable automatic switch-off. The "APO" symbol is shown on the digital display.

4.2.1 "SELECT / ZERO" key

This key has two functions.

"SELECT" function (selecting a function)

Press the "SELECT / ZERO" key to select the second, third or fourth function of the respective rotary switch position.

Rotary switch position (symbol / designation)		Functions
	Non-contact phase test	NCV
	Frequency measurement	Hz
	Current measurement via safety measuring lines	µA-AC → µA-DC
	Resistance, capacitance measurement, continuity or diode testing	Resistance measurement (MΩ) → continuity test → diode test → capacitance measurement
	Voltage measurement	V-AC → V-DC → mV-AC → mV-DC
	Current measurement via measuring clamp	A-AC → A-DC

Table 4: Selecting a function

"ZERO (DC)" function

The "ZERO (DC)" function is intended to carry out a null balance before DC measurements via the measuring clamp.

To carry out the null balance, press and hold the "SELECT / ZERO" key for approx. 2 s until the "ZERO" symbol is shown on the digital display. The device must not be in the vicinity of a live conductor.

4.2.2 “HOLD / BACKLIGHT” key

This key has two functions.

“HOLD” function

The “HOLD” function is intended for holding the currently measured value.

To record the currently measured value, briefly press the “HOLD / BACKLIGHT” key. The “HOLD” symbol is shown on the digital display. To discard the held measured value and display the currently measured value again, briefly press the “HOLD / BACKLIGHT” key again.

“BACKLIGHT” function (background lighting)

The “BACKLIGHT” function is intended to enable the background lighting of the digital display.

Press and hold the “HOLD / BACKLIGHT” key for approx. 2 s to enable or disable the function.

4.2.3 “MIN/MAX / INRUSH” key

This key has two functions.

“MIN MAX” function

The “MIN MAX” function is intended to determine and store the minimum and maximum measured value during all measurements (DC and AC).

Briefly press the “MIN/MAX / INRUSH” key to enable or disable the function. With the function being enabled, the “MAX” or “MIN” symbol is shown on the digital display. Briefly press the “MIN/MAX / INRUSH” key to toggle the display.

- MAX: maximum stored measured value
- MIN: minimum stored measured value

“INRUSH” function (inrush current)

The “INRUSH” function uses the current initially measured via the measuring clamp as zero value.

If the device detects a current of more than 1 A, it starts sampling for 1 s (1 024 samples with a delay of 1 ms). As soon as sampling is complete, the inrush current will be calculated and displayed. Briefly press the “MIN/MAX / INRUSH” key to repeat the measurement.

Press and hold the “MIN/MAX / INRUSH” key for approx. 2 s to enable or disable the function. With the function being enabled, the “INRUSH” symbol is shown on the digital display.

4.2.4 “TORCH / LPF” key

This key has two functions.

“TORCH” function

The “TORCH” function is intended to enable the torch LED on the measuring clamp.

Briefly press the “TORCH / LPF” key to enable or disable the function.

“LPF (AC)” function (low-pass filter)

The “LPF” function is intended for connecting a low-pass filter (high-frequency suppression) during AC current measurement via the measuring clamp or during AC voltage measurement. With this low-pass filter, it is possible to filter out high-frequency pulses, e. g. on pulsed motor drives.

Press and hold the “TORCH / LPF” key for approx. 2 s to enable or disable the function. With the function being enabled, the “LPF” symbol is shown on the digital display. You can use the function for current measurement via the measuring clamp and for voltage measurement.

The limiting frequency (-3 dB) of the filter is $f_g = 1 \text{ kHz}$. When reaching the limiting frequency f_g , the displayed value is lower by a factor of 0.707 than the actual value without filter.




Table 5: Low-pass filter

4.2.5 Wireless data transmission

The device continuously transmits measured values to compatible PV testers via a radio interface (wireless connection).

4.3 Measuring ranges

The device is provided with an automatic switch-over of the measuring range. For this reason, a default setting is not required.

If a measuring range is exceeded, this is indicated by “OL” or “-OL” and, depending on the measuring function, additionally by an acoustic warning. Please note that there will be no indication and warning in case of overload.

Measuring accuracy

The measuring accuracy is specified as the sum of the following:

- Relative part of the measured value
- Number of digits (counting steps of the last digit)

The specified measuring accuracy is specified for 5 % to 100 % of the final measuring range value. This measuring accuracy applies to temperatures of 23 °C ±5 °C and a relative air humidity lower than 80 %. In case of deviating temperatures, observe the temperature coefficient by adding the following value to the specified measuring accuracy:

$0.2 [1/^{\circ}\text{C}] \times \text{specified measuring accuracy} \times \text{difference to reference temperature range } [^{\circ}\text{C}]$

Additional specifications for AC functions

The measured value is obtained and displayed as real r.m.s. value (TRUE RMS). For non-sinusoidal curves, the accuracy of the displayed value decreases. Thus, an additional error results for the following crest factors:

- Crest factor from 1.0 to 2.0: +0.3 %
- Crest factor from 2.0 to 2.5: +0.5 %
- Crest factor from 2.5 to 3.0: +1.5 %

Maximum crest factor of the measuring signal:

- 3.0 for up to 330 V
- 2.0 for up to 600 V
- 1.41 for more than 600 V
- 2.5 for up to 100 A
- 2.0 for up to 200 A
- 1.41 for more than 200 A

“LPF (AC)” function (low-pass filter)

Please observe the following features for the “LPF (AC)” function (low-pass filter for the V-AC and A-AC ranges):

- An additional error for AC current or AC voltage measurements is possible.
- Limiting frequency fg (-3 dB): 1 kHz

4.3.1 Voltage ranges

AC voltage ranges (V-AC)

Overload protection: 1 000 V-AC / 1 500 V-DC

Measuring range	Resolution	Measuring accuracy ^{1), 2)}
400 mV	1 mV	±(1.5 % + 5 digits)
4 V	0.001 V	±(1.0 % + 5 digits)
40 V	0.01 V	
400 V	0.1 V	
1 000 V	1 V	

Table 6: AC voltage ranges (V-AC)

- ¹⁾ Frequency range: 40 Hz ... 1 kHz
From 400 Hz on, the accuracy decreases with the frequency increasing.
- ²⁾ For mixed signals (AC + DC), only the pure AC component is taken into account.
 - Input resistance: 11 MΩ || < 500 pF

DC voltage ranges (V-DC)

Overload protection: 1 000 V-AC / 1 500 V-DC

Measuring range	Resolution	Measuring accuracy
400 mV	1 mV	±(1.5 % + 5 digits)
4 V	0.001 V	±(1 % + 3 digits)
40 V	0.01 V	
400 V	0.1 V	
1 500 V	1 V	±(1 % + 5 digits)

Table 7: DC voltage ranges (V-DC)

- Input resistance: 11 MΩ

4.3.2 Current ranges

AC ranges (A-AC)

Overload protection: 400 A-AC / A-DC

Measuring range	Resolution	Measuring accuracy ^{1), 2)}
40 A	0.01 A	±(2 % + 5 digits)
400 A	0.1 A	

Table 8: AC current ranges (A-AC)

- ¹⁾ Frequency range: 40 ... 400 Hz
- ²⁾ For mixed signals (AC + DC), only the pure AC component is taken into account.
 - Frequency range: 15 ... 400 Hz

DC ranges (A-DC)

Overload protection: 400 A-AC / A-DC

Measuring range	Resolution	Measuring accuracy
40 A	0.01 A	±(2 % + 5 digits)
400 A	0.1 A	

Table 9: DC ranges (A-DC)

AC ranges (µA-AC)

Overload protection: 1 000 V-AC / 1 500 V-DC

Measuring range	Resolution	Measuring accuracy ¹⁾
400 µA	0.1 µA	±(1.8 % + 5 digits)

Table 10: AC current ranges (µA-AC)

- ¹⁾ Frequency range: 40 Hz ... 1 kHz
From 400 Hz on, the accuracy decreases with the frequency increasing.

DC ranges (µA-DC)

Overload protection: 1 000 V-AC / 1 500 V-DC

Measuring range	Resolution	Measuring accuracy
400 µA	0.1 µA	±(2 % + 5 digits)

Table 11: DC ranges (µA-DC)

4.3.3 Resistance ranges

Overload protection: 1 000 V-AC / 1 500 V-DC

Measuring range	Resolution	Measuring accuracy ¹⁾
400 Ω	0.1 Ω	±(1.5 % + 3 digits)
4 kΩ	0.001 kΩ	
40 kΩ	0.01 kΩ	
400 kΩ	0.1 kΩ	
4 MΩ	0.001 MΩ	
40 MΩ	0.01 MΩ	

Table 12: Resistance ranges (Ω)

- ¹⁾ Before measuring, check for a possible offset by short-circuiting the measuring lines and subtract it from the measured value.

4.3.4 Continuity test

Overload protection: 1 000 V-AC / 1 500 V-DC

- The integrated buzzer sounds at a resistance lower than 10 ... 50 Ω.

4.3.5 Diode test

Overload protection: 1 000 V-AC / 1 500 V-DC

Measuring range	Resolution	Measuring accuracy
1.0 V	0.001 V	$\pm(10 \% + 10 \text{ digits})$

Table 13: Diode test

- Open-circuit voltage: approx. 1.5 V

4.3.6 Capacitance ranges

Requirements: Discharge the capacitors and apply the safety measuring lines according to the marked polarity.

Overload protection: 1 000 V-AC / 1 500 V-DC

Measuring range	Resolution	Measuring accuracy ^{1), 2)}
51.2 nF	0.1 nF	$\pm 10.0 \%$
512 nF	0.1 nF	$\pm(1.5 \% + 5 \text{ digits})$
5.120 μF	0.001 μF	$\pm(1.5 \% + 5 \text{ digits})$
51.2 μF	0.1 μF	$\pm 10.0 \%$
100 μF	1 μF	$\pm 10.0 \%$

Table 14: Capacitance ranges (μF)

- ¹⁾ Measuring accuracy applies to values $>10 \text{ nF}$
- ²⁾ Max. measuring time: 15 s (100 μF measuring range)

4.3.7 Frequency ranges

Overload protection: 1 000 V-AC / 1 500 V-DC

Measuring range	Resolution	Measuring accuracy
5 Hz	0.001 Hz	$\pm(0.1 \% + 1 \text{ digits})$
50 Hz	0.01 Hz	
500 Hz	0.1 Hz	
5 kHz	0.001 kHz	
50 kHz	0.01 kHz	
500 kHz	0.1 kHz	
5 MHz	0.001 MHz	

Table 15: Frequency ranges (Hz)

5 Operation

The device enables you to carry out various tests and measurements.

5.1 Requirements for tests and measurements

Please observe the following basic requirements for tests and measurements:

- Remove the device (safety measuring lines) from the measuring point before setting a switch position on the rotary switch of the device.
- Only use approved safety measuring lines [► page 27].
- Please consider sources of interference that might be present. Strong sources of interference in the vicinity of the device might involve unstable readings and measuring errors.
- For carrying out the tests and measurements, please observe the associated measuring ranges and measuring accuracies stated in the chapter “Measuring ranges” [► page 22].



DANGER

Maximum admissible voltage

Danger to life or serious injury is possible due to contact with high electric voltage.

- Use the device only in electric circuits up to overvoltage category IV with a conductor for a maximum of 1 000 V to earth.

5.2 Connecting the safety measuring lines

For certain tests and measurements, it is necessary to connect the safety measuring lines to the device.

Requirements

- Please observe the requirements for measuring [► page 26].
- Safety measuring lines

The safety measuring lines must be approved for the device (e. g. safety measuring lines included in the scope of delivery) and be in a technically perfect and operationally safe condition.

 - Check the specifications regarding nominal voltage and nominal current.
 - Check the insulation of the safety measuring lines.
 - Check the safety measuring lines for continuity.
 - Replace defective safety measuring lines.
- Protective caps (depending on the overvoltage category)
- During tests and measurements, only touch the safety measuring lines in the area intended for your hands.



⚠ WARNING

Dangerous voltage

Danger to life or serious injury is possible due to contact with high electric voltage in case of incorrect operation.

- Do not touch the bare measuring probe tips of the safety measuring lines or the bare contacts of the optional alligator clips. Only touch the safety measuring lines in the area intended for your hands.
- Connect the safety measuring lines to the correspondingly marked measuring jacks of the device and check them for tight fit.
- Only use approved safety measuring lines.
- Attach the protective caps to the contact tips of the safety measuring lines (circuits of overvoltage category III or IV).
- When disconnecting the measuring circuit, first remove the live safety measuring line (phase) and then the neutral safety measuring line from the measuring point.

Procedure

1. Connect the black safety measuring line to the COM jack of the device.
2. Connect the red safety measuring line to the “V Ω μ A Hz $\leftarrow$ $\rightarrow$ $\star$ ” jack of the device.
3. Measurements or tests in circuits of overvoltage category III or IV: Attach the protective caps to the contact tips of the safety measuring lines.

5.3 Voltage measurement

Requirements

- Please observe the requirements for measuring [► page 26].
- Approved safety measuring lines
- Voltage ranges [► page 23]



Figure 9: DC and AC voltage measurement

Procedure

1. Set the rotary switch of the device to switch position " $V_{\sim}$ ".
2. Press the "SELECT / ZERO" key to set the desired measuring function (AC or DC voltage).
3. Connect the safety measuring lines to the device [► page 27].
4. Bring the measuring points into contact with the safety measuring lines and read the measured value on the digital display.

5.4 Current measurement (A)

Requirements

- Please observe the requirements for measuring [► page 26].
- Make sure that no voltage is applied to the jacks of the device ("COM" and " $V \Omega \mu A Hz \text{ } \leftarrow \rightarrow$ "). Remove any connected safety measuring lines.
- Current ranges [► page 23]



Figure 10: Current measurement via measuring clamp (A)

Procedure

1. Set the rotary switch of the device to switch position " $A \text{ } \leftarrow \rightarrow$ ".
2. Press the "SELECT / ZERO" key to set the desired measuring function (AC or DC).
3. For DC measurements: Press and hold the "SELECT / ZERO" key for approx. 2 s to switch the device into the initial mode by means of a null balance. The "ZERO" symbol is shown on the digital display.
4. Operate the opening lever and clamp the single-wire live conductor centrally with the measuring clamp.
5. Read the measured value on the digital display.

5.5 Current measurement (μA)

Requirements

- Please observe the requirements for measuring [► page 26].
- Approved safety measuring lines
- Current ranges [► page 23]



Figure 11: Current measurement via safety measuring lines (μA)

Procedure

1. Set the rotary switch of the device to switch position " μA ".
2. Press the "SELECT / ZERO" key to set the desired measuring function (AC or DC).
3. Connect the safety measuring lines to the device [► page 27].
4. Bring the measuring points into contact with the safety measuring lines and read the measured value on the digital display.

5.6 Frequency measurement

Requirements

- Please observe the requirements for measuring [► page 26].
- Approved safety measuring lines
- Frequency ranges [► page 25]



Figure 12: Frequency measurement

Procedure

1. Set the rotary switch of the device to switch position "Hz".
2. Connect the safety measuring lines to the device [► page 27].
3. Bring the measuring points into contact with the safety measuring lines and read the measured value on the digital display.

5.7 Resistance measurement

Requirements

- Please observe the requirements for measuring [► page 26].
- Approved safety measuring lines
- Resistance ranges [► page 24]



Figure 13: Resistance, capacitance measurement, continuity or diode testing

Procedure

1. Set the rotary switch of the device to switch position "Ω".
The "Resistance measurement" function is set automatically ("MΩ" is displayed, "Ω" is hidden).
2. Connect the safety measuring lines to the device [► page 27].
3. Bring the measuring points into contact with the safety measuring lines and read the measured value on the digital display.

5.8 Continuity testing

Requirements

- Please observe the requirements for measuring [► page 26].
- Approved safety measuring lines
- Continuity test [► page 24]
- Please observe the figure for continuity testing [► page 32].

Procedure

1. Set the rotary switch of the device to switch position “”.
2. Connect the safety measuring lines to the device [► page 27].
3. Press the “SELECT / ZERO” key to set the “Continuity test” function (“” symbol).
4. Bring the measuring points into contact with the safety measuring lines.

When the buzzer sounds (acoustic signal), the line resistance between the COM jack and the “V Ω μ A Hz ” jack falls below the value of 10 to 50 Ω .

The accuracy of the displayed measured value is lower than it is for resistance measurement.

5.9 Capacitance measurement

Requirements

- Please observe the requirements for measuring [► page 26].
- Approved safety measuring lines
- Capacitance ranges [► page 25]



NOTICE

Capacitors not discharged

Measuring the capacitance at capacitors that are not fully discharged can damage the device.

- Discharge the capacitors completely before measuring the capacitance.
- Do not apply any voltage to the jacks of the device during the capacitance measurement.

- Please observe the figure for capacitance measurement [► page 32].

Procedure

1. Set the rotary switch of the device to switch position “”.
2. Connect the safety measuring lines to the device [► page 27].
3. Press the “SELECT / ZERO” key to set the “Capacitance measurement” function (“nF” symbol).
4. Bring the discharged capacitor into contact with the safety measuring lines observing correct polarity.
5. Read the measured value on the digital display.

5.10 Diode testing

Requirements

- Please observe the requirements for measuring [► page 26].
- Approved safety measuring lines
- Diode test [► page 25]
- Please observe the figure for diode testing [► page 32].

Procedure

1. Set the rotary switch of the device to switch position “”.
2. Connect the safety measuring lines to the device [► page 27].
3. Press the “SELECT / ZERO” key to set the “Diode test” function (“” symbol).
4. Bring the measuring points into contact with the safety measuring lines and read the measured value on the digital display.
 - Standard Si diode applied in forward direction: A forward voltage from 0.4 to 0.8 V is displayed.
 - “000”: indicates a short circuit inside the diode.
 - “OL”: indicates an interruption inside the diode.
 - Diode applied in reverse direction: “OL” is displayed. In case of defective diodes, “000” or other values will be displayed.

5.11 Voltage indicator



WARNING

Incorrect use of the function

Danger to life or serious injury is possible due to contact with high electric voltage if the “Voltage indicator” function is used incorrectly.

- Please observe that a dangerous contact voltage might be applied even if it is not indicated by a visual or acoustic signal.
- Do not use the “Voltage indicator” function to test for the absence of voltage.

5.11.1 Non-contact phase testing

An NCV antenna for non-contact detection of alternating fields is located on the right-hand side next to the rotary switch of the device. This position is marked with “NCV”)).

Requirements

- Please observe the requirements for measuring [► page 26].
- Make sure that no voltage is applied to the jacks of the device (“COM” and “V Ω μ A Hz $\rightarrow$ $\rightarrow$ $\rightarrow$ ”). Remove any connected safety measuring lines.



Figure 14: Non-contact phase test

Procedure

1. Set the rotary switch of the device to switch position “NCV”. “NCV” is shown on the digital display.
2. Place the position marked with the “NCV”)) symbol on the right-hand side next to the rotary switch near the measuring point.

If the NCV detection LED lights, the phase of an earthed alternating voltage is applied to this measuring area. The number of dashes shown on the LCD display corresponds approximately to the voltage level.

Practical tip

Interruptions (cable breaks) in exposed cables – e. g. in cable reels, chains of light, etc. – can be traced from the feeding point (phase) to the point of interruption.

Functional range: ≥ 230 V

6 Maintenance

The battery compartment may be opened for maintenance work. Apart from that, there are no components in the device that you can replace.



⚠ WARNING

Opening the device

Danger to life or serious injury is possible due to contact with high electric voltage when opening the device. The device might get damaged.

- Make sure that the device is free of voltage before opening the battery compartment.
- Do not open the device (except for the battery compartment).
- Please contact your specialty retailer or the returns management for any repairs [► page 9].

6.1 Maintenance schedule

The following table provides an overview of all maintenance and servicing work that you must carry out permanently or at regular intervals.

Interval	Measures
Regularly, as needed	• Cleaning the device [► page 37]
As needed	• Replacing the batteries [► page 37]
Every 12 months	• Calibrating the device [► page 38]

Table 16: Maintenance schedule

6.2 Making the device free of voltage

If you want to open the battery compartment for maintenance work, make sure first that the device is free of voltage.

Procedure

1. Remove the device from the measuring point.
2. Disconnect the safety measuring lines from the device.
3. Set the rotary switch of the device to switch position "OFF".

6.3 Cleaning the device

Clean the device regularly and as the need arises. Make sure that the battery compartment and the battery contacts are not contaminated by leaking battery electrolyte.

Requirements

- A clean and dry cloth or special cleaning cloth
- Voltage-free device [► page 36]



NOTICE

Wrong cleaning agents

Using the wrong cleaning agents can damage the device.

- Do not use any solvents, abrasives or polishing agents.

Procedure

1. Clean the exterior of the device with a clean and dry cloth or a special cleaning cloth.
2. Check the battery compartment. To open and close the battery compartment, follow the procedure given in the chapter "Replacing the batteries" [► page 37].
3. In case of electrolyte contamination or white deposits in the area of the battery or the battery compartment, clean the batteries and these areas by means of a clean and dry cloth. Replace the batteries, if necessary [► page 37].

6.4 Replacing the batteries

The device is powered by batteries. Replace the batteries as soon as they are discharged.

Requirements

- Discharged batteries inside the device (all segments of the battery symbol on the digital display have disappeared and the battery symbol is flashing)
- 2 new 1.5 V micro batteries (AAA / IEC LR03)
- Voltage-free device [► page 36]

Procedure

1. Place the device face down (onto an anti-slip surface).
2. Unscrew the two screws of the battery compartment cover.
3. Lift the battery compartment cover off the device.
4. Remove the discharged batteries from the battery compartment and dispose of them properly [► page 40].
5. Insert the new batteries into the battery compartment observing the correct polarity.
6. Place the battery compartment cover back onto the device and tighten the screws.

6.5 Calibrating the device

Benning guarantees compliance with this technical and accuracy specifications stated in this operating manual for the first 12 months after the delivery date.

To maintain accuracy of the measuring results, make sure that the device is recalibrated in annual intervals by the BENNING Service [► page 9].

<http://calibration.benning.de>



7 Technical data

Protection class	II (double or reinforced insulation)
Contamination level	2
Protection category (DIN VDE 0470-1, IEC / EN 60529)	IP40 1st digit: 4 = protection against access to dangerous parts and protection against solid impurities (diameter >1 mm) 2nd digit: 0 = no protection against water
Measuring category	CAT IV 1 000 V to earth
Housing dimensions (length x width x height)	220 mm x 80 mm x 42 mm
Max. clamp opening	30 mm
Weight (without batteries)	0.27 kg
Battery life (alkaline batteries)	approx. 60 h (without background lighting)
Safety measuring lines	
Standard	IEC / DIN EN 61010-031 (VDE 0411-031)
Measuring category (only applies to the safety measuring lines, additionally observe the limitations of the device)	• With attachable protective cap: – CAT IV 1 000 V to earth • Without attachable protective cap: – CAT II 1 000 V to earth
Protection class	II (double or reinforced insulation)
Contamination level	2
Max. rated current	10 A
Length	1.0 m
Operation	
Max. barometric altitude	2 000 m
Operating temperature	0 ... 50 °C (do not permanently expose the device to sunlight)
Max. relative air humidity	80 % RH (0 ... 50 °C), non-condensing
Storage (remove the batteries from the device)	
Ambient temperature	-10 ... 60 °C (do not permanently expose the device to sunlight)
Max. relative air humidity	80 % RH

Table 17: Technical data

8 Disposal and environmental protection



At the end of product life, dispose of the unserviceable device and the batteries via appropriate collecting facilities provided in your community.

Index

A

AC ranges (A-AC)	23
AC ranges (μ A-AC)	24
AC voltage ranges (V-AC)	23
Accessories	15
Auto-Power-Off	19

B

Background lighting	20
Basic knowledge	8
Battery	
Replacing	37
BENNING CM 3-PV	7

C

Calibrating	38
Capacitance ranges	25
Capacitance measurement	33
Cleaning	37
CM 3-PV	7
Continuity testing	33
Copyright	2
Current measurement (A)	29
Current measurement (μ A)	30

D

DC ranges (A-DC)	24
DC ranges (μ A-DC)	24
DC voltage ranges (V-DC)	23
Device	
Calibrating	38
Cleaning	37
Securing	13
Digital display	18
Diode test	25
Diode testing	34
Disclaimer	2, 12
Disposal	40
Documentation	2

E

Environmental protection	40
--------------------------	----

F

Frequency measurement	31
Frequency ranges	25
Function	

APO	19
BACKLIGHT	20
HOLD	20
INRUSH	20
LPF	21, 22
MIN MAX	20
SELECT	19
TORCH	21
ZERO (DC)	19
Further information	7

H

History	8
Holder of rights	2

I

Inrush current	20
Intended use	12

K

Key	
HOLD / BACKLIGHT	20
MIN/MAX / INRUSH	20
SELECT / ZERO	19
TORCH / LPF	21

L

Low-pass filter	21, 22
-----------------	--------

M

Maintenance	36
Maintenance schedule	36
Manufacturer	2
Measurement	
Requirements	26
Measuring accuracy	22
Measuring ranges	22
AC ranges (A-AC)	23
AC ranges (μ A-AC)	24
AC voltage ranges (V-AC)	23
Capacitance ranges	25
DC ranges (A-DC)	24
DC ranges (μ A-DC)	24
DC voltage ranges (V-DC)	23
Diode test	25
Frequency ranges	25
Resistance ranges	24

N

Non-discrimination	2
--------------------	---

O

Operation	26
-----------	----

P

Phase testing	35
Purpose of the operating manual	8

R

Rear panel of the device	17
Resistance ranges	24
Resistance measurement	32
Return address	9
Returns management	9
Rotary switch	18

S

Safety measuring lines	
Connecting	27
Scope of delivery	15
Securing	13
Selecting a function	19
Service & Support	
Technical Support	9
Standards applied	10
Symbols	
Device	11
Operating manual	11

T

Target group	8
Technical data	39
Technical Support	9
Test	
Requirements	26
Torch	21
Trademarks	8

V

Voltage indicator	35
Practical tip	35
Voltage measurement	28
Voltage-free	36

W

Warning system	10
Warranty	12
Wireless data transmission	21



BENNING Elektrotechnik und Elektronik GmbH & Co. KG

Münsterstraße 135 - 137

D - 46397 Bocholt

Phone: +49 2871 93-0 Fax: +49 2871 93-429

Internet: www.benning.de

E-Mail: duspol@benning.de

The text and illustrations correspond to the state of technology at the time of printing. Subject to technical changes. No liability accepted for printing errors.