



LANTEK IV-S

THE FUTURE OF CABLE
CERTIFICATION

QUICK REFERENCE GUIDE



TREND NETWORKS

Depend On Us

LanTEK IV-S

Quick Reference Guide

163819 rev1 2022

TREND NETWORKS
Stokenchurch House
Oxford Road
Stokenchurch
High Wycombe
Buckinghamshire
HP14 3SX
United Kingdom

© TREND NETWORKS 2022

The information contained in this document is the property of TREND NETWORKS and is supplied without liability for errors and omissions. No part of this document may be reproduced or used except as authorized by contract or other written permission from TREND NETWORKS. The copyright and all restrictions on reproduction and use apply to all media in which this information may be placed. TREND NETWORKS pursues a policy of continual product improvement and reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service. All rights reserved.

English

Les informations dans ce document sont la propriété de TREND NETWORKS et elles sont fournies sans responsabilité pour les erreurs et les omissions. Aucune partie de ce document ne doit être reproduite ou utilisée, sauf en cas d'autorisation par contrat ou en cas d'autre autorisation écrite donnée par TREND NETWORKS. Le copyright et toutes les limitations concernant la reproduction et l'utilisation s'appliquent à tous les supports sur lesquels cette information peut être placée. TREND NETWORKS améliore continuellement ses produits et se réserve le droit de modifier sans préavis la spécification, la conception, le prix ou les conditions de fourniture d'un produit ou d'un service. Tous droits réservés.

Français

Die Informationen in diesem Dokument sind das Eigentum von TREND NETWORKS und werden ohne Gewährleistung der Vollständigkeit oder Korrektheit gegeben. Dieses Dokument darf nur soweit vertraglich oder anderweitig schriftlich von TREND NETWORKS zugesichert ganz oder teilweise vervielfältigt werden. Das Urheberrecht und alle Einschränkungen zur Vervielfältigung und Nutzung gelten für alle Datenträger, auf denen diese Informationen gespeichert werden können. TREND NETWORKS bemüht sich um ständige Produktverbesserungen und behält sich das Recht vor, die Spezifikation, das Design, den Preis oder die Lieferbedingungen jeglicher Produkte oder Dienste ohne Vorankündigung zu ändern. Alle Rechte vorbehalten.

Deutsch

Le informazioni contenute nel presente documento sono di proprietà di TREND NETWORKS e sono fornite senza alcuna responsabilità relativa a errori e omissioni. Sono vietati la riproduzione o l'uso di tutto il documento o parte di esso, salvo se autorizzati da contratto o permesso scritto di TREND NETWORKS. Il copyright e tutte le limitazioni sulla riproduzione e l'uso si applicano a tutti i supporti nei quali le presenti informazioni possono essere contenute. TREND NETWORKS segue una politica volta al miglioramento continuo dei prodotti e si riserva il diritto di modificare senza preavviso le specifiche, il disegno, il prezzo o le condizioni di fornitura di qualsivoglia prodotto o servizio. Tutti i diritti riservati.

Italiano

La información que figura en este documento es propiedad de TREND NETWORKS quien no asume responsabilidad alguna sobre posibles errores u omisiones que puedan existir en este documento. Queda prohibida la reproducción parcial o total de este documento, así como darle un uso distinto al autorizado mediante contrato o autorización escrita por parte de TREND NETWORKS independientemente del formato y soporte de los contenidos. TREND NETWORKS sigue una política de mejora continua del producto y nos reservamos el derecho de modificar sin previo aviso las especificaciones, diseño, precio o condiciones de suministro de cualquier producto o servicio. Todos los derechos reservados.

Español

As informações contidas neste documento são de propriedade de TREND NETWORKS e são fornecidas sem responsabilidade sobre erros e omissões. Nenhuma porção deste documento pode ser reproduzida ou usada exceto quando autorizada mediante contrato ou outra permissão por escrito da TREND NETWORKS. Os direitos de cópia e restrições de reprodução e uso são aplicáveis a todas as mídias nas quais estas informações possam ser colocadas. A TREND NETWORKS segue uma política de melhoria contínua do produto e se reserva ao direito de alterar sem aviso prévio as especificações, design, preço ou condições de fornecimento de qualquer produto ou serviço. Todos os Direitos Reservados.

Português

本文件所包含的信息是美国理想工业公司 (TREND NETWORKS) 的财产, 对于本文件中出现的错误或遗漏, 提供方概不负责。除非得到美国理想工业公司的合同授权或其他书面许可, 否则, 本文件的任何部分均不得复制或/或使用。版权和对复制和使用的所有限制都适用于本信息发布的一切媒介。美国理想工业公司奉行持续改进产品的政策, 并保留在不事先通知的情况下变更任何产品或服务的规格、设计、价格或供货条件的权利。保留所有权利。

中文

INTRODUCTION


The LanTEK IV-S and TREND AnyWARE are a Cable Certification System. This guide will give you an overview of the key features of LanTEK IV-S and how to start using AnyWARE to manage your project and test results.

EN


GETTING STARTED

Before you start using your LanTEK IV-S follow the steps below to ensure you can take advantage of all the features your LanTEK IV-S has to offer.


1. Fully charge the display and remote units using the power supply included in your case. This can be connected to the main charging port on the LanTEK IV-S or the quick charge port on the battery. The quick charge port reduces the charging time by 50%. To access the quick charge port the battery must first be removed by releasing the retaining screw.



2. Select the language by selecting the setup gear at the top left of the screen.







3. Visit anyware.trend-networks.net to setup your free TREND AnyWARE account to Manage, Share, Edit and Pre-configure your projects. Select; sign up for cloud based software or download for the desktop version.



EN

4. Link your LanTEK IV-S to your TREND AnyWARE Account by logging into your TREND AnyWARE account.

- Select Menu:  Click Devices:  Devices Add Device: 
- Enter your Device ID and select submit. The LanTEK IV-S device ID is found in the settings menu (below).



HELP OPTIONS

LanTEK IV-S and AnyWARE cloud have a comprehensive on-board help which will guide you through how to use the features. This can be accessed as follows;

EN

Help on the LanTEK IV-S



Icon on the Menu Bar



Or click Settings - Usage

Guides: >

Help on the AnyWARE Cloud

AnyWARE Cloud assistance can be accessed by the Walk Me Through tab located on the bottom right-hand side.

Walk Me Through ^

Return to home screen

Create new job

Multiple job select

Sort jobs by date

Sort jobs by name

15 Tests Library

500 Tests Hospital Bldg 2

75 Tests Hospital Bldg 1

113 Tests Tower 1-Floor 19

89 Tests Tower 1-Floor 20

12 Tests Store 328

19 Tests Store 329

List of all jobs saved to your LanTEK IV-S

Long press job for short cut options

Total number of tests within each project

- View tests
- Clear sync status
- Edit
- Set as current
- Delete

Jobs

15 Tests Library

500 Tests Hospital Bldg 2

75 Tests Hospital Bldg 1

113 Tests Tower 1-Floor 19

89 Tests Tower 1-Floor 20

12 Tests Store 328

19 Tests Store 329

Delete

KEY FUNCTIONS

LanTEK IV-S

High Voltage Warning
Disconnect cable immediately

Status Connection
Blue when both units are connected

EN




VisiLINQ™

VisiLINQ™ incorporates a multi-color LED indicator and action button to initiate tests and report the status independent of the tester handsets.

Action button;
Press to activate white torch when not linked.
Press to initiate Autotest when handsets are linked



Field Replaceable Tip






LED Indicator
Blue = Display and Remote connected
Green = Pass
Red = Fail
Amber = Marginal Pass/Fail
White = Torch mode

HOME SCREEN


The LanTEK IV-S home screen has been designed to display the details of the current project in either Standard mode or Advanced mode. Press the Settings button to change the Operation mode between Standard or Advanced. Standard is the default mode.

EN Setting the Operating Mode



HOME SCREEN (Standard)

The Standard mode displays all of the settings needed to perform a test on a single screen and is used when sequential test IDs are used, or each ID needs to be manually entered.



HOME SCREEN (Advanced Mode)

The Advanced mode is used primarily when a pre-defined list of test ID's has been created in the LanTEK or downloaded from AnyWARE Cloud.

EN

Test Count is the number of tests saved/ total memory capacity

Settings and Help

Active job name, total number of tests and progress bar
Red = Fail
Green = Pass
Grey = Untested

Last test completed

Test list display options

List of tests in the current job:
Green = Pass
Red = Fail
Amber = Marginal
Tap to view test results

Start test

Long press to access test options:

JOBS menu displays all jobs stored on the tester

SYNC to upload/download tests to AnyWARE Cloud or export to USB drive

Tap to view test results


Legend:
Yellow = Next test execute when VisILINQ action/ Autotest button pressed

Test Legend:
Red = Fail
Green = Pass
Grey = Untested

	End	Margin dB	Freq MHz	
WIREFMAP	-	-	-	✓
NEXT	📶	5.5	500	✓
RL	📶	12.0	11.6	✓
IL	📶	2.9	1.0	✓
PSNEXT	📶	6.5	499	✓

SETTINGS

The settings can be accessed from the settings menu on the home screen.



Choose language | **Set Language** (US English)

Connect to a hotspot/Wi-Fi | **Wi-Fi**

Set reference for Cat 8.2, patch cord adapters and fiber jumper calibration | **Set Reference**

View calibration details/export calibration certificate to USB as PDF file | **Calibration**

Start tone generator | **Tone Test**

Software version, serial number and MAC address | **Device Settings** (Sound, Display, Storage)

How to use your LanTEK IV-S | **System Settings**


Device ID, required to register your LanTEK IV-S with AnyWARE cloud | **About**

Device ID, required to register your LanTEK IV-S with AnyWARE cloud | **Usage Guides**

Device ID, required to register your LanTEK IV-S with AnyWARE cloud | **Device ID**

EN

Autotest settings are your preferred set-up for a Job. LanTEK IV-S will use these settings as default for all new jobs to reduce set-up time



Regional Settings (Datetime, Formats and Unit settings) | **Set the date/time and measurement units**

Operator Details | **Set operator name**


Autotest Default Settings | **Autotest Default Settings**

Sound / Volume | **Sound on and off**

Display Brightness (Screen brightness at 100%) | **Screen brightness**

Remote Control Settings | **Activate remote control (Team Viewer)**

UI Settings | **Show cursor when using USB mouse**



Autotest settings

Test Range: Port-01

Default job identifier type

Not Required

Test prefix

Port

Starting range

01


End range

16


Test standard

Selected standard
ISO IEC > PL > EA > Class EA PL3

CREATING A JOB


To create a job, select JOBS from the menu bar and then select: 

EN




1

Enter job name and if required, select the job identifiers (optional). This will allow tests to be grouped specifically by building, floor, etc. Select ✓ when complete.




3

Select + to add tests to the job, then choose Copper or Fiber



2

Select the newly created job from the jobs screen.



4

In Create Tests, enter the prefix (optional) and the test range.

Test Ranges

Enter an alpha-numeric value in Test Range from: that is the first test ID of a sequence. Then enter the last value of the sequence in Test range to: generate the list of test ID's. A red warning will be shown if the from and to ranges cannot create a continuous series.

CREATING A JOB

< Create Tests ✓

Test Range: Port01:24

Test prefix

Port

Test range from:

01

Test range to:

24

Test standard

Selected standard
ISO IEC > PL > EA > Class EA PL3

5 Select standard

< Cable Standard ✓

Select a group

TIA

ISO IEC

Cenelec

Custom

AS NZ 3080

China

Japan

Korea

6 Choose the appropriate standard

< Cable Standard ✓

< ISO IEC Standard

< PL Link model

< EA Grade

< Class EA PL3 Cable type

Cable details

Cable
Cat6a-STP

Connector brand (Near)
Generic

Connector brand (Far)
Generic

7 Choose type of link

Cable details

Cable
Cat6a-STP

Connector brand (Near)
Generic

Connector brand (Far)
Generic

NVP Cable shielded

0.75

8 Optional Step, During the set-up the Cable and Connector manufacture can be selected to add more detail to the finished report

< Pick a brand

Select Manufacturer

3M

BKS

Belden

BlackBox

Commscope

Connectix

DRAKA

Datwyler

Datwyler Uninet

< Create Tests ✓

Test Range: Port01:24

Test prefix

Port

Test range from:

01

Test range to:


24

Test standard

Selected standard
ISO IEC > PL > EA > Class EA PL3

9 Select ✓ when completed


CONNECTING TO WI-FI

To connect LanTEK IV-S to Wi-Fi, firstly select the Settings menu 

EN




Select Wi-Fi from the Settings menu and switch toggle to turn on Wi-Fi.



Select your chosen Network and enter password (if required).


Wi-Fi successfully connected 



SYNCHRONISING

Selecting SYNC will allow you to download pre-configured jobs or upload completed jobs to the cloud. If you are using the TREND AnyWARE desktop SYNC will also allow you to download results to USB. To SYNC your LanTEK IV-S:

Select SYNC



Download all new jobs from the cloud

Display a list of jobs and select the job(s) to be downloaded from the cloud

Download all new jobs from a USB drive

Display a list of jobs and select the job(s) to be downloaded from a USB drive

Upload all jobs to the cloud

Display a list of jobs and select the job(s) to be uploaded to the cloud

Upload all new jobs to a USB drive




Display a list of jobs and select the job(s) to be uploaded to a USB drive

LIVE WIREMAP

Live Wiremap allows an instant, constantly updating Wiremap view for connected links without the need to perform an Auto test. Live Wiremap can be used in two ways. In an active job or free mode which does not require a project to be set-up.

EN


To activate Live Wiremap in free mode. Swipe down from the top of the screen.



Activate Live Wiremap in a job select the test list options menu.

CREATING A TEST REPORT

Jobs can be reviewed and edited using TREND AnyWARE Cloud or Desktop, Jobs synced via Wi-Fi will automatically be added to jobs menu of the cloud.



Key:



Upload jobs from USB using the Cloud and Desktop Swipe down from the top of the screen



View, download and email PDF reports



Download report



Generate a PDF test report



Share the report via an email link where the recipient can view and save the report

Name	Type	Status	Customer Name	Total Tests	File Size	Created At
My Job	Brief	Completed	Radio Controls LTD	25	8968KB	15/10/2019, 09:22
Main Campus	Brief	Completed	Amazon	25	8971KB	15/10/2019, 09:21
First Bank	Brief	Completed	Amazon	25	8971KB	15/10/2019, 09:20



TREND NETWORKS, LanTEK, FiberTEK, VisiLING and the TREND AnyWARE logos are trademarks or registered trademarks of TREND NETWORKS

TREND NETWORKS
TREND Networks House, 728 London Road,
High Wycombe, Buckinghamshire, HP11 1HE, UK
Tel. +44 (0)1925 428 380 | Fax. +44 (0)1925 428 381
uksales@trend-networks.com

www.trend-networks.com

Specification subject to change without notice.
E&OE

© TREND NETWORKS 2023