



Albrecht ATR400 und ATT400 Ladekoffer

Inbetriebnahme:

1. Stellen Sie den Ladekoffer auf eine ebene Fläche.
2. Schließen Sie das mitgelieferte Netzkabel an den Netzanschluss des Koffers an.
3. Schließen Sie nun das andere Ende an eine Steckdose an.
4. Schalten Sie den Koffer über den Netzschalter außen am Gerät ein.
5. Stecken Sie die ausgeschalteten ATR/ATT400 in die Ladestation. Die Ladkontakte befinden sich am Boden des Geräts.
6. Der Ladevorgang dauert bei komplett entladem Akku ca. 3-4 Stunden. Bei voller Ladung wechselt das Kontrolllicht am ATT/ATR400 von „Rot“ auf „Grün“.



Hinweise:

Der Ladekoffer sowie die Akkus der Sender und Empfänger können sich während des Aufladens erwärmen. Stellen Sie Folgendes sicher, damit diese Wärme entweichen kann:

- Die Luft muss frei durch die Lüftungsöffnungen zirkulieren können.
- Setzen Sie den Ladekoffer keinen Wärmequellen und keinem direkten Sonnenlicht aus.
- Der Deckel des Koffers sollte während des Ladevorgangs nicht geschlossen werden.

Serviceanschrift und technische Hotline (für in Deutschland verkaufte Geräte)

Alan Electronics GmbH
Service
Daimlerstraße 1K
63303 Dreieich
Deutschland

Sie erreichen unsere Service-Hotline telefonisch unter **+49 (0) 6103 9481 66** (zum Preis für eine Verbindung ins deutsche Festnetz) oder per E-Mail an **service@alan-electronics.de**

Konformitätserklärung



Hiermit erklärt Alan Electronics GmbH, dass die Ladekoffer für das Albrecht ATR400 System der Richtlinie 2014/30/EU entsprechen. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar:
<http://service.alan-electronics.de/CE-Papiere/>



Albrecht ATR400 and ATT400 charging case

Operation:

1. Place the charging case on a flat surface.
2. Connect the supplied power cord to the power connector
3. Plug the other end into an electrical outlet.
4. Switch the charger on with the mains switch on the outside of the unit.
5. Insert the switched-off ATR / ATT400 into the charging stations. The charging contacts are located at the bottom of the device.
6. The charging process takes about 3-4 hours when the battery is completely discharged. When fully charged, the control light on the ATT / ATR400 changes from "red" to "green".

Notes:

The charging case and the batteries of the transmitter and receiver may warm up during charging. Make sure that the heat can escape:

- The air must be able to circulate freely through the ventilation openings.
- Do not expose the charging case to heat sources or direct sunlight.
- The lid of the case should not be closed during the charging process



Service Address and Technical Hotline (for units sold in Germany)

Alan Electronics GmbH
Service
Daimlerstraße 1K
63303 Dreieich
Germany

Contact our service hotline by phone **+49 (0) 6103 9481 66** (regular costs for German fixed network) or e-mail at service@alan-electronics.de

Declaration of Conformity



Hereby, Alan Electronics GmbH declares that the charging case for the Albrecht ATR400 system is in compliance with Directive 2014/30/EC. The full text of the EU declaration of conformity is available at the following internet address:
<http://service.alan-electronics.de/CE-Papiere/>