



# ASSEMBLY INSTRUCTION

## NYS 373-\* | Heavy duty Phono Plug

**A** Slide the boot onto the cable.

**B** Prepare cable as shown.

**C** Solder the wire ends.

**D** Position the chuck onto the cable and align chuck with plugfinger.

**E** Slide the housing onto the Plugfinger with chuck.

**F** Finish the installation by tighten the bushing onto the connector.

**Attention: If using a cable with big O.D. break off marked part on the chuck.**

6.0 mm [0.24"]

8.0 mm [0.32"]

3.0 mm [0.12"]

break off

NEUTRIK AG	LI	T: +423 / 237 24 24	F: +423 / 232 53 93	NEUTRIK France	FR	T: +33 1 / 4131 6750	F: +33 1 / 4131 0511
NEUTRIK USA Inc.	USA	T: +1 732 / 901 9488	F: +1 732 / 901 9608	NEUTRIK Tokyo Ltd.	JP	T: +81 3 / 3663 4733	F: +81 3 / 3663 4796
NEUTRIK (UK) Ltd.	UK	T: +44 1983 / 811 441	F: +44 1983 / 811 439	NEUTRIK Hong Kong Ltd.	HK	T: +852 / 2687 6055	F: +852 / 2687 6052
NEUTRIK Vertriebs GmbH	DE/NL/AT/DK	T: +49 8131 / 280 890	F: +49 8131 / 280 830				

Draft. Nr.: BDA 262-0 / 3102M1811 | Update: 21.01..2010 | Data subject to change without prior notice. © 2010 NEUTRIK® . ALL RIGHTS RESERVED.