



# ASSEMBLY INSTRUCTION

## NYS 373-\* | Heavy duty Phono Plug

**A** Slide the boot onto the cable.

**B** Prepare cable as shown.

**C** Solder the wire ends.

**D** Position the chuck onto the cable and align chuck with plugfinger.

**E** Slide the housing onto the Plugfinger with chuck.

**F** Finish the installation by tighten the bushing onto the connector.

**Attention:** If using a cable with big O.D. break off marked part on the chuck.

NEUTRIK AG LI T: +423 / 237 24 24 F: +423 / 232 53 93  
NEUTRIK USA Inc. USA T: +1 732 / 901 9488 F: +1 732 / 901 9608  
NEUTRIK (UK) Ltd. UK T: +44 1983 / 811 441 F: +44 1983 / 811 439  
NEUTRIK Vertriebs GmbH DE/NL/AT/DK T: +49 8131 / 280 890 F: +49 8131 / 280 830

NEUTRIK France FR T: +33 1 / 4131 6750 F: +33 1 / 4131 0511  
NEUTRIK Tokyo Ltd. JP T: +81 3 / 3663 4733 F: +81 3 / 3663 4796  
NEUTRIK Hong Kong Ltd. HK T: +852 / 2687 6055 F: +852 / 2687 6052

Draft. Nr.: BDA 262-0 / 3102M1811 | Update: 21.01..2010 | Data subject to change without prior notice. © 2010 NEUTRIK® . ALL RIGHTS RESERVED.

[www.rean-connectors.com](http://www.rean-connectors.com)

**REAN**  
REAN a brand of Neutrik AG