



**855135 ProClip** ONLY for Comfort Dashboard WITHOUT a lid on the middle storage pocket.

Center mount

The ProClip is a mounting bracket that you attach onto the vehicle's dashboard. It provides a mounting platform for mobile phones and other devices that you want to have within easy sight and reach in the car. Safe, neat and convenient! The ProClip has a perfect fit, it is custom made for each vehicle to ensure a secure base for installations.

The ProClip is easy to install. The bracket simply snaps into place in gaps in the dashboard, you do not need to drill holes, not use special tools or not dismantle the dashboard. Made in black ABS plastic. Comes with detailed installation instructions. The mounting plate is equipped with predrilled holes which make the installation of equipment on the ProClip easier. The holes suit all Brodit holders and other products with standard holes, the hole pattern consists of one set of AMPS-holes as well as two sets of double-holes placed in different height.

ONLY for Comfort Dashboard WITHOUT a lid on the middle storage pocket.

For models with Premium Dashboard WITH a lid on the middle storage pocket, please see Volkswagen Multivan.

EAN: 7320288551357

**Item no 855135 fits:**

Volkswagen Caravelle 16-20 (For Europe)

Volkswagen T6 Transporter/Pickup 16-20 (For Europe)

## INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before installing the ProClip.

Important! This ProClip will cover the 12V socket on top of the dash, there will be approximately 40mm between the socket and the ProClip. The ProClip can also be placed on the right airvent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Insert the angled upper edge of the ProClip into the gap dividing the top part of the dashboard.
  2. Press the angled edge all the way into the gap.
  3. Pull the lower part of the ProClip toward you and hook the angled lower edge around the upper edge of the air vent.
  4. The ProClip is in place.
-