



855303 ProClip

Center mount

Keep your device within easy sight and reach in your car! The ProClip makes it easier and safer to use handheld devices in vehicles. The ProClip is a mounting bracket that you attach to the dashboard of your car. Onto the ProClip, you can install any accessory, e.g. a holder for mobile phone or other communication device.

The ProClip is car specific, it is customized for each car model and has a perfect fit. The ProClip offers a firm mounting platform and is available in multiple positions for most vehicles. Discreet design that blends in well with the interior. Safe, neat and convenient!

The ProClip is easy to install, you can do it in a minute! You simply snap the ProClip into place in gaps in the interior, you do not need to drill holes or use special tools or dismantle the dashboard. Detailed mounting instructions included. The ProClip has predrilled AMPS holes for easy installation of a holder. Made of high grade ABS/Acetal plastic. Color: Black. Developed and produced in Sweden.

- Do you want to be able to switch between several holders on the same ProClip? Please see Brodit's MultiMoveClip.
- Are you installing larger devices or heavier equipment? Please see Brodit's Extra Strength Mounting Platforms and Pedestal Mounts.

EAN: 7320288553030

Item no 855303 fits:

MAN TGE 19-21 (For Europe)

Volkswagen Crafter 17-21 (For Europe)

INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can also be placed by the right air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap above the dashboard, to widen the gap between the dashboard and the compartment. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip under the frame surrounding the air vent.
 2. Press the upper part of the ProClip forward so the curved edge hooks into the gap next to the gap opener.
 3. Press the upper edge of the ProClip all the way into the gap. Pull out the gap opener.
 4. The ProClip is in place.
-