



Drucktaster mit LED's



Pushbutton Switches with LED's



LED Type	Farbe/ Colour	Art.-Nr.
A60	2x rot/red	1871.2231
A61	2x gelb/yellow	1871.7731
A62	2x grün/green	1871.8831

Drehschalter mit LED's

Rotary-Switch with LED's



LED Type	Farbe/ Colour	Art.-Nr.
A60	2x rot/red	1872.2231
A61	2x gelb/yellow	1872.7731
A62	2x grün/green	1872.8831