WAGO-I/O-SYSTEM III

Fieldbus Independent I/O Modules

End Module 750-600



Manual

Version 1.0.2



Copyright © 2006 by WAGO Kontakttechnik GmbH & Co. KG All rights reserved.

WAGO Kontakttechnik GmbH & Co. KG

Hansastraße 27 D-32423 Minden

Phone: +49 (0) 571/8 87 – 0 Fax: +49 (0) 571/8 87 – 1 69

E-Mail: info@wago.com

Web: http://www.wago.com

Technical Support

Phone: +49 (0) 571/8 87 – 5 55 Fax: +49 (0) 571/8 87 – 85 55

E-Mail: support@wago.com

Every conceivable measure has been taken to ensure the correctness and completeness of this documentation. However, as errors can never be fully excluded, we would appreciate any information or ideas at any time.

E-Mail: documentation@wago.com

We wish to point out that the software and hardware terms as well as the trademarks of companies used and/or mentioned in the present manual are generally trademark or patent protected.



CONTENT

1 Important Comments				
	Legal Principles			
	Copyright			
1.1.2	Personnel Qualification	4		
1.1.3	Intended Use			
1.2	Symbols	5		
1.3	Number Notation	5		
1.4	Safety Notes	6		
1.5	Scope	6		
2 I/C	O Modules	7		
	System Modules			
2.1.1	750-600 [End Module]	7		
2.1.1.				
2.1.1.	2 Description	7		
2.1.1.	3 Display Elements	7		
211.	4 Technical Data	Q		

1 Important Comments

To ensure fast installation and start-up of the units described in this manual, we strongly recommend that the following information and explanations are carefully read and abided by.

1.1 Legal Principles

1.1.1 Copyright

This manual is copyrighted, together with all figures and illustrations contained therein. Any use of this manual which infringes the copyright provisions stipulated herein, is not permitted. Reproduction, translation and electronic and photo-technical archiving and amendments require the written consent of WAGO Kontakttechnik GmbH & Co. KG. Non-observance will entail the right of claims for damages.

WAGO Kontakttechnik GmbH & Co. KG reserves the right to perform modifications allowed by technical progress. In case of grant of a patent or legal protection of utility patents all rights are reserved by WAGO Kontakttechnik GmbH & Co. KG. Products of other manufacturers are always named without referring to patent rights. The existence of such rights can therefore not be ruled out.

1.1.2 Personnel Qualification

The use of the product detailed in this manual is exclusively geared to specialists having qualifications in PLC programming, electrical specialists or persons instructed by electrical specialists who are also familiar with the valid standards. WAGO Kontakttechnik GmbH & Co. KG declines all liability resulting from improper action and damage to WAGO products and third party products due to non-observance of the information contained in this manual.

1.1.3 Intended Use

For each individual application, the components supplied are to work with a dedicated hardware and software configuration. Modifications are only permitted within the framework of the possibilities documented in the manuals. All other changes to the hardware and/or software and the non-conforming use of the components entail the exclusion of liability on part of WAGO Kontakttechnik GmbH & Co. KG.

Please direct any requirements pertaining to a modified and/or new hardware or software configuration directly to WAGO Kontakttechnik GmbH & Co. KG.



1.2 Symbols



Danger

Always abide by this information to protect persons from injury.



Warning

Always abide by this information to prevent damage to the device.



Attention

Marginal conditions must always be observed to ensure smooth operation.



ESD (Electrostatic Discharge)

Warning of damage to the components by electrostatic discharge. Observe the precautionary measure for handling components at risk.



Note

Routines or advice for efficient use of the device and software optimization.



More information

References on additional literature, manuals, data sheets and INTERNET pages

1.3 Number Notation

Number Code	Example	Note	
Decimal	100	normal notation	
Hexadecimal	0x64	C notation	
Binary		Within ', Nibble separated with dots	



1.4 Safety Notes



Warning

Switch off the system prior to working on bus modules!

In the event of deformed contacts, the module in question is to be replaced, as its functionality can no longer be ensured on a long-term basis.

The components are not resistant against materials having seeping and insulating properties. Belonging to this group of materials is: e.g. aerosols, silicones, triglycerides (found in some hand creams).

If it cannot be ruled out that these materials appear in the component environment, then additional measures are to be taken:

- installation of the components into an appropriate enclosure
- handling of the components only with clean tools and materials.



Attention

Cleaning of soiled contacts may only be done with ethyl alcohol and leather cloths. Thereby, the ESD information is to be regarded.

Do not use any contact spray. The spray may impair the functioning of the contact area.

The WAGO-I/O-SYSTEM 750 and its components are an open system. It must only be assembled in housings, cabinets or in electrical operation rooms. Access must only be given via a key or tool to authorized qualified personnel.

The relevant valid and applicable standards and guidelines concerning the installation of switch boxes are to be observed.



ESD (Electrostatic Discharge)

The modules are equipped with electronic components that may be destroyed by electrostatic discharge. When handling the modules, ensure that the environment (persons, workplace and packing) is well grounded. Avoid touching conductive components, e.g. gold contacts.

1.5 Scope

This manual describes the Digital Input Module 750-600 End Module of the modular WAGO-I/O-SYSTEM 750.

Handling, assembly and start-up are described in the manual of the Fieldbus Coupler. Therefore this documentation is valid only in the connection with the appropriate manual.



2 I/O Modules

2.1 System Modules

2.1.1 750-600 [End Module]

End Module

2.1.1.1 View




Fig. 2.1.1-1: End Module 750-600

g060000e

2.1.1.2 Description

The end module 750-600 is used to terminate the internal bus of a fieldbus node. This module completes the internal data circuit and ensures correct data flow.

The end module is placed at the end of a filedbus node.



Attention

The end module must be used with all Couplers / Controllers of the WAGO-I/O-SYSTEM 750 to ensure correct data flow!

2.1.1.3 Display Elements

The end module 750-600 has no display elements.



2.1.1.4 Technical Data

Module Specific Data							
Dimensions (1	mm) W x H x L	12 x 64* x 100 * from upper edge of 35 DIN rail					
Weight		ca. 35 g					
Standards and Regulations (cf. Chapter 2.2 of the Coupler/Controller Manual)							
EMC-Immuni	ty to interference (CE)	acc. to EN 50082-2 (96)					
EMC-Emissio	on of interference (CE)	acc. to EN 50081-1 (93)					
EMC-Immuni	ty to interference (Ship building)	acc. to Germanischer Lloyd (01)					
EMC-Emissio	on of interference (Ship building)	acc. to Germanischer Lloyd (01)					
Approvals (cf. Chapter 2.2 of the Coupler/Controller Manual)							
c UL us	_C UL _{US} (UL508)						
ABS	ABS (American Bureau of Shipping)						
0	BV (Bureau Veritas)						
<u> ‡</u>	DNV (Det Norske Veritas)		Cl. B				
(GL)	GL (Germanischer Lloyd)		Cat. A, B, C, D				
KR	KR (Korean Register of Shipping	g)					
Living.	LR (Lloyd's Register)		Env. 1, 2, 3, 4				
	NKK (Nippon Kaiji Kyokai)						
*	RINA (Registro Italiano Navale)						
c UL us	cUL _{US} (UL1604)		Class I Div2 ABCD T4A				
⟨£x⟩	KEMA		II 3 G EEx nA II T4				
C€	Conformity Marking						



More Information

Detailed references to the approvals are listed in the document "Overview Approvals WAGO-I/O-SYSTEM 750", which you can find on the CD ROM ELECTRONICC Tools and Docs (Item-No.: 0888-0412) or in the internet under:

<u>www.wago.com</u> → Documentation → WAGO-I/O-SYSTEM 750 → System Description







WAGO Kontakttechnik GmbH & Co. KG Postfach 2880 • D-32385 Minden Hansastraße 27 • D-32423 Minden

Phone: 05 71/8 87 - 0 Fax: 05 71/8 87 - 1 69 E-Mail: info@wago.com

Internet: http://www.wago.com