


# WATER TEMP. GAUGE

Use a commercial sensor attachment

WT3-28m/m, 30m/m, 32m/m, 34m/m, 36m/m, 38m/m



## CONFIRMATION

- The thread size of the temperature sensor is 1/8 NPT. If the thread size of the sensor attachment for the temperature sensor is 1/8 PT, you will need the 1/8 PT sensor (optional part). If it is neither 1/8 PT nor 1/8 NPT, you will need to purchase a conversion adapter available from hardware stores.
- Tighten the sensor into the sensor attachment and then connect it to the sensor wire.
- Diameter format of water temperature sensor attachment :  
28m/m, 30m/m, 32m/m, 34m/m, 36m/m, 38m/m.

Eingang TKB

16. Nov. 2006