

# 2000 Lb. Electric Winch

## Assembly & Operating Instructions



12

### 2000LB. WINCH SPECIFICATIONS

Capacity:	6000 Lb. Rolling 5000 Lb. Marine 2000 Lb. Pulling Capacity
Max. Boat Size:	18 Feet
Max. Boat Weight:	5000 Lb.
Line Speed:	6 Feet/Minute with Load
Cable Length:	30 Ft.
Hook Size:	3/4" Opening x 3-3/4" L.
Power Supply:	12 Volts
Power Cord:	6'L. Negative Lead 14'9"L. Positive Lead
Remote Switch:	9'9"L.
Mounting Plate:	8-3/4" x 4-15/16" x 3/16"
Overall Dimensions:	9-1/2" x 7-1/2" x 10"
Net Weight:	18.6 Lbs.

### INCLUDED ACCESSORIES

1. Power Lead, fitted with water sealed plug and circuit breaker.
2. Remote Switch with water sealed plug, for safe operation.
3. 30' Aircraft Cable with attached hook
4. Mounting Bracket for Trailer Hitch
5. Emergency Crank Handle and adjustable clutch.

### PRODUCT FEATURES

1. Convenient, portable power for pulling boats, stuck vehicles and other heavy items.
2. Powerful 2,000 Lb pulling power.
3. 12Volt powered for convenient use without extension cords or small gas engines.
4. Portable, with built-in carrying handle and quick-attach mounting plate.

### SAVE THIS MANUAL

You will need this manual for the safety warnings and cautions, assembly instructions, operating procedures, maintenance procedures, trouble shooting, parts list, and diagram. Keep your invoice with this manual. Write the invoice number on the inside of the front cover. Keep both this manual and your invoice in a safe, dry place for future reference.

### NOTICE

The Warnings, Cautions, and Instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

13

### SAFETY WARNING & CAUTIONS

**WARNING:** When using powered equipment, basic safety precautions should always be followed to reduce the risk of personal injury and hazards.

#### READ ALL INSTRUCTIONS BEFORE USING THIS TOOL!

1. KEEP WORK AREA CLEAN. Cluttered areas invite injuries.
2. OBSERVE WORK AREA CONDITIONS. Do not use tools in damp, wet, or poorly lit locations. Don't expose to rain. Keep work area well lit. Do not use electrically powered equipment in the presence of flammable gases or liquids.
3. KEEP CHILDREN AWAY. Children must never be allowed in the work area. Do not let them handle machines, tools, or equipment.
4. STORE IDLE EQUIPMENT. When not in use, tools must be locked up in a dry location to inhibit rust. Always lock up tools and keep out of reach of children.
5. DO NOT FORCE THE TOOL. It will do the job better and more safely at the rate for which it was intended. Do not use inappropriate attachments in an attempt to exceed the tool's capacities.
6. USE THE RIGHT TOOL FOR THE JOB. Do not use a tool for a purpose for which it was not intended.
7. DRESS PROPERLY. Do not wear loose clothing or jewelry, as they can be caught in moving parts. Non-skid footwear is recommended. Wear restrictive hair covering to contain long hair. Always wear appropriate work clothing.
8. USE EYE, EAR AND BREATHING PROTECTION. Always wear ANSI approved impact safety goggles if you are producing metal filings or wood chips. Wear an ANSI approved dust mask or respirator when working around metal, wood, and chemical dusts and mists. Use ANSI approved ear protection when working in a loud or noisy environment.
9. DO NOT ABUSE THE POWER CORD. Protect the power cord from damage, either from impacts, pulling or corrosive materials. Do not yank machine's cord to disconnect it from the receptacle.
10. DO NOT OVERREACH. Keep proper footing and balance at all times. Do not reach over or across running machines.
11. MAINTAIN TOOLS WITH CARE. Keep tools sharp and clean for better and safer performance. Follow instructions for lubricating and changing accessories. Inspect power cord periodically and, if damaged, have it repaired by an authorized technician. Inspect all moving parts and mounting bolts prior to use. Control handle and power switch must be kept clean, dry, and free from oil and grease at all times.

14

12. REMOVE ADJUSTING KEYS AND WRENCHES. Be sure that keys and adjusting wrenches are removed from the tool or machine work surface before operation.

13. AVOID UNINTENTIONAL STARTING. Be sure that you are prepared to begin work before turning the start switch on.

14. STAY ALERT. Watch what you are doing. Do not operate this machine when you are tired.

15. DO NOT OPERATE THIS MACHINE WHILE UNDER THE INFLUENCE OF ALCOHOL, DRUGS, OR PRESCRIPTION MEDICINES.

16. CHECK FOR DAMAGED PARTS. Before using any tool, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for alignment and binding of moving parts, any broken parts or mounting fixtures, and any other condition that may affect proper operation. Any part that is damaged should be properly repaired or replaced by a qualified technician. Do not use the tool if any switch does not turn on and off properly.

17. REPLACEMENT PARTS AND ACCESSORIES. When servicing, use only identical replacement parts. Use of any other parts will void the warranty. Only use parts and accessories intended for use with this tool, which are available from seller.

### SPECIAL WARNINGS WHEN USING THIS ELECTRIC WINCH

Using this powerful tool may create special hazards.  
Take particular care to safeguard yourself and those around you.

#### The Cable.

Be sure the cable is in good condition, and is attached properly. Do not use the winch if the cable is frayed. Do not replace the cable with a cable of lesser strength.

#### The Battery.

Be sure the battery is in good condition. Avoid contact with battery acid or other contaminants. Always wear ANSI approved eye protection when working around a battery. Have the engine running when using the winch, to avoid running the battery down.

#### Stand Back.

Stay out of the direct line that the cable is pulling. In case it slips or breaks, it will "whiplash" along this line. Keep hands, clothing, hair and jewelry clear of the winch while in use. Use a spotter to assist you in assuring that it is safe to operate the winch. Make sure this person is out of the way of the vehicle and the cable before activating the winch.

#### Power Limits.

Do not attempt to exceed the pulling limits of this winch. Never use the hand crank to "assist" the winch. This will damage the winch and may cause personal injury.

15

### INSTALLATION

#### Wiring your Electric Winch

Your Winch may be used with temporary wiring or permanent wiring

#### Temporary Wiring

1. Lift the rubber seal, and plug the POWER CABLE (#23) into the PLUG (#47) on the right side of the winch body. This plug is labeled "power". Route the Electric Cord from the winch to your battery, being careful to avoid tangling it in moving equipment, or causing a tripping hazard.
2. Connect the Black Clamp Handle of the POWER CABLE (#23) to the frame of your vehicle, establishing a ground connection. Connect the Red Clamp Handle to the Positive (+/Red) terminal of your battery. **Note: Be sure you are using a 12V automotive battery or equivalent, in good condition.**
3. Lift the rubber seal on the left side of the winch body. Taking the Remote Control Unit, insert the Socket (#46) at the end of the cord into the Plug on the left side of the winch body labeled "Remote Control".
4. Set the remote control aside in a safe place until ready for use.

#### Permanent wiring

1. Attach the OVER-CURRENT PROTECTOR (#28) to the Positive (+/Red) terminal of your battery, using the battery terminal clamp bolt.
2. Plan a route for the wiring from the point of the vehicle where the winch will be mounted or used to the battery. This route must be secure, out of the way of moving parts, road debris, or any possibility of being damaged by operation or maintenance of the vehicle. For example, you may wish to route the wires under the vehicle, attaching it to the frame using suitable fasteners. Do not attach the wires to the exhaust system, drive shaft, emergency brake cable, fuel line, or any other components which may create damage the wiring through heat or motion, or create a fire hazard.
3. If you drill through the bumper or any part of the body to route the wires, be sure to install a rubber grommet in the hole to prevent fraying of the wires at that point.
4. Route the POWER CABLE (#23) from the point the winch will be used to the battery, following the precautions discussed above.
5. Remove the Red Clamp handle, and attach the red wire to the OVER-CURRENT PROTECTOR (#28) which is mounted onto the Positive (+/Red) terminal of your battery.
6. Remove the Black Clamp handle, and attach the black wire to the frame of your vehicle, creating a secure electrical ground.

### WARNING

1. Always connect Red to Red (Positive to Positive) and Black to the frame, making a ground connection, when using battery power from your vehicle.
2. Never continue use of your winch or other accessory until the battery is completely run down.
3. You may wish to keep your engine running while using this winch, to continually recharge the engine. However, exercise extreme caution when working around a running vehicle.
4. Do not use a dirty, corroded or leaking battery. You may suffer injury from acid burns.
5. Always wear ANSI approved safety glasses when working around or with a battery.

16