



安裝說明書

INSTALLATION INSTRUCTION

1、打開側板與前面板

Pull the side cover and front panel as below arrow.




擰開固定螺絲後將側板取下,然後將機箱前面板如圖示方向拆開。

Pull the side cover backwards after disassemble one screw then release the front panel.

2、取下支架

Take out the bracket.




擰開四個固定螺絲,然後沿圖示方向將支架取下。

Pull the bracket backward and take it out disassemble four screws (show as the arrow of the picture)

3、安裝硬盤與光驅

Install the HDD and ODD.



將硬盤 如圖示方向安裝在支架上,并用四個螺絲將其固定,然後將光驅如圖示方向裝入支架內,并用四個螺絲將其固定,最後將其安裝在機箱內。
Fix the ODD onto the bracket with four screws,then install the HDD into the bracket with four screws,install it onto the case at last.