Evoluent Mouse Manager

for Windows

Less is more.

In ergonomic terms, the less movement you make, the more relaxed you are. Did you know the Evoluent Mouse Manager software lets you do many things without moving the mouse or touching the keyboard?

The primary benefits of the Mouse Manager are:

Button Programming

Configure the mouse buttons to perform functions that normally require moving the mouse to click buttons on screen or pressing the keyboard. This reduces mouse movements and hand movements to the keyboard. The buttons may even be configured with different functions in different programs.

Accelerated scrolling

Configure the wheel to scroll a single line per increment when rolled slowly, and scroll many lines per increment when rolled quickly. This significantly reduces the amount of scrolling necessary.

E Evoluent N	Mouse Manager v5.5			_ XX
Buttons Po	inter Options Wheel Break	Click		
6		Evoluent V	/erticalMouse 4	
Primary Fu	unctions	Secondary Fu		
Button 1	Left Click 🔹	Select Secon under Primary	dary Functions for button Functions.	6
Button 2	Double Click 🔹	Simultaneous of buttons 1-4	y press button 6 and any to activate.	one
Button 3	Right Click	Buttons 6+1	Left Click	-
Button 4	Esc 💌	Buttons 6+2	Close	•
Button 5	Show/Hide Desktop 🔹	Buttons 6+3	Right Click	-
Button 6	Secondary Functions 🔹	Buttons 6+4	Wheel/Middle Click	•
Res	store defaults	Customize function	s for different programs	
Remove	Copyrigh	t Mouse Manager nt Evoluent <u>roluent.com</u>	v5.5	
		ОК	Cancel Ar	ply

Download the free driver at evoluent.com

Buttons tab

The mouse buttons may be programmed to perform a large variety of mouse and keyboard functions. This reduces the need to frequently move the mouse to click tiny buttons on the screen, and the need to frequently move your hand to the keyboard to press keys.

To configure the buttons, pull down the button menus and select the desired functions in the Primary Functions section.

Here is an example of a configuration with functions that are useful when working on the Desktop. You may use any of the many other functions available, or even assign any keyboard key or combination of keys to a mouse button by selecting the Keystroke Recording function.

Button 1 – Left Click

Button 2 - Double Click

One click represents a double click. This makes double clicking much easier and more accurate when opening programs and files.

Button 3 - Right Click

Button 4 - Esc

Closes menus and dialog boxes.

Button 5 - Show/Hide Desktop

Press once to minimize all windows to show the desktop to find a program or file, press again to restore all windows.

Button 6 - Secondary Functions

When this function is selected, button 6 may be pressed in combination with buttons 1, 2, 3 or 4 to perform a secondary function. For example, button 2 is configured as double click when pressed by itself, but when buttons 6 and 2 are pressed together, they perform a secondary function. In this example, buttons 6 + 2 are configured as Close for closing windows.

E Evoluent I	Mouse Manager v5.5		<u> </u>
Buttons Po	inter Options Wheel Break	Click	
6		Evoluent \	/erticalMouse 4
Primary Fi			dary Functions for button 6
		under Primary Simultaneous	r Functions. ly press button 6 and any one
Button 2	Double Click	of buttons 1-4	
Button 3	Right Click 🔹	Buttons 6+1	Left Click 👻
Button 4	Esc 🔹	Buttons 6+2	Close
Button 5	Show/Hide Desktop	Buttons 6+3	Right Click
Button 6	Secondary Functions 🔹	Buttons 6+4	Wheel/Middle Click 👻
Re	store defaults	ustomize functior	ns for different programs
Remov	Copyrigh	t Mouse Manager It Evoluent Poluent.com	·v5.5
		ОК	Cancel Apply

You can configure the buttons in many other ways to suit your needs.

Customize Button Functions For Different Programs

The mouse buttons may be configured to perform different functions in different programs such as Microsoft Word, Adobe Acrobat, Internet Explorer, etc. For example, the middle button may be configured to perform a double click to open programs or files on the desktop, while at the same time it may also be configured to copy text or images in Microsoft Word, and activate the Find function in Adobe Acrobat.

Example 1 – Internet Explorer

When using Internet Explorer or other internet browser, it is often necessary to go back to previous pages. Pressing the Back button requires downloading the previous pages again in a time consuming process.

A more convenient way of browsing is to open links on new tabs and keep the home page open. This avoids having to press the Back button many times to get back to it. When many tabs are open, the tabs may be brought to the front for viewing. The tabs may be individually closed when they are no longer needed.

These actions may be done by moving the mouse a lot to click menus and buttons on the screen, or moving your hand to use the keyboard. With the Evoluent Mouse Manager, these actions may be done without moving the mouse or touching the keyboard.

Here is how to configure the buttons to operate specifically in Internet Explorer:

- 1. Click **Customize functions for different programs** at the bottom right of the Buttons tab.
- 2. Click **Add** to find the Internet Explorer program. Browse to C drive, Program Files, Internet Explorer, select iexplore.exe, and click Open.

E Evoluent Mouse Manager v5.5	E Customize Functions For Different Programs
Buttons Pointer Options Wheel Break Click	Customized Programs ACDSee 16 Adobe Acrobat Adobe Acrobat Adic Advector Acrobat Adic Advector Acrobat Adic Advector Acrobat Advector Acr
Primary Functions Button 1 Left Click Button 2 Double Click Button 3 Right Click Button 4 Wheel/Middle Click Button 5 Back Button 6 Secondary Functions. Simultaneously press button 6 and any one of buttons 1-4 to activate. Button 3 Right Click Button 4 Wheel/Middle Click Button 5 Back Button 6 Secondary Functions Button 7 Back Button 8 Right Click Button 9 Buttons 6+3 Restore defaults Customize functions for different programs Remove icon on taskbar Evoluent Mouse Manager v5.5 Copyright Evoluent www.evoluent.com	Add Delete Primary Functions Secondary Functions Button 1 Left Click Select Secondary Functions Button 2 Drag Scrol Select Secondary Functions Button 3 Right Click Simultaneously press button 6 and any one of buttons 1-4 to activate. Button 4 KeyStroke Recording Buttons 6+1 Button 5 Back Buttons 6+2 Button 6 Secondary Functions Buttons 6+3 KeyStroke Recording Buttons 6+3 KeyStroke Recording Buttons 6+4 Wheel/Middle Click Buttons 6+4
OK Cancel Apply	OK Cancel

- 3. Select Secondary Functions for **Button 6**.
- 4. Open the menu for **Buttons 6 + 1**, select Keystroke Recording, press Ctrl on the keyboard and check the box for Left click, click OK.

E Customize Functions For Different Pro	ograms 🛛 🕅 🕅	E Customize Functions For Different Programs
Customized Programs	Buttons may have different functions in different programs. For example, button 2 may be Double Click on the main Buttons tab for most programs, and it may be Wheel/Middle Click for Internet Explorer for opening web pages on new tabs. Click Add to find the programs to be customized, which are usually in C:\Program Files or C:\Program Files (x86). Caution: Adding Windows Explorer here overnides the button settings on the main Buttons tab when working on the Desktop.	Customized Programs ▲ Adobe Acrobat ▲ Adobe Acrobat ▲ Internet Explorer ▲ Microsoft Excel ▲ Microsoft Word ▲ Microsoft Word ▲ Explorer ▲ Microsoft Word ▲ Microsoft W
Add Delete Primary Functions Button 1 Left Click Button 2 Drag Scrol Button 3 Right Click Button 3 Right Click Button 4 KeyStroke Recording Button 5 Back Button 6 Secondary Functions Restore defaults	Secondary Functions Select Secondary Functions for button 6 under Primary Functions. Simultaneously press button 6 and any one of buttons 1-4 to activate. Buttons 6+1 KeyStroke Recording Buttons 6+2 KeyStroke Recording Buttons 6+3 KeyStroke Recording Buttons 6+4 Wheel/Middle Click	Add Press and release keyboard keys one at a time. Ctrl Ctrl Button 1 Image: Ctrl Button 2 Image: Ctrl Button 2 Image: Ctrl Button 3 Right Click Button 4 KeyStroke Recording Button 5 Back Button 6 Secondary Functions Button 6 Secondary Functions
	OK Cancel	OK Cancel

- 5. Open the menu for **Buttons 6 + 2**, select Keystroke Recording, press Ctrl and W on the keyboard, and click OK.
- 6. Open the menu for **Buttons 6 + 3**, select Keystroke Recording, press Ctrl and Tab on the keyboard, and click OK.

E Customize Functions For Different Pro	ograms 🛛 🕅	E Customize Functions For Different Programs
Customized Programs Customized Programs Adobe Acrobat Chitemet Explorer Microsoft Excel Microsoft Word Exel Fress and release keyboan Ctrl+W	Buttons may have different functions in different programs. For example, button 2 may be Double Click on the main Buttons tab for most programs, and it may be Wheel/Middle Click for Internet Explorer for opening web pages on new tabs. Click Add to find the programs to be customized, which are usually in C:\Program Files or C:\Program Files (x86). Caution: Adding Windows Explorer here overrides the button settings on the main Buttons tab when working on the Desktop.	Customized Programs Customized Programs Adobe Acrobat Internet Explorer Microsoft Excel Microsoft Word Dick Add to find the programs to be customized, which are usually in C:NPogram Files (x86). Caution: Adding Windows Explorer here overrides the button settings on the main Buttons to be customized, which are usually in C:NPogram Files (x86). Caution: Adding Windows Explorer here overrides the button settings on the main Buttons tab when working on the main Eutrons tab when working on the Cit+Tab
Button 1 L Clear	OK Cancel nd any one	Button 1 Left click Right click button 6 Clear OK Cancel nd any one
Button 2		Button 2
Button 3 Right Click	Buttons 6+1 KeyStroke Recording	Button 3 Right Click Buttons 6+1 KeyStroke Recording
Button 4 KeyStroke Recording -	Buttons 6+2 KeyStroke Recording	Button 4 KeyStroke Recording Buttons 6+2 KeyStroke Recording
Button 5 Back	Buttons 6+3 KeyStroke Recording	Button 5 Back Buttons 6+3 KeyStroke Recording
Button 6 Secondary Functions	Buttons 6+4 Wheel/Middle Click	Button 6 Secondary Functions Buttons 6+4 Wheel/Middle Click
Restore defaults		Restore defaults
	OK Cancel	OK Cancel

Click OK to close **Customize functions for different programs**, and click **OK** to close Evoluent Mouse Manager. Now open Internet Explorer, go to any web site, and try this:

1. Hold down button 6 (bottom thumb button) with your thumb and click button 1 (top finger button) to open a link on a new tab. Do this several times to open several links on additional tabs.

2. Hold down button 6 and click button 3 (bottom finger button) to cycle through the tabs to see different pages.

3. Hold down button 6 and click button 2 (middle finger button) to close each tab when done viewing the page.

Note: The Edge browser in Win 10 is part of Windows Explorer. The settings on the **Buttons** tab apply to Windows Explorer and also to Edge. Therefore Edge may be configured on the **Buttons** tab.

Example 2 – Microsoft Word

Using the same procedure as above, add Microsoft Word to **Customize functions for different applications**. Here is a suggested configuration:

Button 1 – Left Click

Button 2 - Copy

Button 3 - Right Click

- Button 4 Paste
- Button 5 Keystroke Recording (Alt F4 for "Find")

Button 6 - Secondary Functions

- Buttons 6 + 1 Keystroke Recording (Ctrl P for printing)
- Buttons 6 + 2 Keystroke Recording (Alt F4 for closing the window)

Pointer Options tab

Click **Settings** to open the Mouse applet in Window's Control Panel. In the Mouse applet, go to the **Pointer Options** tab, move the slider to the middle, and uncheck **Enhance pointer precision**. On the Evoluent VerticalMouse, press the **pointer speed** buttons to set the pointer speed indicators to MD (medium). This configuration provides the best pointer control.

Evoluent Mouse Manager v5.5	23
Buttons Pointer Options Wheel Break Click	
Pointer speed	
Click Settings to open Mouse in Control Panel to set the pointer speed on the Pointer Options tab. Generally, the best setting is the middle position on the pointer speed slider.	
An additional pointer speed control is on the Evoluent VerticalMouse itself. Press the Pointer Speed buttons to light up three indicators at the top of the mouse for best response.	
Settings	
OK Cancel App	ly

Wheel tab —

Without Evoluent Mouse Manager, the scroll wheel scrolls a selected number of lines per increment. The Windows system default is 3 lines. Regardless of how slowly or quickly the wheel is rolled, the number of lines scrolled per increment is the same. 3 lines per increment provides coarse control but faster scrolling. You can reduce the setting to 1 line per increment for fine control but much slower scrolling.

Mouse Manager provides **Accelerated scrolling** for quick scrolling but also fine control at the same time. By default the box is checked and lines per increment set to 1.

The wheel scrolls 1 line per increment when it is rolled slowly for the finest control possible. It scrolls several lines per increment when it is rolled quickly, but returns to 1 line per increment when rolled slowly again. Mouse Manager automatically varies the number of lines scrolled per increment according to the speed of rolling the wheel. This greatly reduces the amount of wheel movement necessary while still maintaining precision.

The amount of scroll acceleration is adjustable by moving the slider.

luttons	Pointer O	ptions Whe	el Break	Click			
	croll 🔘	ne increment f Scroll one scr					
🔽 A	ccelerated	scrolling - scr	oll more line	s per increme	nt when rolling	the wheel f	aster
Slow	1 1 1			Fast			

Break tab -

Check Break Reminder and Resume Reminder to remind yourself to periodically take a break and resume work.

uttons Pointer C	Dptions Wheel Break Click	
🛛 Break remin	der	
Reminds you to	take a break and stretch your body.	
Break every:	30 minutes	
Visual alert		
Audio alert	notify.wav	
Resume ren	ninder	
Reminds you to	resume work.	
Resume after:	3 minutes	
Visual alert		
Audio alert	notify.wav	

Click tab -

Check the box for Click Lock to simulate holding down the left click button even after releasing the button. This is useful for users with physical difficulty holding down the button.

Check the box for Auto Click to perform an automatic single or double click when pausing the pointer over any clickable area. This is useful for users with physical difficulty pressing the button.

uttons Pointer Options Wheel Break Click Image: Click lock Simulates holding down a button even after the button is released. To activate, click and briefly hold the button. To deactivate, click and release the button again. Activation delay: 1.0 Seconds Image: Value click Performs a click after briefly pausing the pointer. To activate, pause the pointer on a clickable area. Image: Performs single click Performs double click Activation delay: 1.0 Seconds	
Simulates holding down a button even after the button is released. To activate, click and briefly hold the button. To deactivate, click and release the button again. Activation delay: 1.0 Seconds Activation delay: 1.0 Performs a click after briefly pausing the pointer. To activate, pause the pointer on a clickable area. Performs single click Performs double click	
Simulates holding down a button even after the button is released. To activate, click and briefly hold the button. To deactivate, click and release the button again. Activation delay: 1.0 Seconds Activation delay: 1.0 Performs a click after briefly pausing the pointer. To activate, pause the pointer on a clickable area. Performs single click Performs double click	
To activate, click and briefly hold the button. To deactivate, click and release the button again. Activation delay: 1.0 Seconds V Auto click Performs a click after briefly pausing the pointer. To activate, pause the pointer on a clickable area. Performs single click Performs double click	
Activation delay: 1.0 Seconds Image: Auto click Performs a click after briefly pausing the pointer. To activate, pause the pointer on a clickable area. Performs single click Performs double click	
Auto click Performs a click after briefly pausing the pointer. To activate, pause the pointer on a clickable area. Performs single click Performs double click	
Performs a click after briefly pausing the pointer. To activate, pause the pointer on a clickable area. Performs single click Performs double click	
To activate, pause the pointer on a clickable area. Performs single click Performs double click	
Performs single click Performs double click	
Activation delay: 1.0 🛓 Seconds	
OK Cancel Appl	