

LS6300E/LS6320E GOOD READ BEEP TONE & GOOD READ BEEP  
DURATION

GOOD READ BEEP TONE - NONE



014200

GOOD READ BEEP TONE - LOW



014201

GOOD READ BEEP TONE - MEDIUM



014202

GOOD READ BEEP TONE - HIGH



014203

GOOD READ BEEP TONE  $\delta$  LOW/HIGH



014204

GOOD READ BEEP TONE  $\delta$  HIGH/LOW



014205

GOOD READ BEEP TONE - RESET



0B142

GOOD READ BEEP DURATION - SHORT



014300

GOOD READ BEEP DURATION - MEDIUM



014301

GOOD READ BEEP DURATION - LONG



014302

GOOD READ BEEP DURATION - RESET



0B143