

MOBILE-ALERTS Sensor

This is a sensor for the "MOBILE-ALERTS" system, it can be used with this system only. To use the sensor you need a MOBILE-ALERTS gateway.

Sensor set up

Open the battery compartment of the temperature sensor and put in 2x AAA batteries with the correct polarity.

Add Sensor

Open the app, dashboard is displayed. Tap "Add new sensor" and scan the QR code on the back of the temperature sensor. Then set a name for the sensor.

Specifications

Batteries:

 Battery life:
 alkaline

 approx. 2 years
 approx. 2 years

 Measuring range:
 -29.9°C to +59.9°C

 Accuracy:
 1°C

 Measurement intervals:
 7 minutes

 Transmission range:
 100m (open area)

 Cable length:
 1m

More information and detailed instructions can be found in the app at "Info" or at <u>www.mobile-alerts.eu</u>

The declaration of Conformity can be found at: www.mobile-alerts.eu/technoline/doc



Old batteries do not belong into general household waste. You are obliged to return used batteries to your vendor or collection points.

2 x micro (LR03, AAA)



Electrical devices have to be disposed separately from the general household waste. Take your old electronics to your local waste collection point or recycling centre.