



Power supply


External supply




Supply via phantom powers
AM/FM



Supply via phantom powers
DAB






Supply via phantom powers
AM/FM and DAB



FAKRA housing assembly

After mounting the antenna FAKRA housing snapping to FAKRA connector



To unlock housing with screwdriver,
lift the elastic finger and pull housing

Modification reserved



MOUNTING INSTRUCTIONS



Combiflex Roof antenna

**AM/FM, DAB/DAB+
GPS, GSM, UMS**

MONTAGEANLEITUNG

Mounting Instruction

