Simplified EU Declaration of Conformity



C RADEMACHER Geräte-Elektronik GmbH hereby declares that the 2-Channel Micro Manual Transmitter RP-MHS-RF63 complies with the Directive 2014/53/ **EU (Radio Equipment Directive).**

> The full text of the declaration of conformity is available at the following website:

www.rademacher.de/ce



Geräte-Elektronik GmbH Buschkamp 7 46414 Rhede info@rademacher.de www.rademacher.de

Service:

Telephone +49 1807 933-171* Fax +49 2872 933-253 service@rademacher.de

* 30 seconds free of charge, subsequently 14 cents/minute from German fixed line networks and max. 42 cents / minute from German cellular networks



2-Channel Micro Manual Transmitter RP-MHS-RF63 Item no. 8000 00 55



VBD 607-8 (08.17)

Dear Customer,

Congratulations on purchasing the manual transmitter, you have opted for a quality product manufactured by RADEMACHER. Thank you for the trust you have placed in us!

Logging on to the receiver

Please refer to the operating manual of the respective device for information on how to log the manual transmitter on to your receiver (controller, drive or similar). Only use the manual transmitter for RADEMACHER devices

Technical specifications

Item no.:	8000 00 55
Frequency:	433.92 MHz AM
Security coding:	Keeloq
Operating voltage:	12 V, 27 A
Weight incl. battery:	Approx. 38 g
Dimensions:	(WxHxD): 38 x 65 x 11 mm

Changing the battery

The battery must be replaced if the range of the transmitter drops or the LED on the sensor no longer lights up when it is activated. Only use the right type of replacement batteries and pay attention to the correct polarity when inserting them.

Please dispose of the old batteries in the designated collection containers after replacing the battery.

Warranty terms and conditions

RADEMACHER Geräte-Elektronik GmbH provides a 24-month warranty for new systems that have been installed in compliance with the installation instructions. All construction faults, material defects and manufacturing defects are covered by the warranty. Your statutory warranty claims remain unaffected by this warranty.

The following are not covered by the warranty:

- Incorrect fitting or installation
- Non-observance of the installation and operating manual
- Improper operation or wear and tear
- External influences, such as impacts, knocks or weathering
- Repairs and modifications by third parties, unauthorised persons
- Use of unsuitable accessories
- Damage caused by unacceptable excess voltages (e.g. lightning)
- Operational malfunctions caused by radio frequency overlapping and other such radio interference

A prerequisite for the warranty is that the new device must have been purchased from one of our approved specialist retailers. Proof of this must be provided by presenting a copy of the invoice. RADEMACHER will remedy any defects that occur within the warranty period free of charge either by repair or by replacement of the affected parts or by supplying a new replacement unit or one to the same value. There is no general extension of the original warranty period by delivery of a replacement or by repair as per the terms of the warranty.

Attention:

Please check the battery condition **before** making a complaint and sending in the transmitter!