

Stone & Wood Cleaner is a water-based cleaning detergent for cleaning stone, masonry and wood. Stone & Wood Cleaner is also an excellent detergent for cleaning facades of any objects that endure water.

Coverage: Approx 125 m2 per 2½ litres. Cleaning by hand: 300 ml to 10 litres water.

Stone & Wood Cleaner is a gentle - but very efficient detergent to remove dirt.

Always test on a small area to make sure the surface tolerates the cleaning detergent.

Packaging may be recycled in accordance with local regulations.

Readily biodegradable surfactants in accordance with EU legislation. Store in frost-free place.

Dosage:

- For use with HPW: 2-5%
- Manual use: 1-2 dl. to 5 ltr. litres of tap water.

Application:

- High-pressure washer
- Foam sprayer (item no. 128500077)
- Super Foam Sprayer (item no. 128500938)
- Patio Cleaner

Fill detergent into the cleaning tank/Foam Sprayer. Apply detergent on subjects to be cleaned. Wait 2-5 minutes, but without the cleaning agent to dry out. After cleaning, rinse with tap water. Also use in combination with Patio Cleaner.

- Standard equipment

Model	STONE & WOOD CLEANER 2.5 L
Ref. no.	125300385
Technical specifications	
Packaging	1x2,5 L
Ph value	8,0 (1% solution)

- Standard equipment, ○ Supplementary accessories, □ Mountable equipment



Picture shown may not represent model quoted

