


	<b>1</b> x2	<b>2</b> x2	<b>3</b> x1	<b>4</b> x1
<b>5</b> x1	<b>6</b> x1	<b>7</b> x1	<b>8</b> x2	<b>9</b> x4
<b>10</b> x8	<b>11</b> x4	<b>12</b> x12	<b>13</b> x1	<b>14</b> x1
<b>15</b> x2	<b>16</b> x4	<b>17</b> x1	<b>18</b> x1	<b>19</b> x4
<b>20</b> x1	<b>21</b> x1	<b>22</b> x4	<b>23</b> x4	<b>24</b> x4
<b>25</b> x4	<b>26</b> x4	<b>27</b> x4	<b>28</b> x4	<b>29</b> x8



**1**

**2**

**9**

**1**

EN Turn this nut to adjust the height of wheel  
 IT Avvitare questo dado per regolare l'altezza delle ruote  
 DE Drehen Sie diese Mutter, um die Höhe des Rades einzustellen  
 FR Tournez cet écrou pour ajuster la hauteur de la roue  
 ES Gire en la tuerca para ajustar la altura de la rueda  
 PL Przekręć nakrętkę, aby wyregulować wysokość koła

**2**

**2**

**10**

**3**

**1**

**11**

BACK

Front

**3**

**8**

**6**

**6**

**7**

**5**

**4**

**4**

**12**

**5**

**12**

**13**

240mm

**5**

**6**

**16**

**15**

**14**

