


# Programming Quick Guide - FS5020M

## **Installation**

Make sure that the scanner has the correct cable to plug in the PC as below described:



## **Reset Configuration to Default :**

If you are unsure of the scanner configuration or have scanned the incorrect codes, please scan USB HID. This will reset the scanner to its factory defaults.



## **Keyboard Country (FOR USB HID Only)**

Scan the appropriate country code as below to program the keyboard layout for your country or language. As a general rule, the following characters are supported, but need special care for countries other than the United States: @ | \$ # { } [ ] = / ' \ < > ~



USA  
(Original setting)



Italy



Portuguese (Brazil)



German



France



Spanish



Portuguese (Portugal)

## **1D Symbologies – 1**



**CODABAR**



**CODE 39**



**Interleaved  
25**



## **1D Symbologies – 2**



**Matrix 25**



**CODE 128**



**GS1-128**



**UPC-A**



**UPC-E**



**EAN 8**













**EAN 13**













**Industrial  
25**



## 1D Symbologies – 3

|   |                                    |  |
|---|------------------------------------|--|
| <b>ENABLE</b><br>  | <b><u>ISSN</u></b>                 | <b>DISABLE</b><br>  |
| <b>ENABLE</b><br>  | <b><u>GS1 DataBar</u></b>          | <b>DISABLE</b><br>  |
| <b>ENABLE</b><br>  | <b><u>GS1 Databar Limited</u></b>  | <b>DISABLE</b><br>  |
| <b>ENABLE</b><br>  | <b><u>GS1 Databar Expanded</u></b> | <b>DISABLE</b><br>  |
| <b>ENABLE</b><br>  | <b><u>ISBN</u></b>                 | <b>DISABLE</b><br>  |
| <b>ENABLE</b><br> | <b><u>CODE 93</u></b>              | <b>DISABLE</b><br> |

## 2D Symbologies

|   |                             |   |
|---|-----------------------------|---|
| <b>ENABLE</b><br> | <b><u>PDF 417</u></b>       | <b>DISABLE</b><br> |
| <b>ENABLE</b><br> | <b><u>QR Code</u></b>       | <b>DISABLE</b><br> |
| <b>ENABLE</b><br> | <b><u>Micro QR Code</u></b> | <b>DISABLE</b><br> |
| <b>ENABLE</b><br> | <b><u>Data Matrix</u></b>   | <b>DISABLE</b><br> |
| <b>ENABLE</b><br> | <b><u>Aztec Code</u></b>    | <b>DISABLE</b><br> |

● Information in this document is subject to change without notice.  
Q\_190102\_01