

Quick reference MA10870 AC-OFF sensor



MOBILE-ALERTS Sensor

This is a sensor for the "MOBILE-ALERTS" system, it can be used with this system only. To use the sensor you need a MOBILE-ALERTS gateway. This sensor sends a warning message 5 seconds after an AC failure to the app.

Sensor set up

Plug the transmitter into a socket that is in the same voltage circle as the devices to be monitored. The red LED lights up twice. The green LED flashes while data is being sent and stays lit when the transmitter can send both temperature data and the status of the power supply.

Add Sensor

Open the app, dashboard is displayed. Tap "Add new sensor" and scan the QR code on the back of the temperature sensor. Then set a name for the sensor.

Specifications

Measuring range:	- 9.9°C to +59.9°C
Accuracy:	+/- 2 °C
Measurement intervals:	6 Seconds
Transmission range:	150m (open area)

More information and detailed instructions can be found in the app at "Info" or at www.mobile-alerts.eu

Summary of the Declaration of Conformity: We hereby declare that this device does comply with the requirements of RED Directive 2014/53/EU.

The declaration of Conformity can be found at: www.mobile-alerts.eu/technoline/doc

Old batteries do not belong into general household waste. You are obliged to return used batteries to your vendor or collection points.



Electrical devices have to be disposed separately from the general household waste. Take your old electronics to your local waste collection point or recycling centre.

