

Desk calculators



DH-12ET

Functions

Calculation functions

- Tax calculation
- Currency conversion
- Pro-percentage
- Mark up with percentage key
- Square root
- Sign change (+/-)
- Rounding selector
- Key rollover

Memory

- Grand total memory
- 3-key memory

Product features

Display

- 12-digit display
- LC display
- Function command signs
- 3-digit comma markers

Power

- Solar/Battery powered
- Backup battery
- Auto power off

Input

- Double zero key

Materials / Outer Appearance

- Plastic keys
- Rubber feet
- Ergonomically shaped keys



151 x 29 x 159 mm



180 g

4549526609954
EAN Code

www.casio-europe.com

CASIO

Desk calculators



DH-12ET

Operating instructions for selected functions

TAX CALCULATION

Set a VAT rate of 19%.

AC RATE SET % 19 RATE SET %

Press and hold for about 8 seconds

The tax rate of 19% is now permanently saved.

Calculation of the net amount of €238, so 19% of €238.

238 TAX-

200

TAX-

38

Absolute amount in €

Calculation of the gross amount of €200.

200 TAX+

238

TAX+

38

Absolute amount in €

Pocket and desk calculators

Tax calculation

Function for easy and quick calculation of tax reductions and additional taxes. A previously saved tax rate can be added or subtracted from an amount at the touch of a button. Especially for complex tax and VAT calculations, this function makes work easier and saves time.

PROFESSIONAL PERCENTAGE CALCULATION

Addition of 10% to the reference value 50 with interim display of the amount to be added during the calculation.

50 × 10 %

5

+

55

Subtraction of 10% from the reference value 50 with interim display of the amount to be subtracted during the calculation.

50 × 10 %

5

-

45

Pocket and desk calculators

Pro-percentage

Determine percentage-based surcharges and discounts with a separate display of the calculated value. Comfortable calculating percentage markups and markdowns and subsequent display of the calculated absolute value.

3-KEY MEMORY

M+ Adding memory

M- Subtracting memory

MRC Display of total balance:
Press 1x
Complete deletion of memory:
Press 2x one after the other

Addition of 10 and 10 to memory and subtraction of 5 from memory.

10 M+ 10 M+ 5 M-

MRC

15

Content of memory

MRC MRC

Memory deleted

AC MRC

0

Content of memory

Pocket and desk calculators

3-key memory

Memory buttons can be used to save numbers for later use.