


Opening Your Chest


1. Insert the key (2 included) into the lock and then turn clockwise to the right.



2. Push the large button and the locking latch will open and spring forward.




3. Once the latch has cleared the lip that it was secured to, you can open the Chest lid.




Closing Your Chest

1. Close the lid, making sure that the contents do not obstruct the seal.



2. Push the latch back and down onto the lid clasp, and snap the latch into the closed position.



3. Turn the key counter-clockwise to the left, and remove key. Your safe is now locked.



Assembling Wheels (Model 2037WFE only)

If your Chest includes Easy Roller™ Wheels, follow the simple assembly instructions included in the box. For your safety, the instructions printed on the wheel cart should be upright and facing outward.

After assembly, carefully place the Chest onto the wheel cart. Do not sit or stand on the Easy Roller™ Wheels. The maximum weight supported is 38.6 kg.

LIFETIME AFTER FIRE REPLACEMENT GUARANTEE

If your NOFIRE® Fire/ Fire Water Chest is ever damaged by a fire, EPS Vertriebs GmbH will replace it with a comparable model at no charge to the consumer. Freight on the replacement unit is not included in the guarantee and must be paid by the consumer.

For claims, submit your name and address, a photo of the damaged safe along with its Model Number, and a copy of the Fire Department report to EPS Vertriebs GmbH as proof of loss. Once the information is received, EPS Vertriebs GmbH will contact you with further instructions.

LIMITED WARRANTY

EPS Vertriebs GmbH, ("The company") warrants that for a period of five (5) years from the date of purchase, this product will be free from defects in material and workmanship. The company, at its sole option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement or repair will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is only valid for the original retail purchaser from the date of initial retail purchase and is not transferable. You must keep the original sales receipt. Proof of purchase is required to obtain warranty performance. EPS Vertriebs GmbH dealers, service centres, or retail stores selling this product do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not apply to the finish on the product. This warranty does not cover normal wear and tear of parts or damage resulting from any of the following: negligent use or misuse of the product, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than the company or an authorized service center, improper installation, or exposure to extremes of heat or humidity. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

The company shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. The company is also not responsible for: costs associated with removing or installing the product; damage or loss of the contents of the product; nor for the unauthorized removal of the contents; or damages incurred during shipment.

Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above Warranty Period.

NOFIRE®



Fire Chest

Model 2011FE

Fire / Water Chest

Model 2013FE

Model 2017FE

Model 2037FE

Model 2037WFE


Read These Instructions Very Carefully!

Congratulations!

Your new NOFIRE® Fire/ Fire Water Chest will provide years of safe and secure storage for valuables and important documents. Your Chest has been built with the highest manufacturing standards to ensure maximum user satisfaction under a variety of conditions.

Package Contents

- 1 NOFIRE® Fire/ Fire Water Chest
- 1 Operation & Installation Guide
- 2 Entry Keys



Proper Use of Your Chest

Fire/ Fire Water Chest protect paper records and other valuable documents. U.L. testing shows that the interior temperature remains below 350°F (177°C) for 30 minutes during a fire up to 1550°F (843°C). Your Fire/ Fire Water Chest is protected by our Lifetime After Fire Replacement Guarantee. Please see details in that section. Verified fire protection for: Memory sticks, CD's & DVD's, USB Drives. This product is NOT INTENDED to protect audio or video cassettes, floppy discs, data cartridges, film and photos or photo negatives.


Waterproof even when fully submerged

Moisture Warning We recommend that you place delicate items such as pictures or intricate jewelry into an air-tight container **before** storing them in your safe. Avoid placing your Chest in areas of high humidity. For optimum performance, the safe should be opened and aired out for at least 20 minutes every two weeks.

To clean your Chest, wash off with a damp cloth and dry. Never use paint thinners or chemical solvents, as they can permanently damage the finish.

Important: ALWAYS STORE SAFE FLAT

Always store your Chest in a flat horizontal position so that the contents remain protected during a fire. Storing the unit on the sides or ends WILL NOT PROTECT CONTENTS during a fire.



For Your Protection

- Always store keys away from (AND NEVER INSIDE) Chest.
- Save this manual and NEVER keep it inside the Chest.

Important: DO NOT RETURN CHEST TO STORE

If you have any questions pertaining to proper use, DO NOT RETURN Chest to the store. Please Contact EPS Vertriebs GmbH.

Your Chest's Unique Identification Numbers

When contacting EPS Vertriebs GmbH Consumer Affairs, you should be prepared to supply some important information that specifically identifies your Chest. This information is extremely important to assuring prompt and accurate assistance.

It is strongly recommended that you identify and record the following information in the "Chest Identification Record" form located on the bottom of this page.

Model Number

The NOFIRE® Home and Office Security Safes product line consists of many different models, each identified by a specific Model #. Every model is manufactured with unique capabilities and features that may require specific solutions to a variety of difficulties that occasionally occur.

Key Number

The Key # is necessary to identify the specific configuration of the key and lock cylinder components of your Chest. If a key becomes damaged or misplaced, the Key # is absolutely required to provide you with a replacement key.

Locating Key Number

The Key numbers are engraved on the keys and around the lock cylinder.

Your Chest Identification Record

Record all Chest Identification Numbers below:

Model Number _____

Key Number _____

Contact Us

EPS Vertriebs GmbH
Lütke Feld 9
48329 Havixbeck
Germany

Central: +49 2507 98750-0
Email: info@eps-vertrieb.de
Web: www.eps-vertrieb.de

Ordering Replacement Keys

Additional keys can be purchased from EPS Vertriebs GmbH. Please have the following information ready:

- Name / Address / Telephone
- Safe Model Number / Serial Number
- Key Number (located on the key and on the Key lock)
- Number of keys requested

Maintenance instructions

For optimal use, the document box should be opened every two weeks and ventilated for at least 20 minutes to allow air to be exchanged.