

## GB Dismantling Instructions

### LED desk lamp

Item no: 2481634

#### 1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.

#### 2 Dismantling instructions

##### Step 1

Remove 4pcs screws on the lamp arm.



##### Step 2

Open the shell of the lamp.



##### Step 3

Take out the LED board carefully.



##### Step 4

Cut off the wire at the end of the LED board.



This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau ([www.conrad.com](http://www.conrad.com)).

All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited. This publication reflects the technical status at the time of printing.

Copyright by Conrad Electronic SE.

\*2481634\_V1\_0622\_hs\_en 586595723 I1/O1 en