

PL012 Rechargeable Penlight

Item no: 2497598

1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.

2 Dismantling instructions

Step 1

Overview



Step 2

Disassemble from the top.



Step 3

Remove the magnet.



Step 4

Carefully remove the lens.



Step 5

Remove the battery, LED and PCB as shown.



This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com).
All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited.
This publication reflects the technical status at the time of printing.
Copyright by Conrad Electronic SE.
*2497598_V1_0622_hs_en 566822539 I1/O1 en