
Inflatable Neck Massage Cushion Item no: 2498118



User's manual

Directory

Precautions	01
Essential knowledge	02
Charging method	03
Instructions	04
Product parameters	05-06
Warranty	07
Warranty Card	08

G

tills brodder, pispose in accordance with rocal environmental laws and Buidennes. This product should not be discarded with household waste. When you decide to discard Disposal and recycling

broduct by themselves.

technicians should be asked to repair it, Non-professionals cannot disassemble the no not piace neavy objects on the instrument, when a fault occurs, professional performed with the power off. The instrument should be placed in a safe place after use. Take measures to prevent moisture, rodents and pollution, Cleaning should be

Check the power supply. It the power supply voltage exceeds the specified range, do not

Avoid rain, snow, splashing and collision.

air, rail, road and ship transportation.

The product packaging is equipped with simple shockproof facilities, which is suitable for

right exposure and corrosive gas attack.

Please keep it away from water, fire or wet space.

inspected to recharge the machine before use.

When the storage period exceeds 3 months, the machine should be unpacked and

Charging interface	USB-C™
Battery capacity	4Am 00SS
Rated voltage	A1 -V2
Rated power	M S
Model	EE-4003

To ensure that you use this product correctly and safely, be sure to read the Manual. For incorrect use or failure to follow the instructions

The company is not responsible for the consequences

- 1. Do not use this product while driving.
- When using, please remove the accessories or items that may affect the massage.
- 3. Do not use in a humid environment such as a bathroom.
- 4. Keep this product away from water, fire and corrosive environment
- 5. When used in a specific environment, observe safety regulations.
- 6. Do not use it on the massage site
- 7. Do not use if the massage area has discomfort such as skin damage, redness, inflammation and congestion
- 8. Do not use it if you have a history of heart disease or illness, patients with acute illness, patients with skin disease, patients with malignant tumors, or those with physical abnormalities.
- 9. Do not use for patients with blood diseases such as bleeding tendency, osteoporosis, soft tissue disease and stroke
- 10. Do not use if you have a slow movement, mental or physical discomfort, or mental retardation. If you need to use it, please follow your doctor's advice.
- 11. Please stop using if discomfort during use
- Pregnant women and menstrual women should not use the massager. 12. Use by children under 6 years of age is prohibited. Children 6-12 years of age must be used under the guidance and care of their parents or persons with supervision.
- 13. If you need to clean the appearance, you should use alcohol cotton to avoid cleaning with water
- 14. Keep sharp objects away. Sharp objects can damage the product.
- 15. This product is a home electronic health care product, it is not intended as a medical device and is not intended for diagnostic, therapeutic, and other commercial uses.
- 16. Please use the charging equipment configured by our company to charge the product and pay attention to the safety of electricity use.
- 17. If an abnormal phenomenon occurs during use, please cut off the power immediately.
- 18. Do not disassemble or repair it by yourself
- 19. The product has a hot moxibustion function, and the device has a heating surface, so people who are not sensitive to heat must pay attention when using it,

ueck and skin during use * For the first time use, or people with sensitive skin, please observe the changes in the

> Please check if the air valve is open when starting the inflation Deflate by pressing the air valve Compressed air valve design instructions for inflation and deflation

The heating is on by default when the machine is turned on.

Heating function

UO SÁPMIP When charging-LED red light is always on; when fully charged-LED green light is

Two-color light, normal operation when booting-LED flashes green; low voltage-LED

- э. сер іпаісапоп massage head starts to rotate;
- The product is inflated when the product is turned on. After the air bag is full, the
 - switch modes and the buzzer sounds.
- There are 2 modes of massage head rotation. Press the [5witch Button] shortly to 3. Massage tunction
- three "drops"; Intu ou: The buzzer will sound a short "drop" I, shut down: the buzzer will short
- Long press [Switch Button] (225) to turn on or off,
 - Power on / off function sport "dididi" beeps;
- 10 min timing, when the time is up, the buzzer will turn off automatically after three T. IIMINg Tunction
 - Use after removing the adapter.
- This product cannot be used while charging. After charging is complete, turn the power

Essential knowledge

* About use frequency

Use as needed, it is recommended to control the massage time for each use within 10-30 minutes and use it at appropriate intervals, Excessive use may cause physical discomfort, neck and skin injuries. Therefore, when using for the first time, you need to observe the physical condition and the changes of the shoulder, neck and skin to minimize the use

* About suitable size

This product is suitable for a neck circumference of about 30 to 40 cm.

* About usage

When using this product, please lean on the back of your chair and relax your body completely.

Please remove jewelry such as necklaces, neck-hook headphones, and neck-tags. If you feel pain or discomfort around the shoulder and neck, stop using it and consult a doctor immediately

* About the state after use

The neck and surrounding area may turn red for a short time, but will recover after a period of time as is.

* Other

During use, it will make a special sound, which is the rotation of the massage head and the sound made when adjusting the airflow is not an abnormality of the product.

2

Both the power button and the mode button are recessed, with a little bump next to the You can tell the position and type of the keys by touch.

Operation panel may be left or right after wearing

of the head, and wear the product on the neck

- 2. Hold the hands at both ends of the host, wrap from the top of the head to the back The maximum neck circumference for this product is about 40 cm
 - 1. Press the button in the middle of the pull buckle to separate the pull buckle
 - - 3. When the red-light flashes, please charge immediately,
 - 2. When fully charged, use it for 10 minutes each time (mode 1 and mode 2).
 - It takes about 3.5 hours to fully charge. പാരാളുനള വന
- * It is normal for the main unit and power adapter to heat up slightly during charging. riasnes. Arter charging is completed, the charging lamp is on.
- The main unit emits a beep sound, and then the charging lamp on the control panel Plug the power adapter into the socket,

 - 1. Connect the USB charging cable to the host

Product parameters Charging method