

GB Dismantling Instructions

LED Work Light (60 W)

Item no: 2568479


1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.

2 Dismantling instructions

Step 1

Remove 12pcs of screws from the front of the light fixture by using a screwdriver.



Step 2

Remove 2pcs of the red plastic housings.




Step 3

Remove 18pcs of screws from the back of the fixture by using a screwdriver.




Step 4

Remove a black plastic housings.




Step 5

Open the PC lampshade.




Step 6

Remove 6pcs of screws on the PCB by using a screwdriver.



Step 7


Open the lamp module.




Step 8
Remove the three wires which are connecting the switch by using a screwdriver to press the connection terminal.



Step 9
Short-circuit the grey and black connection terminals with the wire.




Step 10
Remove 4pcs of screws by using a screwdriver to secure the PCB of the power supply.



Step 11
Cut the input line L/N by using a scissor and keep 7-10mm length from the wire ends.



Step 12
Remove the driver with LED module for SLR testing.



This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com).
All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited.
This publication reflects the technical status at the time of printing.
Copyright by Conrad Electronic SE.
*2568479_V1_0622_hs_en 580287755 11/01 en