

GB Dismantling Instructions

Flexible LED strip

Item no: 2612391

1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.

2 Dismantling instructions


Step 1

Remove 6pcs screws from the housing cover.



Step 2

Remove the front panel.



Step 3

Desolder the cables and light source board.



Step 4

Remove 4pcs screws from the light source board.



Step 5

Remove light source.



This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com).
All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited.
This publication reflects the technical status at the time of printing.
Copyright by Conrad Electronic SE.
*2612391_V1_1022_hs_en 694714635 I1/O1 en