Dismantling Instructions

LED Work Light

Item no: 2614575 (Work light) Item no: 2614576 (Work light + tripod)

1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.

2 Dismantling instructions

Notes:

- The product and photos are slightly different, but the steps for removing the light source are the same.
- Repeat steps 1 6 for each light source.

Step 1




Unscrew 6x housing cover screws.

Step 2



Remove the front panel.

Step 3



Unsolder the connection between the power cord and light board.

Step 4



Unscrew 4x light source board screws.

Step 5



Remove the light source.

This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com).

All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited. This publication reflects the technical status at the time of printing.

Copyright by Conrad Electronic SE.

*ProductNameAndBn_V1_1222_hs_en 759058443 I1/O1 en