Dismantling Instructions

Rechargable LED work light, 2500 LM Item no: 2734751

1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.


2 Dismantling instructions

Step 1

Remove the 4 screws and open the back cover.




Step 2 Remove the 4 screws and open the handle.





Step 3 Disconnect the wire and take out the lamp head.




Step 4 Remove the 8 screws and open the lamp cover.




Step 5 Remove the 4 screws and open LED head.



Step 6 Desoldering the wire solder.




Step 7 Remove the 4 screws.



Step 8





This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com). All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited. This publication reflects the technical status at the time of printing. Copyright by Conrad Electronic SE.

*2734751_V1_0623_hs_en 893545355 I1/O1 en