





# SHORT MANUAL

## Teaching a transmitter to recognise a receiver

1. Press the button  at the receiver for 5 seconds until the status LED flashes.
2. Depending on the model press the channel or learn button  on the transmitter - finished!

## Deleting a transmitter on a receiver

1. Press the button  at the receiver for 5 seconds until the status LED flashes.
2. Depending on the model press the channel or learn button  on the respective transmitter - finished!

## Dimming of lamps

(only suitable for receivers with dimming function)

1. Press transmitter ON button 1x briefly to switch on the connected lamp.
2. Press ON button 1x briefly again to start the dimming process.
3. By short pressing the OFF button the dimming process will stop and the brightness will be retained.

**Up to 8 transmitters per receiver!**