

Data Cable Weco RS 232 (392476)

08.03.2022


WeCo MONITOR 232 / USB PC CONNECTION

Screw Terminal Side	Cable 232 / RJ45
PIN1	-
PIN 2 T/R-	RX
PIN 3 RXD+	TX
PIN 4	-
PIN 5	GND
PIN 6	-



RJ 45 TO WIRE - PIN DEFINITION-

- PIN 01 = TX
- PIN 02 = RX
- PIN 03 = GND
- PIN 04 = none
- PIN 05 = none
- PIN 06 = none
- PIN 07 = none
- PIN 08 = none



WECO OLP RS232 (USB / RS232 converter is necessary to communicate with the battery, need to be ordered separately)

**PC -Battery communication and set up for 232-USB device is available for auth. Installers.*