

Magnet wall lamp

Item no: 3026634

1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.

2 Dismantling instructions


Step 1

Take off the back plate.



Step 2

Use a screwdriver to remove the screws on the magnet and mounting plate.




Step 3

Use a screwdriver to remove the screw x 2 of the frame.




Step 4

Use a cutter to cut off the LED COB wire.




Step 5

Use a screwdriver to remove the screw x 2 on the cover.



Step 6

Unsolder the wire over the LED.



Step 7

Use a screwdriver to remove the screw x 2, take out the LED for testing.

