

Vitesse Ultra




Keep this quick start guide for future reference.
Keep this equipment away from humidity.
If any of the following situation arises, get the device checked by a service technician.

- The equipment has been exposed to moisture.
- The equipment has been dropped and damaged.
- The equipment has obvious sign of breakage.
- The equipment has not been working well or you cannot get it work according to quick start guide.

No part of this publication may be reproduced in any form by any means without the prior written permission.

Regardless of any direct acknowledgement elsewhere in the body of this document, WAVLINK hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and other related documents are the property of their respective holders.

Information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential or other damage.




- 1 -

When using the product, the ambient light is always on. Touch to turn the ambient light off and on.

1 x AX5400 Tri-band Wireless Adapter
1 x USB 3.0 Cable
1 x Quick Start Guide

Windows 10/11

Connect the adapter to your host via involved USB 3.0 cable.



- 2 -

The following steps are based on a Windows 10 (19044.1706) system.

1. Open this PC and click on the **CD Drive**.



- 3 -

Step 1: When the computer turned on, insert the wireless card into an open USB port

Step 2: Left-click network icon in the task bar to turn on the new WiFi.

Step 3: Select the Wi-Fi SSID you want to connect and type the Wi-Fi password.



- 4 -



Firstly you need to find the right WLAN name of your new wireless LAN card, then you can set it up if necessary, you can change the name in "Network Connections".

If your adapter is not functioning then probably the drivers are missing or the wrong drivers have been installed.

- 5 -

Plug in the USB adapter.

Right-click the computer icon> select Manage > double-click Device Manager> go to network adapter to see if you could find the the Realtek 88xx device.If you could find such device which means the driver should be installed correctly.



- 6 -



Official website: www.wavlink.com
Technical support: support@wavlink.com

备注：