

## Hybrid LED floor lamp

Item no: 3306468

### 1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.

### 2 Dismantling instructions

#### Step 1

Use a flat screwdriver to remove the top cover.



#### Step 2

Remove the lampshade.




#### Step 3

Use a socket wrench to remove the hexagon nut.



#### Step 4

Remove the screwed conduit.



#### Step 5

Take out the light source for ErP testing.



This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com).

All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited. This publication reflects the technical status at the time of printing.

Copyright by Conrad Electronic SE.

\*3306468\_V1\_0425\_hs\_en 2084605707 I1/O1 en