

Electronic Parking Disc
Item no. 3338640



Contents



Parking disc x 1
Instruction manual x 1
CR2450- 3V Battery x 1




Battery holder



PRESS this button to release the battery holder

Product Features



Start the product with placing the battery:

You need a new CR2450 – 3V cell battery
Press the 'battery locker button' as the diagram and carefully insert the battery to the compartment as a start.
Caution : Please always "press" the battery locker button to insert or pull-out the battery holder in order not to damaged the battery compartment.
Replace the battery if the battery symbol shows empty.

Default the clock at the top

In order to activate the setting mode, use a pointed object to **press the button 03** and hold it down until the "Hours"-digits show to flash. As soon as the "Hours" show flashing, press the 02 button several times until adjust the hours. **Press 03** button and "Minutes" will start to flash. Set the minutes using the **02 button**. Proceed the same way to set the year, month and date located at **04** (in that order).



01 02 03 04 05



Remarks :

- 1) The clock & date need to be adjusted from the first-time use and after the battery is changed.
- 2) As long as the time from the clock and date are set, the park timer from the front panel will also be automatically set up. This park timer is triggered by the vibration sensor, once the vehicle stopped over 60 seconds, the parking disc will automatically start itself and default to every 15 or 30 minutes. (e.g. • Default to every 15 minutes: if arrive at 08:10, it will set to 8:15 if arrive at 08:45, it will set to 9:00 • Default to every 30 minutes: if arrive at 08:10, it will set to 8:30, if arrive at 08:45, it will set to 9:00.) And the park timer will stop to show 60secs after your vehicle start to move.
- 3) Manual setting: The parking disc can be set manually. If you wish to set it manually, simply press 02 button for 3 seconds to move the clock forward at 15 or 30 minutes intervals. Press the button down and release once the desired time appears. The front LCD display will move to the set parking time and the small LCD display will show the current time and date. Please note that this function is only available if the parking disc is in night parking mode.
- 4) Changing the time interval: Different countries may have different requirements for setting parking time. Change the interval to 15 or 30 minutes, depending on the parking rules in the respective country. When pressing 01 and 02 at the same time for 3 second, and then pressing 02 to set 15 or 30 minutes. It is possible to change this setting at any time.

Remarks :

- 1) **Press 01** for the backlight for the park timer, please always turn it off by **Press 01** after use in order to save the battery energy.
- 2) **Long Press 01** for the red flashing light **at 05** in case there have emergency situation.



BATTERY WARNING:

KEEP OUT OF REACH OF CHILDREN!

If the battery compartment (if applicable) does not close securely, stop using the product and keep it away from children !

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention !



(E1) 10R-0610067

