


## Preface

Thank you for purchasing the Shanghai PYTES Energy products. For optimum operation, please read this manual carefully before use.


## Introduction

Shanghai PYTES Energy USB to RJ45 Console Cable can connect your computer or laptop's USB port to your vna/router/firewall, switch or other device with a console port. Support HUAWEl/ZTE, TP-link, H3C, and D-link Routers/Switches. Built-in FTDI232RL chip for high stability and multiple operating systems supported.


## Product Details



## How it Works




## How it Works




## Driver Installation

Step 1: Open the driver CD, select your corresponding computer operating system, double click "Setup" application to install, and follow the instructions on the screen to complete the driver installation.



Step 2: When the driver installation is finished, plug the cable and open Device Manager to check if the port (COM and LPT) is running normally.



## Notes

- Do not press external force on this unit.
- Do not expose this unit to moisture or water environment.
- Do not modify, repair or disassemble this product.

## Package Contents

- X1 USB to RJ45 Console Cable
- X1 User Manual
- X1 Warranty Card