

Underbonnet LED Light 3000 lm

Item no: 3479016

1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.

2 Dismantling instructions

Step 1

Remove the protective cover.




Step 2

Take out the screws.




Step 3

Open the shell and remove the wire connector.




Step 4

Open the shell on the other side.




Step 5

Remove the two sets of fixing screws from the holder.




Step 6

Remove the lamp tube cover and take out the LED module, then remove the screws.



Step 7

Pull out the LED board and remove the heat dissipating aluminum.



Step 8

Install the light board into the heat dissipating aluminum, take the light source for testing.



This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com).

All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited. This publication reflects the technical status at the time of printing.

Copyright by Conrad Electronic SE.

*3479016_V1_0126_hs_en 2698388107 I1/O1 en