




Druckschalter mit LED

Pushbutton Switches with LED Interrupteurs Boutons Poussoirs avec LED

2-polig
2 Pole



Funktion Function	Farbe Taste +LED	LED- Type ●	Art.-Nr.	Art.-Nr.
			mit/with LED	ohne/without LED
Schalter R - R Switch ON - (ON)	Rot/Red	A1	1844.2332	1844.1233
	Gelb/Yellow	A3	1844.1732	1844.1733
	Grün/Green	A4	1844.1832	1844.1833
Taster R - T Momentary ON - (ON)	Rot/Red	A1	1844.6235	1844.6234
	Gelb/Yellow	A3	1844.6735	1844.6734
	Grün/Green	A4	1844.6835	1844.6834

Schaltbild/Circuit

