

CONGRATULATIONS

You're now the proud owner of the ROCCAT™ Pyra Mobile Gaming Mouse. Designed for optimum use while travelling or gaming with a notebook, it's the perfect companion for every gamer who likes to remain flexible and mobile. The mouse features a world-exclusive innovation, the so-called EasyShift[+] button, which enables you to assign double functions and macros to all the mouse buttons, virtually duplicating their number.

Macro Manager

Not only can you use the driver software to change the DPI settings or the preset functions, you can also create macros for games and applications with it. These control sequences can consist of up to 200 button actions and can be assigned to each of the mouse buttons.

ROCCAT™ EasyShift[+]

Besides the normal functions of a 5-button mouse, the sophisticated Pyra features an innovative EasyShift[+] button, which allows 2nd level functions to be assigned to the mouse buttons and the scroll wheel. In this way, you can virtually double the number of functions that can be used at any one time.

Unisize design

The handy size and symmetric shape of the Pyra are not only perfect for transport and mobile gaming on notebooks, these features also transform the mouse into an exceptionally versatile device: It is suitable for right and left-handed use and fits into any hand size.



SPECIFICATIONS

PACKAGE CONTAINS

- ROCCAT™ Pyra – Mobile Gaming Mouse
- Quick Install Guide
- Driver CD
- ROCCAT ID Card
- Soft Transport Bag

TECH SPECS

- 5 mouse buttons (+2 incl. mouse wheel)
- EasyShift[+]: up to 12 functions at once
- 1600dpi optical sensor
- 1000Hz polling rate
- 130ips maximum speed
- 30G acceleration
- 1.5m USB cable

SYSTEM REQUIREMENTS

- Windows® XP 32-bit
- Windows Vista®
- Windows® 7
- USB 1.1 Port
- CD-ROM Drive



QUICK INSTALLATION GUIDE

IMPORTANT DOCUMENT


© 2010 ROCCAT GmbH. All rights reserved. Any product names mentioned in this manual may be trademarks or registered trademarks and are the property of their respective owners. Information contained herein is subject to change without notice. ROCCAT GmbH shall not be made liable for any errors that may appear in this manual. This publication or parts of it may not be reproduced without the express consent of the publisher.

ROCCAT GmbH
Otto von Behrenpark
Gasstrasse 6b, Building N
22761 Hamburg
Germany


WWW.ROCCAT.ORG/SUPPORT

Should you need assistance ...
Our support team will help you with any technical problems –
just send us an email (support@roccat.org) or visit our website:


1 CONNECT TO COMPUTER (USB)



2 DRIVER INSTALLATION



3 SWITCH HAND MODE



PRESS 4 + 5 DURING PLUG IN
= Change hand mode from right- to left-handed


4 BUTTON ASSIGNMENT (right-handed mode)

STANDARD BUTTON ASSIGNMENT

- 1 = Left Mouse-Button
- 2 = Right Mouse-Button
- 3 = Middle Mouse-Button
- 4 = EasyShift[+] Button #1
- 5 = EasyShift[+] Button #2
(Disabled on delivery, please use driver interface to assign a function.)
- 6 = Mouse Wheel Up
- 7 = Mouse Wheel Down

EASYSHIFT[+] BUTTON ASSIGNMENT

- 4 + 1 = Browser Back
- 4 + 2 = Browser Forward
- 4 + 3 = Mute Volume
- 4 + 5 = Disabled on delivery
(Please use driver interface to assign a function.)
- 4 + 6 = Volume Up
- 4 + 7 = Volume Down



EN

1. Connect the mouse to a free USB port on your notebook or PC.
2. Insert the Pyra driver CD in your CD-ROM drive and follow the instructions on the screen.
3. To switch from right-handed mode to left-handed mode, simultaneously press buttons 4 and 5 while connecting the mouse on.

DE

1. Verbinde die Maus mit einer freien USB-Schnittstelle deines Notebooks oder PCs.
2. Lege die Pyra-Treiber-CD in dein CD-ROM-Laufwerk und folge den Anweisungen auf dem Bildschirm.
3. Um vom Rechts- in den Linkshänder-Modus zu wechseln, drücke gleichzeitig die Tasten 4 und 5 während du die Maus anschließt.

ES

1. Conecta el ratón a un puerto USB que esté libre en tu ordenador de mesa o portátil.
2. Coloca el CD del controlador Pyra en la unidad de CD-ROM y sigue las instrucciones que aparecen en pantalla.
3. Para cambiar del modo diestros a zurdos pulsa al mismo tiempo los botones 4 y 5 mientras conectas el ratón.

FR

1. Relie la souris à une prise USB libre de ton ordinateur portable ou de ton PC.
2. Insère le CD du pilote Pyra dans ton lecteur de CD-ROM et suis les instructions qui s'affichent à l'écran.
3. Pour passer du mode droitier à gaucher, appuie simultanément sur les boutons 4 et 5 lorsque tu raccordes la souris.

FI

1. Liitä hiiri kannettavan tietokoneen tai PC:n vapaaseen USB-liitäntään.
2. Aseta Pyra-ajuri-CD CD-ROM-asemaan ja noudata näytöllä näkyviä ohjeita.
3. Vaihda oikeakätisestä tilasta vasenkätiseen tilaan painamalla samanaikaisesti painikkeita 4 ja 5 hiirtä liittäessäsi.

DK

1. Slut musen til en ledig USB-port på din laptop eller pc.
2. Læg Pyra-driver-CD'en i dit CD-ROM-drev, og følg anvisningerne på skærmen.
3. For at skifte fra højre- til venstrehåndsmodus skal du trykke samtidig på tasterne 4 og 5, mens du tilslutter musen.

RU

1. Соедини мышку со свободным USB-портом ноутбука или компьютера.
2. Вставь CD с драйверами Pyra в дисковод и следуй указаниям на экране.
3. Для переключения режимов для правой и левой одновременно нажать кнопки 4 и 5 во время подсоединения мышки.

PL

1. Podłączyć mysz do wolnego złącza USB laptopa lub komputera PC.
2. Włożyć załączoną płytę CD ze sterownikami do napędu CD-ROM komputera i postępować zgodnie z instrukcjami na ekranie.
3. Aby przełączyć tryb pracy z praworęcznego na leworęczny, nacisnąć jednocześnie przyciski 4 i 5 podczas podłączania myszy.

TR

1. Fareyi dizüstü bilgisayarın ya da PC'nin boşta kalan bir USB portuna bağla.
2. Pyra sürücü CD'sini CD-ROM sürücüne tak ve ekrandaki talimatları izle.
3. Sağ el modundan sol el moduna geçmek için fareyi bağlarken aynı anda 4 ve 5 tuşlarına bas.

SE

1. Koppla musen till en ledig USB-port på din laptop eller PC.
2. Lagg in skivan med Pyras drivrutin i CD-enheten och följ anvisningarna på bildskärmen.
3. För att ändra till läget för vänsterhänta trycker du på knapparna 4 och 5 samtidigt som du ansluter musen.