

Overview

1. Multifunction Button For Bluetooth® Pairing / Play / Pause

2. Mode Button Change from Bluetooth® Aux-in → MicroSD → USB Audio

AUX-IN (Blue)
SD CARD (Green)
USB AUDIO (Purple)

Vol - Vol +

100% - 75%
75% - 50%
50% - 25%
25% - 1%

PC/MAC

* (Not included)

Source Selection

Bluetooth®

USB Audio

SD Card

Source: Bluetooth®

LED

OR

3 sec

3 sec

3 sec

M + - = ⏪

M + + = ⏩

Take call

3 sec

M = 📞 / 🎤

Mute call

3 sec

Reject call

> 2 sec

Aux-in

Mobile Device

PC/MAC

Wireless Stereo: Link

OFF → ON

3 sec

3 sec

3 sec

3 sec

LL

RR

LL

RR

Wireless Stereo: Unlink

OFF

> 15 sec

> 15 sec

LL

RR

LL

RR

OR

> 15 sec

> 15 sec

LL

RR

LL

RR

AUX-IN
USB Audio
SD-Card
Bluetooth®

Register your products at www.creative.com/register

TECHNICAL SUPPORT www.creative.com/support

© 2016 Creative Labs Pte. Ltd. All rights reserved. Creative, the Creative logo, and MUVO are trademarks or registered trademarks of Creative Technology Ltd in the United States and/or other countries. The Bluetooth® word mark and logo are owned by the Bluetooth® SIG, Inc. and any use of such marks by Creative Technology Ltd is under license. microSDHC, microSDXC logos are trademarks of SD-3C, LLC. All other trademarks are the property of their respective owners and are hereby recognized as such. All specifications are subject to change without notice. Actual product may differ slightly from images shown. Use of this product is subject to a limited warranty.

EN | Technical Specifications

Bluetooth® Version: Bluetooth® 4.2
Operating Frequency: 2402 - 2480 MHz
Operating Range: Up to 10 meters, measured in open space. Walls and structures may affect range of device.
Supported Bluetooth® Profiles: A2DP (Wireless Stereo Bluetooth®), AVRCP (Bluetooth® Remote Control), HFP (Handsfree profile)
Supported Codec: SBC
Supported Audio Formats (For SD card playback): MP3, WAV, WMA, FLAC
Does not support WMA PRO/lossless, (Extra High and above)
Support USB Audio for PC/MAC
Lithium Ion Battery: 3.7V 650mAh (2.41Wh)
Input: 5V 650mA
Battery Saving Mode: The speaker automatically powers down when there is no Bluetooth® connection or no audio cable attached for more than 10 minutes.
Operating Temperature Range: 0°C - 45°C
Note: Compliance markings are located on the bottom of this product.
*** Not Included. Sold Separately.**

Other Information

For the latest, online version of this guide, DoC and supplementary documentation such as safety and regulatory information for this product, please visit [creative.com/support/muvo2c](http://www.creative.com/support/muvo2c)
Detailed instructions on removal of integrated battery can be found at Quickstart User Guide / Safety and Regulatory Information ([creative.com/support/muvo2c](http://www.creative.com/support/muvo2c)), these instructions are meant strictly for independently qualified professionals.

Notice for Singapore

Complies with IDA Standards DA 107311

Source: SD Card

LED

3 sec

3 sec

MicroSD (SD Card 128GB Max)

Fat 16, 32
MP3, WMA, Flac, WAV

M + - = ⏪

M + + = ⏩

Hold M + Hold - = 📁

Hold M + Hold + = 📁

Read SD Card

0%

100%

PC/MAC

Source: USB Audio

LED

3 sec

3 sec

M + - = ⏪

M + + = ⏩

Wireless Stereo: Unlink

OFF

> 15 sec

> 15 sec

LL

RR

LL

RR

Wireless Stereo: Link

OFF

3 sec

3 sec

3 sec

3 sec

LL

RR

LL

RR

