





415QR N 435SG-QR N
415QRL N 452QR
415SGH N 512QR N
415SG-QR N 512SG-QR N
416QR 516QR
418QR 517QR
435QR N

Repair instructions




MADE IN CROENBERG
MADE IN GERMANY


FREQUENT USE



INFREQUENT USE




SPARE PARTS


			NLGI-Class*
415QR N 415QRL N 415SG-QR N 416QR 418QR	1/4"	19012020	1
415SGH N	1/4"	19010013	1
435QR N 435SG-QR N 452QR	3/8"	19021020	1
512QR N 512SG-QR N 516QR 517QR	1/2"	19042020	1

*ASTM D217, DIN 51818


1




2




3




4




5




6 CLEAN




7




8




9




10



11



12



TOOLS
... that inspire

STAHLWILLE Eduard Wille GmbH & Co. KG
Lindenallee 27 · 42349 Wuppertal · Germany
Tel.: +49 202 4791-0 · Fax: +49 202 4791-200
info@stahlwille.de · www.stahlwille.com

© STAHLWILLE Eduard Wille GmbH & Co. KG // 20-02-23 DHF // V 2.0 // 91979798

 service.stahlwille.com