



- Sollten Sie noch Fragen haben, die in dieser Bedienungsanleitung nicht beantwortet werden, wenden Sie sich an unseren technischen Kundendienst oder an andere Fachleute.

ⓓ Bedienungsanleitung

Selfie Light

Best.-Nr. 1543956

Bestimmungsgemäße Verwendung

Das Produkt dient als mobile Lichtquelle. Durch die kleine Bauform und den integrierten praktischen Clip können Sie es zur besseren Ausleuchtung bei Selfies verwenden. Die Helligkeit ist in 3 Stufen wählbar.

Ein fest eingebauter, nicht wechselbarer Akku dient zur Stromversorgung. Das Aufladen des Akkus erfolgt z.B. über ein geeignetes USB-Netzteil oder den USB-Anschluss eines Notebooks/Computers.

Aus Sicherheits- und Zulassungsgründen dürfen Sie das Produkt nicht umbauen und/oder verändern. Falls Sie das Produkt für andere Zwecke verwenden, als zuvor beschrieben, kann das Produkt beschädigt werden. Außerdem kann eine unsachgemäße Verwendung Gefahren wie z.B. Kurzschluss, Brand etc. hervorrufen. Lesen Sie sich die Bedienungsanleitung genau durch und bewahren Sie diese auf. Reichen Sie das Produkt nur zusammen mit der Bedienungsanleitung an dritte Personen weiter.

Dieses Produkt erfüllt die gesetzlichen, nationalen und europäischen Anforderungen. Alle enthaltenen Firmennamen und Produktbezeichnungen sind Warenzeichen der jeweiligen Inhaber. Alle Rechte vorbehalten.

Lieferumfang

- Selfie Light
- USB-Kabel
- Bedienungsanleitung



Aktuelle Bedienungsanleitungen

Laden Sie aktuelle Bedienungsanleitungen über den Link www.conrad.com/downloads herunter oder scannen Sie den abgebildeten QR-Code. Befolgen Sie die Anweisungen auf der Webseite.

Symbol-Erklärung



Das Symbol mit dem Ausrufezeichen im Dreieck weist auf wichtige Hinweise in dieser Bedienungsanleitung hin, die unbedingt zu beachten sind.



Das Pfeil-Symbol ist zu finden, wenn Ihnen besondere Tipps und Hinweise zur Bedienung gegeben werden sollen.

Sicherheitshinweise



Lesen Sie sich die Bedienungsanleitung aufmerksam durch und beachten Sie insbesondere die Sicherheitshinweise. Falls Sie die Sicherheitshinweise und die Angaben zur sachgemäßen Handhabung in dieser Bedienungsanleitung nicht befolgen, übernehmen wir für dadurch resultierende Personen-/Sachschäden keine Haftung. Außerdem erlischt in solchen Fällen die Gewährleistung/Garantie.

a) Allgemein

- Das Produkt ist kein Spielzeug. Halten Sie es von Kindern und Haustieren fern.
- Lassen Sie das Verpackungsmaterial nicht achtlos liegen. Dieses könnte für Kinder zu einem gefährlichen Spielzeug werden.
- Das Produkt darf nicht feucht oder nass werden.
- Schützen Sie das Produkt vor extremen Temperaturen, direktem Sonnenlicht, starken Erschütterungen, brennbaren Gasen, Dämpfen und Lösungsmitteln.
- Setzen Sie das Produkt keiner mechanischen Beanspruchung aus.
- Wenn kein sicherer Betrieb mehr möglich ist, nehmen Sie das Produkt außer Betrieb und schützen Sie es vor unbeabsichtigter Verwendung. Der sichere Betrieb ist nicht mehr gewährleistet, wenn das Produkt:
 - sichtbare Schäden aufweist,
 - nicht mehr ordnungsgemäß funktioniert,
 - über einen längeren Zeitraum unter ungünstigen Umgebungsbedingungen gelagert wurde oder
 - erheblichen Transportbelastungen ausgesetzt wurde.
- Gehen Sie vorsichtig mit dem Produkt um. Durch Stöße, Schläge oder dem Fall aus bereits geringer Höhe wird es beschädigt.
- Achtung, LED-Licht:
 - Nicht in den LED-Lichtstrahl blicken!
 - Nicht direkt oder mit optischen Instrumenten betrachten!
- Lassen Sie Wartungs-, Anpassungs- und Reparaturarbeiten ausschließlich von einem Fachmann bzw. einer Fachwerkstatt durchführen.

b) Akku

- Der Akku ist fest eingebaut, er ist nicht wechselbar.
- Laden Sie den Akku regelmäßig auf (etwa alle 3 Monate), auch wenn Sie das Produkt nicht verwenden. Andernfalls könnte der Akku tiefentladen werden, was diesen dauerhaft beschädigt.
- Bei Beschädigungen am Gehäuse kann es auch zu einer Beschädigung des Akkus kommen. Ein auslaufender oder beschädigter Akku kann bei Hautkontakt Säureverätzungen hervorrufen. Tragen Sie Schutzhandschuhe, wenn Flüssigkeiten aus dem Akku/Produkt austreten.
- Laden Sie den Akku nicht mehr auf, wenn das Produkt beschädigt ist, sondern entsorgen Sie das Produkt umweltgerecht.
- Werfen Sie das Produkt nicht ins Feuer. Es besteht Explosionsgefahr durch den Akku!

Bedienung

a) Aufladen

→ Schalten Sie das Selfie Light vor einem Ladevorgang aus.

- Betätigen Sie den Clip, dann wird die im Gehäuse liegende MicroUSB-Buchse sichtbar.
- Sie können das Selfie Light über das beiliegende USB-Kabel mit einem USB-Netzteil oder einem USB-Port eines Computers bzw. USB-Hubs verbinden. Stecken Sie Ihr USB-Netzteil in eine Netzsteckdose bzw. schalten Sie den Computer ein.

Durch die MicroUSB-Buchse kann das Selfie Light auch mit einem entsprechenden USB-Netzteil Ihres Smartphones oder Tablets aufgeladen werden.

- Der Ladevorgang dauert bei vollständig leerem Akku ca. 1 Stunde; während dem Ladevorgang leuchtet eine rote LED am Selfie Light. Die rote LED erlischt, wenn der Akku aufgeladen ist. Trennen Sie dann das Selfie-Light von der Stromversorgung.

b) Befestigung

- Über den Clip kann das Selfie Light an Gegenständen befestigt werden, z.B. einem Selfie-Stick oder auch am Smartphone/Tablet.
- Richten Sie die Frontseite so aus, dass die Vorderseite zu Ihnen hin liegt (die Seite mit dem Taster ist die Rückseite).

c) Einschalten, Helligkeit wählen, ausschalten

- Drücken Sie die kleine Bedientaste auf der Rückseite kurz, um das Selfie Light einzuschalten. Die niedrigste Helligkeitsstufe ist jetzt aktiviert.
- Durch mehrfaches kurzes Drücken der Bedientaste können Sie eine der drei Helligkeitsstufen wählen (niedrig, mittel, hoch).
- Halten Sie die Bedientaste länger gedrückt, um das Selfie Light auszuschalten.

Pflege und Reinigung

- Verwenden Sie auf keinen Fall aggressive Reinigungsmittel, Reinigungsalkohol oder andere chemische Lösungen, da dadurch das Gehäuse angegriffen oder gar die Funktion beeinträchtigt werden kann.
- Verwenden Sie ein trockenes, faserfreies Tuch zur Reinigung des Produkts.

Entsorgung



Elektronische Geräte sind Wertstoffe und gehören nicht in den Hausmüll. Entsorgen Sie das Produkt am Ende seiner Lebensdauer gemäß den geltenden gesetzlichen Bestimmungen.

Technische Daten

Stromversorgung.....	LiPo-Akku, 3,7 V, 55 mAh (fest eingebaut, nicht wechselbar)
Ladebuchse.....	MicroUSB (Eingang: 5 V/DC)
Stromaufnahme bei Ladevorgang.....	ca. 50 mA
Ladedauer.....	ca. 1 h (bei vollständig leerem Akku)
Betriebsdauer bei vollem Akku.....	max ca. 40 min (max. Helligkeit)
Leuchtmittel.....	9 LEDs (fest eingebaut, nicht wechselbar)
Lichtstrom.....	160 lm (höchste Helligkeitsstufe)
Lichtfarbe.....	5000 K (Neutralweiß)
Betriebs-/Lagerbedingungen.....	-30 °C bis +60 °C, 20% bis 98% relative Luftfeuchte, nicht kondensierend
Abmessungen.....	59 x 39 x 25 mm (L x B x H)
Gewicht.....	12 g



• Rechargeable battery

- The rechargeable battery is permanently installed and cannot be replaced.
- Charge the rechargeable battery regularly (about every 3 months), even if you don't use the product. Otherwise the battery may become deeply discharged, which would cause permanent damage to it.
- Any damage to the casing may also lead to battery damage. Leaking or damaged batteries can cause acid burns upon contact with the skin. Wear protective gloves if fluids leak out of the battery/product.
- Do not recharge the battery if the product is damaged. Instead, dispose of the product in an environmentally compatible manner.
- Do not throw the product into a fire. There is danger of explosion due to the rechargeable battery!

GB Operating instructions

Selfie light

Item no. 1543956

Intended use

The product is intended to be used as a mobile light source. With its small design and convenient clip-on feature, it can be used to give your selfies better lighting. It is possible to choose from 3 different brightness levels.

The product is powered by a non-replaceable, rechargeable battery, which can be charged, e.g., from a suitable USB power adapter or the USB port of a notebook/computer.

For safety and approval reasons, you may not convert and/or alter the product. If you use the product for other purposes than those described above, the product may be damaged. Furthermore, improper use may cause risks such as short-circuits, fire, etc. Please read the operating instructions carefully and do not discard them. If you pass the product on to a third party, please hand over these operating instructions as well.

This product complies with the applicable national and European requirements. All names of companies and products are the trademarks of the respective owners. All rights reserved.

Package contents

- Selfie light
- USB cable
- Operating instructions



Up-to-date operating instructions

Download the latest operating instructions via the link www.conrad.com/downloads or scan the QR code. Follow the instructions on the website.

Explanation of symbols



An exclamation mark in a triangle indicates important instructions in these operating instructions which must be adhered to.



The arrow symbol is used when specific tips and information on the operation are provided.

Safety instructions



Please read the operating instructions carefully and pay particular attention to the safety instructions. We do not assume liability for any injuries/material damages resulting from failure to observe the safety instructions and the information in these operating instructions regarding the proper use of the product. Furthermore, in such cases, the warranty/guarantee will be null and void.

a) General information

- The product is not a toy. Keep out of the reach of children and pets.
- Do not leave packaging material lying around carelessly. This could become a dangerous plaything for children.
- The product must not get damp or wet.
- Protect the product from extreme temperatures, direct sunlight, strong vibrations and combustible gases, vapours and solvents.
- Never expose the product to mechanical stress.
- If safe operation is no longer possible, take the device out of service and secure it against unintended use. Safe operation is no longer possible, if the product:
 - shows visible signs of damage,
 - no longer functions properly,
 - has been stored under adverse ambient conditions for an extended period of time or
 - has been exposed to considerable strain during transport.
- Please handle the product with care. The product can be damaged if crushed, struck or dropped, even from a low height.
- Attention, LED light:
 - Do not look directly into the LED light!
 - Do not look directly or with optical instruments into the light!
- Maintenance, adjustment and repair work should only be carried out by an expert or a specialised workshop.
- If you have any questions that are not answered in these operating instructions, please contact our technical customer service or other professionals.

Operation

a) Charging



Turn off the selfie light before charging.

- Press the clip. The micro USB socket inside the casing will then become visible.
- You can connect the selfie light to a USB power adapter or a USB port of a computer or USB hub via the supplied USB cable. Plug your USB power adapter into a mains socket or switch on the computer.

Using the micro USB socket, the selfie light can also be charged with the corresponding USB power adapter of your smartphone or tablet.

- When the battery is fully discharged, the charging process takes approx. 1 hour; a red LED lights up whilst the battery is charging. The red LED goes out once the battery is fully charged. Disconnect the selfie light from the power supply.

b) Fastening

- Using the clip, you can clamp the selfie light to any object, e.g., a selfie stick or even your smartphone/tablet.
- Align it with the front facing you (the side with the button is the back).

c) Switching on/off, selecting brightness

- Press the small control button on the back briefly to switch on the selfie light. The lowest brightness level is now activated.
- You can select one of the three brightness levels (low, medium, high) by briefly pressing the control button repeatedly.
- To switch off the selfie light, hold the control button down for a longer period of time.

Care and cleaning

- Never use abrasive cleaning agents, rubbing alcohol or other chemical solutions, since these could damage the casing or even impair operation.
- Use a dry, lint-free cloth to clean the product.

Disposal



Electronic devices are recyclable material and do not belong in the household waste. Please dispose of the product, when it is no longer of use, according to the current statutory requirements.

Technical data

Power supply	LiPo rechargeable battery, 3.7 V, 55 mAh (fixed, not replaceable)
Charging socket	MicroUSB (input: 5 V/DC)
Power consumption whilst charging	approx. 50 mA
Charging duration	approx. 1 h (when battery is completely empty)
Max. operating time with full battery	approx. 40 min (at max. brightness)
Light bulb	9 LEDs (firmly mounted, not replaceable)
Luminous flux	160 lm (at highest brightness level)
Light colour	5000 K (neutral white)
Operating/storage conditions	-30 °C to +60 °C, 20% to 98% relative humidity, non-condensing
Dimensions	59 x 39 x 25 mm (L x W x H)
Weight	12 g