

PHILIPS


hue

 personal wireless lighting


T-connector / extension cable





HUE serial number



- ⚠
- EN Use only with Philips Hue 24V SELV IP67 LED power supply!
- DE Verwendung nur mit Philips Hue 24V SELV IP67 LED-Stromversorgung!
- FR Utiliser uniquement avec l'alimentation LED Philips Hue 24V SELV IP67!
- ES Se utiliza solo con la fuente de alimentación LED Philips Hue SELV 24V IP67!
- PT Utilize apenas com fonte de alimentação LED SELV Philips Hue de 24V IP67!
- IT Da utilizzare solo con un alimentatore LED Philips Hue 24V IP67!



User manual
 Benutzerhandbuch
 Notice d'emploi
 Manual de usuario
 Manual do usuário
 Manuale d'uso




Sample set up, add up the wattage of the lights

$$8W + 8W + 8W + 16W = 40W$$

Choose your power supply unit (PSU)

40W PSU: Connect up to 40W of lights and 35 m of cable

100W PSU: Connect up to 100W of lights and 30 m of cable



Signify
 I.B.R.S. / C.C.R.I. Numéro 10461
 5600 VB Eindhoven,
 the Netherlands
 ☎00800-74454775

Signify Australia Limited
 65 Epping Road, North Ryde,
 NSW, 2113 Australia
 Toll Free number: 1300 304 404

Signify New Zealand Limited
 123 Carlton Gore Road
 Newmarket, Auckland 1023
 New Zealand
 Tel: 0800 454 448

www.philips-hue.com

© 2021 Signify Holding
 All rights reserved

4404 029 12662
 Last update: 10/2021