

Einstellen der vierstelligen Zahlenkombination

- 1) Stellen Sie die Zahlenwalze auf die Grundstellung 0000.
- 2) Drücken Sie den roten Knopf und öffnen Sie damit das Faltschloss
- 3) Drehen Sie den seitlich gelegenen Rest-Knopf um 90 Grad im Uhrzeigersinn
- 4) Stellen Sie die Zahlenwalze auf die gewünschte Kombination ein und notieren Sie sich Ihre neue Kombination.
- 5) Drehen Sie den Reset-Knopf nach der Auswahl der Ziffernkombination gegen den Uhrzeigersinn zurück in die ursprüngliche Position.
Die neue Kombination ist nun eingestellt.



BASI GmbH
Konstantinstraße 387
41238 Mönchengladbach
Germany
info@basi.eu
www.basi.eu



facebook.com/BASIGmbH



[@basi_gmbh](https://www.instagram.com/@basi_gmbh)

Setting the 4-digit combination code

- 1) Set the combination wheels to the basic setting 0000.
- 2) Press the red button and open the lock.
- 3) Turn the reset knob on the side 90 degrees clockwise.
- 4) Set the combination wheels to the desired combination and make a note of your new combination.
- 5) After selecting the number combination, turn the reset knob anti-clockwise back to the original position. The new combination is now set.

